

STOLL

Operating instructions

	Type	Computer type	Component type
CMS 530	642 643	OKC5.0	000
CMS 520 C	647	OKC5.0	000
CMS 502	645 646	OKC5.0	000



Date: 2014-10-02

Translation of the original operating instructions

Operating system of the machine: V_OKC_002.008.000_STOLL (or higher)

H. STOLL GmbH & Co. KG, Stollweg 1, D-72760 Reutlingen, Germany

Our products are being developed further continuously. They are therefore subject to technical modifications.

End User Licence Contract (03/2001)

Licence terms in business transactions with entrepreneurs for the use of the STOLL software

Licenser: H. STOLL GmbH & Co. KG, Stollweg 1, D-72760 Reutlingen / Germany.

§ 1 Licensed object and scope of use

- (1) The licensor grants the licensee a not exclusive right to use above-mentioned STOLL software according to the following terms and conditions. The licensor shall provide the licensee with a copy of the object code for the licensed programs. The licence material also includes a program description in printed form. In the following text, the licensed programs and the program description are altogether referred to as "licensed software".
- (2) The licensed software is only intended to be used with the STOLL knitting machine with which the software was delivered and can only be run in connection with this knitting machine. Any other form of use of the licensed software is not permitted.
- (3) The approved use covers the storing of the licensed programs in one data-processing machine, the execution of the programs, the processing of the data stock, as well as the production of copies of the programs to the extent that this is required for contractual use. All rights to the copies shall remain with licensor.
- (4) Additional usufructuary and exploitation rights of the licensee do not exist. The creation of back-up copies, the testing and inspecting of the programs, the processing of the data stock as well as a decompiling are only permissible if this must be imperatively permitted due to legal regulations.
- (5) Licence material handed over in printed form, in particular the program description is only allowed to be reproduced with the written consent of the licensor.
- (6) After having informed the licensor previously in writing, the licensee is allowed to transfer his right of use together with the knitting machine mentioned in Par. (2) in the scope and with the limited conditions resulting from the Par. (1) to (5) entirely to a third party. These conditions must be expressly pointed out to the third party. The transfer within the framework of continuous obligation (e.g. rental, leasing) is not permissible. With the transfer, all the rights of use of the first licensee shall expire, including any rights to copies and adaptations. If these were not handed over to third parties, they must be destroyed.
- (7) Neither the licensee nor the subsequent user has the right to use licensed software in whole or in part on more than one data-processing machine at the same time or distribute any reproduced sections of the licensed software in its original version or in altered adapted versions.

§ 2 Period of use

The granting of the usufruct mentioned under § 1 is provided for an indefinite period of time for the entire economic service life of the licensed software.

§ 3 Safeguarding of the licensed software

- (1) The licensee must ensure that no form of improper use of the licensed software is carried out at his company and that the obligations in accordance with § 1 are also observed by his employees and personnel as well as by other persons working with the package.
- (2) The licensee agrees not to change any protective annotations, such as copyright annotations or any other reservations of rights and agrees to transfer completely into specifically made copies of the licensed software. The licensee is only allowed to use the programs or program sections of other producers included in or related to the licensed software if the licensee accepts the licence terms applicable for such use.

§ 4 Warranty

- (1) The contracting parties are in agreement that, based on the present state of technology, it is not possible to develop programs so that they run without any errors for all application conditions. For the licensed software, the licensor shall hand over to the licensee a program description based on the most recent status in each case that refers to the proper use and conditions of use for the programs. Specific characteristic features shall not be guaranteed unless an agreement to the contrary is reached in individual cases.
- (2) The licensor guarantees that the licensed software is usable within the meaning of the program description issued by him and applicable at the time of delivery to the licensee; an irrelevant diminishment of the usability shall not be taken into account. The licensor also guarantees that the data carrier being used is free of material and manufacturing defects and that the data has been properly recorded on the data carrier. If the licensee operates the licensed software in connection with hardware and software products that do not come from STOLL, the licensee is obliged to furnish proof that a determined error has its cause in the licensed software.

- (3) If the licensed software proves to be useless or defective within the meaning of Par. (2), the warranty is carried out by replacement delivery versus the return of the defective software. If the software delivered on a replacement basis also proves to be useless or defective and the licensor is not able to restore the usability or eliminate the error within a suitable time limit, the licensee can demand, according to his choice, a reduction of the licence fee or reimbursement of the licence fee versus the return of the licensed software.
- (4) Any further warranty, in particular for guaranteeing that the data or the licensed software comply with the requirements and purposes of the licensee shall be excluded.
- (5) The warranty period amounts to twelve months, starting with the date of delivery of the licensed software to the licensee.

§ 5 Liability limitations

- (1) The licensor shall be liable for damages that were caused by a culpable infringement of an essential contractual obligation, for which the licensor is responsible, in a manner endangering the achievement of the contractual purpose. The liability is limited to the contract-typical damage the occurrence of which the licensor had to expect based on the circumstances known to the licensor upon the conclusion of the contract. In any case, the liability is limited to two times the amount of the licence fee paid by the licensee.
- (2) In case of virus contamination, the licensee is responsible for providing proof that the licensed software was contaminated with the virus.
- (3) The licensor shall not be liable for insufficient economic success, lost profits, remote damages and consequential damages and for damages from the claims of third parties with the exception of claims resulting from the infringement of protective rights of third parties.
- (4) For the recovery of data, licensor shall only be liable within the framework of Par. (1) and only if the licensee stored this data in machine-readable form on a daily basis, the corresponding data carrier is available and the data can be reproduced at reasonable expense.
- (5) The aforementioned liability limitations do not apply to damages that have been proved to be based on premeditation or gross negligence on the part of licensor or on the lack of guaranteed characteristics, as well as to any claims based on the product liability law.

§ 6 Final provisions

- (1) Alterations and supplements of this contract require the written form for their legal validity.
- (2) Should any individual provisions of this licence terms be void or become void, the validity of the other provisions shall remain unaffected. The void provision must be replaced by a lawful provision that comes as close as possible to the economic purpose it is being used to pursue.
- (3) This terms and the legal relations between the licensor and the licensee are subject to German law exclusively.
- (4) Place of fulfilment and jurisdiction in business transactions with businessmen is D-Reutlingen / Germany.

Installation of the programs

The exact installation instructions for the software are contained in the manual.

Software license for Windows XP

The license number is located on the left or on the right control cabinet.




Fig. 1 Software license for Windows XP on the left control cabinet

Table of contents

1	About this document	12
1.1	Function of this document.....	12
1.2	Target groups of this document	12
1.3	Information in this document.....	13
1.4	Symbols in this document.....	14
1.5	Warnings in the documentation.....	15
2	Description of knitting machine.....	17
2.1	Components of the knitting machine.....	18
2.1.1	Front side (CMS 530, CMS 520, CMS 520 C, CMS 502) *	18
2.1.4	Lateral view (right) *	21
2.1.5	Rear side *	22
2.2	Yarn guide.....	23
2.2.1	Courses of yarn	23
2.2.2	Yarn control unit.....	26
2.2.3	Lateral yarn guide *	27
2.2.4	Thread clamping and cutting device *	29
2.2.5	Intarsia yarn carrier *	30
2.2.6	Plating yarn carriers *	31
2.3	Carriage assembly	32
2.3.1	Drive, speed and operating path.....	32
2.3.2	Suction and cleaning row.....	32
2.3.3	Central lubrication	33
2.4	Knitting system.....	34
2.4.1	Needle paths and design	34
2.4.2	Holding-down function	35
2.4.3	Step motor for adjusting the stitch tension.....	36
2.5	Control devices	37
2.5.1	Impulse sensor	37
2.5.2	Stop resistance	38
2.5.3	Shock stop	38
2.5.4	Needle detector	38
2.6	Needle beds.....	39
2.6.1	Structure	39
2.6.2	Racking device	39
2.7	Fabric take-down.....	41
2.7.1	Main take-down	41
2.7.2	Auxiliary take-down *	42
2.7.3	Comb take-down *	43
2.7.5	Control devices (fabric take-down)	44

2.8	Display and operating elements	45
2.8.1	Main switch	45
2.8.2	Engaging rod	46
2.8.3	Signal light	48
2.8.4	Input unit	49
2.8.5	User Interface	50
3	Producing with the knitting machine	59
3.1	Preparing production and shift changes	59
3.1.1	Loading files, libraries and pattern folders	59
3.1.2	Entering piece number or number of courses	64
3.1.3	Setting touch screen	65
3.2	Threading up yarn	67
3.2.1	Calling up yarn carrier assignment and allocation	67
3.2.2	Putting up bobbins	68
3.2.3	Threading threads through yarn guide bracket	68
3.2.4	Threading threads through yarn control device	69
3.2.5	Thread the yarns through the yarn length measuring device *	69
3.2.6	Threading up threads into friction feed wheel *	70
3.2.7	Thread up the yarn into the permanent brake	71
3.2.8	Threading threads through safety door	72
3.2.9	Threading up yarns into yarn deflector (CMS 520 C, CMS 830 C)	73
3.2.10	Threading up yarns into yarn carrier	74
3.3	Production	75
3.3.1	Starting machine	75
3.3.2	Calling up report and shift counters	78
3.3.3	Stopping machine	85
3.3.4	Switch off machine at the end of work	87
3.3.5	Monitoring the running time	89
3.3.6	Measuring the running time	94
3.4	Producing with knitting orders (order menu)	96
3.4.1	Creating and managing order menu	96
3.4.2	Setting or changing counters for order menu	98
3.4.3	Saving/loading order menu	99
3.5	Eliminating errors in the fabric	101
3.5.1	Starting again after pressing off fabric	101
3.5.2	Threading up thread into yarn carrier	105
3.5.3	Removing fabric winding around fabric take-down	106
3.6	Starting the machine after a fault	107
3.6.1	Message and tip retrospective view	109
3.6.2	Suppressing error messages	111

4	Adjusting knitting machine.....	110
4.1	Basic settings	110
4.1.1	Adjusting carriage speed	111
4.1.2	Setting stitch tension.....	114
4.1.3	Adjusting yarn carriers	118
4.1.4	Staggering yarn carriers	126
4.1.5	Adjusting yarn tension	129
4.1.6	Adjusting yarn delivery on friction feed wheel *	131
4.1.7	Adjusting storage feed wheel MSF 3 *	133
4.1.8	Adjusting knitting areas.....	134
4.1.9	Adjusting take-down	135
4.1.10	Processing fabric take-down menu.....	139
4.1.12	Setting Cycle Counter and Quantity of Fabrics.....	145
4.1.13	Adjusting shape counters	146
4.1.14	Setting counters	148
4.1.15	Switch illumination on and off	148
4.1.16	Setting value for releasing thread clamp	150
4.1.17	Configuration symbol bar	151
4.1.18	Configuring monitoring.....	153
4.1.19	Setting up the pattern	157
4.1.20	Racking correction	165
4.2	Advanced adjustments.....	168
4.2.1	Switching on and off aggregates *	169
4.2.2	Setting language	172
4.2.3	Adjusting sensor mechanism *	174
4.2.4	Setting needle bed parameters.....	176
4.2.5	Setting machine parameters	178
4.2.6	Setting switch-off time when a power failure occurs.....	180
4.2.7	Copying service data	182
4.2.8	Carry out the reference run.....	184
4.2.9	Adjusting racking position correction VPK.....	187
4.2.10	Adjusting basic racking correction VGK.....	189
4.2.11	Correcting position of stitch cams	192
4.2.12	Adjusting needle brushes	194
4.2.14	Adjusting needle detector	200
4.2.15	Adjusting yarn carriers	201
4.2.16	Adjusting yarn carrier limiters	202
4.2.17	Adjusting yarn carrier guide	203
4.2.18	Adjusting the brushes of the central lubrication *	203
4.2.19	Adjusting intarsia yarn carrier (type 1) *	204
4.2.20	Adjusting intarsia yarn carriers (type 2) *	205
4.2.21	Shifting intarsia yarn carriers in area of carriage assembly *	206
4.2.22	Intarsia yarn carrier - Adjust stopping point (basic setting, braking value) *	207
4.2.23	Intarsia yarn carrier - check the pressure plates *	216
4.2.24	Intarsia yarn carrier - Correct stopping point (correction value) *	218
4.2.25	Float slider (holding-down jack control)	219
4.2.26	Normal yarn carrier type 2	222
4.2.27	Plating – the different possibilities.....	224
4.2.28	Plating - Double bow yarn carrier	226
4.2.29	Plating - Plating yarn carrier carriage	228

4.2.30	Changing the position of the knock-over wire	231
4.2.31	Overview of all machine data	233
4.3	Working with files	235
4.3.1	Help on working in the windows	235
4.3.2	File manager	241
4.3.3	Working with files, libraries and folders	245
4.3.4	Displaying file in pattern editor	250
4.3.5	Clear knitting memory	252
4.3.6	Copying files	254
4.3.7	Selecting the current folder	257
4.3.8	Carrying out a program check	260
4.4	Working with the Sintral editor	262
4.4.1	Activating Sintral editor	262
4.4.2	Go to help in function and error list	268
4.5	KnitLAN connection	269
4.6	Defining user profile	272
5	Setup Data	274
5.1	Background	275
5.2	Comparing Setup1 to Setup2	276
5.3	Using Setup1 or Setup2	278
5.4	Loading knitting program	279
5.5	Setup2 Editor	280
5.5.1	Overview of the Setup2 Editor of the CMS	280
5.5.2	Take-down	289
5.5.3	Yarn carrier	293
5.5.4	Stitch lengths	297
5.5.5	Carriage speed	299
5.5.6	Cycle counters	300
5.5.7	Yarn length	301
5.5.8	Racking	306
5.5.9	Miscellaneous	307
5.5.10	Data Mode and File Mode	308
5.6	Setup1 - Editing the setup file	309
6	Maintenance of the knitting machine	313
6.1	Minimize wear	314
6.2	Cleaning the knitting machine	316
6.2.1	Cleaning the touch screen	317
6.2.2	Cleaning suction and lint container *	318
6.2.3	Vacuuming off knitting machine	319
6.2.4	Cleaning needle bed	320
6.2.5	Cleaning thread clamping and cutting device	320
6.2.6	Cleaning the active thread clamp	321
6.2.7	Cleaning the permanent brakes	321
6.2.8	Cleaning the friction feed wheel *	321

6.2.9	Cleaning main drive fan *	322
6.2.10	Cleaning fan and radiators in right control unit	322
6.2.11	Cleaning filter mat of power supply unit	323
6.2.12	Thoroughly cleaning needle bed	323
6.2.13	Clean the knitting systems	325
6.3	Lubricate knitting machine	326
6.3.1	Lubrication interval	327
6.3.2	Setting lubricating interval for needle bed	328
6.3.3	Setting of central lubrication	329
6.3.4	Oil needle bed	333
6.3.5	Restarting lubricating interval	334
6.3.6	Oiling jack bed	334
6.3.7	Oiling yarn carrier rods	335
6.3.8	Oiling the control of the holding-down jacks	335
6.3.9	Oiling carriage guide rail	335
6.3.10	Greasing impulse sensor rails	336
6.3.11	Greasing butts of the coupling parts and intermediate sliders	337
6.3.12	Oiling lifting slide (yarn carrier plunger)	337
6.3.14	Greasing racking device	338
6.3.15	Grease needle bed support/adjustment pieces	339
7	Repairing the knitting machine	349
7.1	Supplementary activities during maintenance	349
7.1.1	Switching power supply 40 V off and on	349
7.1.2	Central lubrication - mounting and working position	351
7.2	Helpful knitting rows	352
7.3	Replacing parts	354
7.3.1	Replacing needle and coupling part	355
7.3.2	Replacing intermediate slider	357
7.3.3	Replacing selection jack	360
7.3.4	Replacing holding-down jack	361
7.3.5	Remove needle bed or position it at an angle	364
7.3.6	Repairing needle bed and additional needle bed	367
7.3.7	Removing selection jack bed (CMS 520 C and CMS 830 C)	371
7.3.8	Removing and mounting carriage part	374
7.3.9	Removing cam plate	382
7.3.10	Removing and mounting step motor	383
7.3.11	Replacing gear racks in the step motor	384
7.3.12	Replacing yarn carrier	388
7.3.13	Mount intarsia yarn carrier *	389
7.3.14	Replacing yarn control unit	391
7.3.15	Replacing drive belts and friction roller of friction feed wheel	391
7.3.16	Deaerating oil line	394
7.3.17	Replacing comb hook	395
7.4	Eliminating faults in electronics system	397
7.4.1	Overview of the electronic control (control cabinet right)	397
7.4.2	Overview of the electronic control (control cabinet right)	400

7.4.3	Overview of the electronic control (control cabinet left and right)	403
7.4.4	Power supply unit	406
7.4.5	Control of yarn carrier magnets	406
7.4.6	Replacing electronic card	407
7.5	Check fuses	408
7.5.1	Checking fuse (right control cabinet)	408
7.5.2	Checking fuse (right control cabinet)	411
7.5.3	Checking fuse (right and left control cabinet)	414
7.6	Needle selection displacement	417
7.6.1	Setting the impulse sensor type.....	418
7.6.2	Preparations	423
7.6.3	Reset reference values of impulse sensor, carry out carriage reference run	424
7.6.4	Determining the needle selection displacement manually	425
7.7	Entering the data of the needle selection displacement manually	428
8	Software - Installation and basic settings	418
8.1	Boot process	419
8.1.1	Basic Settings	423
8.2	Saving all machine data on the USB-Memory-Stick	432
8.3	Saving pattern after a big fault	434
8.4	Installing the Stoll operating system.....	436
8.4.1	Direct installation	437
8.4.2	Indirect installation	443
8.4.3	Updating software	449
8.4.4	Carrying out a restart (Restart)	453
8.4.5	Carrying out restart with machine configuration (Restart and Configuration)	454
8.4.6	Setting online connection.....	456
8.4.7	Overview of all system data	458
8.5	Diagnose Control	460
9	Yarns and stitch tension	462
9.1	Economic production and the influencing factors.....	462
9.2	Stitch Tension Range	464
9.3	Stitch lengths.....	466
9.4	Yarn table.....	469
9.5	Conversion table	472
10	Empty Chapter	473

11	Machine Management Tools	474
11.1	Machine Management Tools window	475
11.2	Display the virtual keyboard	476
11.3	Remote control with the software VNC	477
11.3.1	Activating the remote control VNC on the machine	478
11.3.2	Configuring the remote control VNC on the machine	479
11.3.3	Determine the IP address of the machine	480
11.3.4	Installing software VNC Viewer on the computer (e.g. a note-book)	480
11.3.5	Remote control with the VNC Viewer	481
11.3.6	Remote control via a web browser	483
11.4	Send email directly from the machine	485
12	Key word directory	489

1 About this document

This chapter contains information on:

- Function of this document [☐1]
- Target groups of this document [☐1]
- Information in this document [☐2]
- Symbols in this document [☐3]
- Warnings in the documentation [☐4]

1.1 Function of this document

This document explains how to operate your knitting machine.

This section contains the information about:

- Operation
- Maintenance in normal operation
- Elimination of faults
- Maintenance
- Troubleshooting

1.2 Target groups of this document

The individual chapters of this document are directed at persons with different tasks and qualifications:

Target groups and qualifications	Chapter	
everybody: Knowledge on the applicable safety guidelines at the workplace	1	About this document
	2	Description of knitting machine
User: Knowledge of the basic principles of flat knitting	all the above-mentioned chapters	
	3	Producing with the knitting machine
	4	Adjusting knitting machine
	6	Maintenance of the knitting machine
	7	Repairing the knitting machine
Technician: Knowledge of the current electrotechnical safety guidelines and completed professional training in the field of textile mechanics	All chapters	

Allocation of target groups and chapters

1.3 Information in this document

This document contains all information on assembly, operation, servicing and maintenance of the knitting machine.

Additional information is provided by the following separate documents:

Document	Information contained
Spare Parts Catalog	Illustration of all spare parts with their order numbers
Manual for the STOLL pattern preparation unit	Using the STOLL pattern preparation unit
ASCON instructions STIXX instructions	Special attachments for measuring and controlling stitch length
Stoll-knit report 2 (SKR2)	Software for operational and machine data acquisition
Order Management Software (OMS)	Software for the distribution, control and management of knitting orders

Overview of the documents for the knitting machine and STOLL pattern preparation unit

Additional information is available via:

- the Stoll branch office or Stoll dealer in your country
- the Stoll helpline:
 - Tel: +49-(0)7121-313-450
 - Fax: +49-(0)7121-313-455
- E-mail: helpline@stoll.com
- Internet: <http://www.stoll.com>
- Training courses at the Stoll training centers

Type plate

Some information and descriptions depend on the component and computer type. There may be differences in the design depending on the manufacturing date of the machine. The type plate and the table, which are located on the front page of these operating instructions, indicate which machine model is concerned.



Machine type plate

The second column of numbers in the "Type" field indicates the component type. In the above example the machine in question is the component type "000".

1.4 Symbols in this document

Some information in this document are marked with special symbols to make it easier to access this information quickly.

- ✱ The additional equipment of your machine can deviate from this description depending on the machine type (type of machine, scope of supply, special equipment).



Background information is provided here.



Tips for optimal procedure are provided here.



DANGER

A warning is given here!

A warning protects you from death or injuries and the knitting machine from serious damage.

→ Always read warnings carefully and observe them exactly.

One-step action Carry out an one-step action:

- ✓ Condition for the following action.
- Carry out one-step action.

Multi-step action Carry out a multi-step action:

- ✓ Condition for the following actions.
- 1. Carry out first action.
- 2. Carry out second action.
- ▷ Result of the action carried-out.
- 3. Carry out third action.

- or -

- Carry out the alternative action for point 3.
- ▶ Result of the action sequence.



If something fails to function properly:

Information on the possible causes is provided here.


→ To solve the problem, carry out the action described here.

1.5 Warnings in the documentation

The warnings in the documentation have the following structure:

- **Safety sign**
The safety sign warns about the danger of injury and death. In order to avoid death and injuries, all measures that are indicated along with the safety sign are to be followed.
- **Signal word**
DANGER, WARNING, CAUTION, IMPORTANT
- **Signal color**
depending upon the signal word: red, orange, yellow, blue
- **Text comprises of:**
 - Type and source of danger
 - Possible outcomes
 - Measures for protection against danger and prohibitions

Example:

	DANGER
	<p>Life-threatening high voltage!</p> <p>Electrical shock may cause death or serious injuries.</p> <p>→ Set machine main switch to "0".</p> <p>→ Secure the machine against being switched on again.</p>

Signal word	Explanation
DANGER	Imminent danger of death or serious injuries (irreversible).
WARNING	Death or serious injury (irreversible) possible.
CAUTION	Slight injury (reversible) possible.
IMPORTANT	Damage to property possible.

Explanation to the signal words

2 Description of knitting machine


This chapter contains information on:

- Components of the knitting machine [18]
- Yarn guide [23]
- Carriage assembly [32]
- Knitting system [34]
- Control devices [37]
- Needle beds [39]
- Fabric take-down [41]
- Display and operating elements [45]

2.1 Components of the knitting machine

2.1.1 Front side (CMS 530, CMS 520, CMS 520 C, CMS 502)

*



	Label	Explanation
1	Yarn control unit	Tensions and controls the thread.
2	Bobbin board	The bobbins are placed on it.
3	Carriage	It moves over the needle beds. It controls the work positions of each yarn carrier and each and every needle in the needle bed.
4	Signal light	It displays the operating state of the knitting machine
5	Safety door (left, right)	The reversing position of the carriage is secured by the safety door.
6	Covers	The entire traversing path of the carriage is secured with a safety door. You have to forbid everyone from reaching out into the running machine.
7	Control Unit	It controls the knitting process. It saves the data of the knitting program. It controls the needle selection and the motors in the carriage.
8	Main switch	Switching on and off of the machine. EMERGENCY-STOP switch.

Overview machine elements 1



	Label	Explanation
9	Engaging rod	It activates and stops the carriage run.
10	Fabric take-down (main take-down, auxiliary take-down, comb take-down)	<p>Main take-down: Pulls the stitches away from the needle downwards to the fabric container.</p> <p>Auxiliary take-down: Grasps the fabric directly under the needle bed.</p> <p>Comb take-down: With the comb take-down fabric pieces are automatically started and press off after completion.</p>
11	Fabric collection chamber	The fabric take-down guides the finished fabric into the fabric collection chamber. There the fabric is protected from soiling.
12	Touch screen	The touch screen enables communication with the machine control
13	USB connection	<p>Connection for a removable data carrier, containing knitting programs, operating systems and machine data.</p> <p>Recommendations: Use USB Memory Stick. Also possible: Floppy disk drive, CD drive, DVD drive, external hard disk.</p>

Overview machine elements 2

Components of the knitting machine

Inside




	Label	Explanation
1	Carriage	It moves over the needle beds. It controls the work positions of each yarn carrier and each and every needle in the needle bed.
2	Needle Bed	Every machine has a front and a rear needle bed. There are grooves in the needle bed which are run by needles.
3	Thread clamping and cutting device (left, right)	The thread clamping and cutting device holds the thread of a yarn carrier not used for knitting at the moment.
4	Yarn carrier	It gets pulled by the carriage over the needle bed and leads the thread into the needle.
5	Yarn carrier rail	The bars are attached to the upper part of the needle beds. The yarn carrier glides on this rail.

Overview machine elements 3

Further information:

- Symbols in this document [14]

2.1.4 Lateral view (right) *




	Label	Explanation
1	Yarn control unit	Tensions and controls the thread.
2	Yarn guide device	On this the yarn control units and the friction feed wheels are mounted.
3	Friction feed wheel	It pulls the thread from the bobbin and feeds it to the yarn carrier with a constant tension.
4	Lateral yarn tensioner	It monitors and tensions the thread.
5	Safety door (left, right)	The reversing position of the carriage is secured by the safety door.

Overview machine elements 4

Further information:

- Symbols in this document [14]

2.1.5 Rear side *



	Label	Explanation
1	Carriage	It moves over the needle beds. It controls the work positions of each yarn carrier and each and every needle in the needle bed.
2	Rear needle bed	Every machine has a front and a rear needle bed. There are grooves in the needle bed which are run by needles.
3	Trailing cable (energy chain)	The cables for the carriage that travels hence and forth are fed along with in the energy chain.
4	Transformer (Fuses)	The knitting machine can be operated with various mains voltages.
5	Fluff absorption	The fluff absorption removes the yarn fluff from the upper area of the needle beds.
6	Control Unit (CMS 530, CMS 520, CMS 520 C, CMS 502)	It controls the knitting process. It saves the data of the knitting program. It controls the needle selection and the motors in the carriage.
	Control (right-hand side of the machine) (CMS 830 C, CMS 822, CMS 740)	It controls the carriage run and the racking of the needle bed.
7	Main Drive	The carriage is driven by the drive motor via a toothed belt.
8	Racking device	Racks the rear needle bed laterally.

Overview machine elements 5

Further information:

- Symbols in this document [14]

2.2 Yarn guide

The yarn guide has the following tasks:

- Guiding knitting yarn
 - from the bobbin to the yarn carrier
 - as friction-free as possible
 - without the threads touching or crossing over each other
- Controlling knitting yarn for
 - yarn end
 - Yarn Breakage
 - Knots
- Controlling yarn tension
- Preventing sagging threads with yarn tensioning

2.2.1 Courses of yarn


Various courses of yarn are provided for threading up the yarn on the knitting machine. The optimal course of yarn depends on the yarn and pattern.

Yarn	Course of yarn
Seldom used threads, e.g. elastic yarns	Course of yarn 1
Seldom used threads, e.g. draw threads	Course of yarn 2
Frequently used threads	Simple patterns: Course of yarn 2 Difficult patterns: Course of yarn 3
Difficult-to-process threads	Course of yarn 3
Equally long fabrics	Course of yarn 4

Determining the course of yarn


Yarn guide

The following pictures show the four possible courses of yarn.




Course of yarn 1

- | | |
|----------------------|------------------|
| 1 Bobbin | 4 Safety door |
| 2 Yarn guide bracket | 5 Yarn deflector |
| 3 Yarn control unit | 6 Yarn Carrier |




Course of yarn 2

- | | |
|----------------------|--------------------------|
| 1 Bobbin | 5 Yarn deflector |
| 2 Yarn guide bracket | 6 Yarn Carrier |
| 3 Yarn control unit | 7 Lateral yarn tensioner |
| 4 Safety door | |



Course of yarn 3


- | | |
|----------------------|--------------------------|
| 1 Bobbin | 5 Yarn deflector |
| 2 Yarn guide bracket | 6 Yarn Carrier |
| 3 Yarn control unit | 7 Lateral yarn tensioner |
| 4 Safety door | 8 Friction feed wheel |



Course of yarn 4

- | | |
|----------------------|--|
| 1 Bobbin | 6 Yarn Carrier |
| 2 Yarn guide bracket | 7 Lateral yarn tensioner |
| 3 Yarn control unit | 8 Friction feed wheel |
| 4 Safety door | 9 Yarn length measuring device (ASCN, STIXX) |
| 5 Yarn deflector | |

2.2.2 Yarn control unit



Yarn control unit

- | | |
|---------------------------------|-------------------|
| 1 Thread break control | 4 Yarn brake disc |
| 2 Knot detector for large knots | 5 LED |
| 3 Knot detector for small knots | |

The elements of the yarn control device can individually be adjusted to the yarn being processed.

The yarn break control (1) monitors the yarn ends and switches off the machine in case of a yarn breakage or end. The error is indicated by the LED (5) on the yarn control device, the signal light and on the touch screen.


In the case of large knots in the yarn, the knot detector switches off the knitting machine. The error is indicated by the LED (5) on the yarn control device, the signal light and on the touch screen.

In the case of small knots in the yarn, the machine knits a programmed number of rows at reduced speed.

The yarn brake setting (4) regulates the yarn tension and prevents the thread from hanging through.

2.2.3 Lateral yarn guide *

The friction feed wheel, the permanent brake, the active thread clamp and the lateral yarn tensioner work together.



Lateral yarn guide

- | | |
|-----------------------|--------------------------|
| 1 Friction feed wheel | 3 Active thread clamp |
| 2 Permanent brake | 4 Lateral yarn tensioner |

Further information:


- Symbols in this document [□ 14]

Friction feed wheel * The friction rollers of the friction feed wheel (1) reduce the yarn tension.

Further information:

- Symbols in this document [□ 14]

Storage feed wheel MSF 3 * The feed wheel serves for intermediate storage of the thread. The cylindrical coiling and the separately positioned thread layers offer a more even thread tension when yarn is being drawn off than when drawing off the bobbin. Peaks in tension are caught up and compensated by the feed wheel.



Storage feed wheel MSF 3


According to use up to 6 feed wheels can be inserted on each machine side.

Further information:

- Symbols in this document [□ 14]

Yarn guide

Active thread clamp The active thread clamp is found under the friction feed wheel. It is integrated in the lateral safety door. The thread clamp is positioned in such a manner that each track of the friction feed wheel is arranged corresponding to a track of the thread clamp. In all there are 8 tracks available.



Lateral yarn guide

- 1 Friction feed wheel
- 2 Permanent brake
- 3 Active thread clamp
- 4 Lateral yarn tensioner

In the case of a friction feed wheel sometimes a problem appears: When a thread is not knitted over a longer period of time it is possible that the friction feed wheel releases some threads because of the friction and thereby the lateral yarn tensioner swivels so much outwards that the machine stops. This hinders the thread clamp. If the yarn tensioner swivels over the angle by approx. 45 degree, the clamp closes automatically. If the thread is knitted again the yarn tensioner swivels inwards and the clamp is open.


Lateral yarn tensioner

The lateral yarn tensioner has two tasks:

Function	Description
Control the thread	Switch off the knitting machine in case of a thread break or yarn end.
Tension the thread	When the yarn carrier moves on the yarn tensioner, it can hold the threads that are not yet being knitted in a tensioned state. The yarn tensioner swivels and holds the threads tensioned.

In the case of a yarn breakage the side yarn tensioner swivels outwards and switches off the knitting machine. On the upper end of the yarn tensioner a magnet is fixed that releases a contact in the lateral safety door without touching it.

2.2.4 Thread clamping and cutting device *



Thread clamping and cutting device

- 1 Clamping
- 2 Catch hook

The thread clamping and cutting device is mounted next to the front needle bed. Each one works with 8 or 16 clamps (1). The clamping devices are actuated by the carriage.


The thread clamping and cutting device holds the thread of a yarn carrier not used for knitting at the moment. If the yarn carrier is not needed anymore, it is positioned at its clamping position. The catch hook (2) pulls the thread downward. Then the thread is clamped and cut off. When the yarn carrier is used again, the carriage opens the clamping device after knitting a few rows and the yarn end is released. The number of rows knitted until the clamping device opens up, is programmed in the knitting program.

Further information:

- Symbols in this document [14]


2.2.5 Intarsia yarn carrier *

Intarsia yarn carriers can be installed to produce intarsia patterns.



Pattern with 21 intarsia yarn carriers

Depending on the machine type, the intarsia yarn carrier type 1 or 2 will be inserted.




	Intarsia yarn carrier	Machine
1	Type 1	CMS 830 C CMS 520 C CMS 730 S CMS 830 S
2	Type 2	CMS 933 CMS 822 CMS 740 CMS 730 T CMS 530 T CMS 530 CMS 520

Further information:

- Symbols in this document [14]

2.2.6 Plating yarn carriers *



Plating yarn carrier

- | | | |
|---|----------------------------|----------------------------|
| 1 | Double bow yarn carrier | All gauges except E 3, E 4 |
| 2 | Double eyelet yarn carrier | E 3, E 4 |

It is possible to knit color and quality platings with these yarn carriers.



Colored plating pattern

Further information:

- Plating – the different possibilities [▢224]
- Symbols in this document [▢14]

2.3 Carriage assembly

2.3.1 Drive, speed and operating path



Carriage assembly


The carriage assembly is driven by the drive motor via a toothed belt. The speed is infinitely programmable, and can therefore be adapted to the yarn material, pattern and working step.

Limit switches control the path of the carriage assembly. If the carriage assembly moves too far outward, the limit switch stops the knitting machine.

The operating path of the carriage is controlled by the knitting program and may differ for each knitting or transfer row. The carriage assembly reverses when the last working needle leaves the system.

2.3.2 Suction and cleaning row


Suction *



Fluff absorption and lint container

The suction removes the yarn fluff from the upper area of the needle beds. The fluff is collected in a container.

Cleaning row



Brushes for cleaning the selection systems


After a programmable number of knitting rows, the carriage assembly carries out a cleaning row over the entire needle bed during which the fluff is extracted from the needle bed. Brushes (1) are mounted outside on the needle bed which clean the selection systems during the cleaning row.

Further information:

- Switching on and off aggregates * [169]


2.3.3 Central lubrication

All the machines with four or more knitting systems are equipped with a central lubrication as a standard equipment (not for CMS 822)



Central lubrication on carriage, on the right: Oil supply


It lubricates the working butts of the holding-down jacks, the coupling part and the intermediate slider with oil. All other lubrication points must be lubricated manually.



Lubrication points of the central lubrication

2.4 Knitting system

2.4.1 Needle paths and design



Knitting system

- | | | | |
|---|-------------|---|------------------|
| 1 | Stitch cam | 3 | Selection system |
| 2 | Raising cam | 4 | movable cams |

Each knitting system can knit using the three-way technique without limitation.

Each needle can be controlled in seven positions:

- Stitch
- Tuck
- out of operation
- Transfer
- Take-over
- Split - stitch/transfer
- Split - stitch/receiving

This results in the following possibilities during stitch formation:


- Stitch
- Tuck
- out of operation
- Transfer of stitches and tuck loops from the front to the rear needle bed or vice-versa, even simultaneously in both directions

The selection system only selects the needles which knit a stitch or tuck, transfer or split-stitch. All other needles are not selected and do not sink the stitches.

2.4.2 Holding-down function


The holding-down jacks hold down the fabric when the needles for stitch formation are driven out. The holding down jacks are moved by the holding-down jack control unit on the carriage.

Following stitch formation, the holding-down jacks are opened again (exception: CMS 830 C, the holding-down jacks remain closed).



Holding-down jack control unit

- 1 Holding-down jack control unit
- 2 Swiveling brush holder
- 3 Jack slider



Jack slider

- 4 Leading jack slider
- 5 Following jack slider


The leading jack slider (4) is switched upward.

This pivots the holding-down jacks downward into the holding-down position during needle raising. They hold down the stitches.

The following jack slider (5) is pulled back and the holding-down jacks pivot back again. The holding-down jacks are open during yarn insertion.

When the carriage reverses, the jack sliders are switched over automatically.

2.4.3 Step motor for adjusting the stitch tension



Step motor for adjusting the stitch tension

A step motor (1) on each knitting system adjusts the stitch tension. The step motor is controlled by the knitting program.


The stitch tension can be adjusted individually

- for individual areas in the fabric which are particularly subject to loading, e.g. narrowing edges or pattern motifs
- for individual stitch cams
- for different yarns (yarn count correction)

During knitting, changes can also be made via the touch screen.

2.5 Control devices

2.5.1 Impulse sensor



Impulse sensor

The impulse sensor (1) scans the grooves and trick walls on the impulse sensor rail on the front and rear guide rail for the carriage assembly. It recognizes the position of the carriage assembly and specifies the time for the selection of the selection jacks by the selection systems.

Depending on the machine gauge, there is a front and a rear impulse sensor rail.

Machine gauge	Impulse sensor rail
E 18 (E 9.2) E 16 (E 8.2) E 14 (E 7.2) E 12 (E 6.2) E 10 (E 5.2)	front and rear
E 8 E 7 (E 3,5.2) E 5 (E 2,5.2) E 4 E 3.5 E 3	Back

2.5.2 Stop resistance


If the power consumption of the drive motor differs from a stored value, the knitting machine is stopped. The reason for a higher power consumption may, for example, be a sticky needle.

2.5.3 Shock stop

In the case of a shock on the needle bed, e.g. in the case of needle breakage, the piezo-electric shock stop switches off the knitting machine. The piezo-electric shock stop is located below the needle beds.

2.5.4 Needle detector

The needle detector (1) checks the height of the fabric in the needle area.



Needle detector

If needles are defective (e.g. latch breakage), there is a danger of the fabric not being taken down downward and gathering in the needle area. The machine will then stop automatically to prevent from a major damage.

2.6 Needle beds

2.6.1 Structure

The front needle bed is screwed to the needle bed support tightly. The rear needle bed can laterally be racked relative to the front needle bed by the racking device.




Fig. 27: Needle bed (schematic representation)

- | | |
|-----------------------|-------------------|
| 1 Holding-down jack | 5 Selection jack |
| 2 Needle | 6 Selector spring |
| 3 Coupling part | 7 Needle bar |
| 4 Intermediate slider | 8 Cover rail |

The moveable parts (2) to (6) are fixed by several rails in the needle bed. To replace a part, the corresponding rail must be pulled to the side. This takes place with the help of the extraction hook. It is included in the accessories.

2.6.2 Racking device

The front needle bed is screwed to the needle bed support tightly. The rear needle bed can laterally be racked relative to the front needle bed by the racking device.



Racking motor

The racking motor (1) is located on the right-hand side below the needle bed support. It laterally racks the rear needle bed. It is controlled by the knitting program. The racking movement is infinitely programmable.

Fabric take-down

Racking course The racking course may be up to 4 inches (approx. 10 cm). Depending on the machine gauge, this is a maximum racking course over 12 to 72 needles.

Machine gauge	Maximum racking course
E18 (E9.2)	72 needles
E16 (E8.2)	64 needles
E14 (E7.2)	56 needles
E12 (E6.2)	48 needles
E10 (E5.2)	40 needles
E8	32 needles
E7 (E3,5.2)	28 needles
E5 (E2,5.2)	20 needles
E4	16 needles
E3.5	14 needles
E3	12 needles

Maximum racking course in dependence on the machine gauge

Transfer During transfer the rear needle bed is racked until the needles of the front and rear needle beds almost touch. The needle dips into the pelerine spring of the needle opposite.

OVERRACKING The overracking mechanism pre-stretches the stitches prior to transfer so, that they are somewhat enlarged. Then the needle bed is reset to the programmed racking. As a result, the stitches are also transferred very reliably even at a high carriage speed.

Slow racking To protect the yarn, the needle bed can be racked very slowly. The carriage assembly then waits at the reversing point until the needle bed is racked.

2.7 Fabric take-down

The fabric take-down consists of the three units:

- Main Take-down
- Auxiliary Take-down
- Comb Take-down

- or -

- Belt take-down

Each unit is driven by a separate motor. The motor can individually be adapted to the knitting situation.

2.7.1 Main take-down




Fig. 29: Main take-down (right picture: CMS 502)

- 1 Take-down rollers
- 2 Knurled screws
- 3 Scale

A motor drives the take-down rollers (1). The take-down rollers guide the finished fabric into the fabric collection chamber. There the fabric is protected from soiling.

Take-down tension The take-down tension consists of:

- Pre-tensioning when the carriage assembly is at the reversing point
- Take-down tension during knitting

Both tensions are independently set of each other. The optimum value for the take-down tension is dependent on the working width, yarn material and pattern.

The pressure of the take-down rollers (1) is individually adjusted with the knurled screws (2). The regulation acts on two take-down rollers. A scale (3) simplifies the adjustment of the take-down roller.

On CMS 502:

The pressure of the take-down rollers (1) is individually adjusted with the knurled screws (2). The knurled screws are placed on the left and right machine foot. If you change the adjustment you must take care that both the knurled screws are adjusted by the same value.


Fabric take-down

Premature wear of the take-down roller

The roller rubber of the take-down roller (1) is prematurely worn by:

- Fabric take-down values too high (roller spins)
- Contact pressure too high
- Yarns harmful to rubber, e.g. abrasive, sanding yarns or yarn finishes such as greases or oils
- UV radiation
- Cleaning agents harmful to rubber, e. g. ether or fuels.
Recommendation: Use cleaning petrol for cleaning

2.7.2 Auxiliary take-down *



Auxiliary take-down

- 1 Main take-down
- 2 Auxiliary take-down

The auxiliary take-down grasps the fabric directly under the needle bed.

The auxiliary take-down supports:

- Stitch formation
- Adjustment of the fabric take-down to requirements typical of the fabric
- Narrowing or widening


If the fabric is only taken down with the main take-down, the rollers of the auxiliary take-down are pivoted apart.

The take-down force and the take-down speed are programmable.

Further information:


- Symbols in this document [□ 14]

2.7.3 Comb take-down *



Comb Take-down

With the comb take-down fabric pieces are automatically started and press off after completion.



Comb hooks of comb take-down with sliders (left open, right closed)

When starting a new fabric, a net row is knitted with the elastic thread (comb thread). The main and auxiliary take-down open and the comb take-down moves upward. The sliders open the holding-down recesses on the comb hooks.

The comb thread is automatically laid in the holding-down recesses and the sliders close the holding-down recesses again.

After two stitch rows, the draw thread is inserted and the knitting machine begins with the fully fashioned article. The comb take-down adopts the settings of the main take-down and pulls the fabric off downward.

As soon as the comb hooks are below the main take-down, the take-down rollers close and the fabric is transferred to the fabric take-down. The sliders open the holding-down recesses on the comb hooks. The comb take-down releases the fabric and moves into the home position.




The sliders can open the comb hooks at any point. Therefore, short shape parts, e. g. collars or trimmings, can only be taken down by the comb take-down. They are knitted without the main or auxiliary take-down.

Further information:

- Symbols in this document [14]

2.7.5 Control devices (fabric take-down)

The following parameters are controlled on the fabric take-down:

Parameter	Control
Speed of the take-down roller	The rotating speed of the take-down rollers is constantly measured. If the deviation from the upper or lower limit is too large, the knitting machine stops. The limit values are infinitely programmable.
Speed of take-down belts (2)	The rotating speed of the take-down belts is constantly measured. If the deviation from the upper or lower limit is too large, the knitting machine stops. The limit values are infinitely programmable.
Wrapping around loose threads (1) 	Four yarn deflectors (accessory) prevent loose threads from wrapping around the fabric take-down rollers.
Wrapping around of fabric (1) 	A winding plate prevents the fabric from wrapping around the fabric take-down rollers. If the fabric nevertheless wraps around, the knitting machine stops.
Throwing off of fabric (1) 	Four fabric sensors (accessory) scan the fabric between the needle bed and the fabric take-down. They can be moved as desired over the entire working width. If the fabric is ejected, the knitting machine stops.

Control devices on the fabric take-down

(1) not in case of machines with comb take-down

(2) only in case of machines with belt take-down

Further information:

- Adjusting sensor mechanism * [174]

2.8 Display and operating elements

2.8.1 Main switch



Main switch

The main switch (1) is located on the front of the machine above the right control unit.

In position "1 - On" the main switch is switched on, in position "0 - Off" it is switched off.

Switch-off process


When the main switch is turned from "1" to "0", the machine is immediately switched off. Dangerous movements are immediately stopped. However, the machine data are not lost, as they are saved with a battery. This takes approx. 60 seconds. In the process, messages appear on the touch screen. Once the process has been completed, the touch screen becomes dark and an alarm signal sounds.

Even with the main switch switched off, the mains supply up to the main switch still carries current with extremely high voltage. The mains supply must be disconnected and secured against being switched on again before working on the main switch unit.


Emergency-stop

The main switch is also the emergency-stop switch.

The main switch has to be locked during maintenance and service work. This prevents the main switch from being switched on accidentally.



2.8.2 Engaging rod




Engaging Rod

- 1 Carriage stopped
- 2 reduced speed
- 3 normal speed

The carriage assembly, and therefore also knitting, is started and stopped with the engaging rod. The engaging rod can be moved into three positions.

Smooth and jolt-free start-up
of the carriage

The path of the engaging rod from "0" to the production speed is subdivided in 32 stages. The 32 stages are evaluated using a logarithmic curve.




With the engaging rod half-way pulled-up, 16 percent of the final speed will be reached. The final speed will be reached in the second half of the path with increasing steps.

If the engaging rod is pulled upwards only somewhat, the carriage will start very slowly and without jolting.

- The knitting process can be observed better (stitch forming process, switching of the intarsia yarn carriers, holding-down jack control)
- After a yarn breakage: Tying in the yarns in the needles is easier.

If the engaging rod is pulled upwards fast, the carriage starts immediately.

- Please observe in position 3
1. When the covers are closed, the engaging rod is held by a magnet (production at normal speed).

	DANGER
	Danger by parts of needles which have broken off! Danger of injury to eyes by parts of needles. → Wear safety glasses.

2. When the covers hoods are open (e.g. during set-up and checking work) the engaging rod is not held by a magnet and must be held in position 3 by hand. If the engaging rod is released, it immediately falls into position 1 and stops the machine (dead man's switch in accordance with EN 11 111). The maximum carriage speed with open safety doors can be set.

Further information:

- Setting machine parameters [178]

2.8.3 Signal light




Signal light

The signal light (1) displays the operating status of the knitting machine. Depending on the machine type, the signal light is mounted either on the left or on the right machine side.

Color	Status of the knitting machine
green	Knitting machine is producing
green (flashes)	Knitting machine is stopped with engaging rod
yellow	Knitting machine is not producing, as an error has occurred during knitting
green, yellow	Both lamps light up during the shutdown process. Duration is approximately 60 seconds - from switching off main switch until machine is completely shut down.
off	Main switch is off

Signal light colors

2.8.4 Input unit



Input unit (right: CMS 502)

The input unit (1) enables communication with the machine control:

- Display of operating data
- Calling up help information
- Changing machine settings and pattern data
- Input of commands

The input unit can be moved over the entire width of the needle bed. On the CMS 502 the input unit is mounted tightly (with type 637, type 638: component type 001 or higher).

To carry out a function, tap one of the symbols (keys) on the touch screen. We recommend using the touch pen (2) to prevent the touch screen from becoming dirty or damaged.

2.8.5 User Interface

Design of the user interface



Design of the user interface



Do not touch the touch screen with sharp objects and do not subject it to direct sunlight, which will destroy the picture tubes.

The user interface displays information on the current operating situation. It is always divided into three areas:

- Upper area (1)
 - Menu
 - Input and output of information
- Middle area (2)
 - Status display
 - Additional input elements
 - Selection elements
- Lower area (3)
 - Function keys























- Functions of user interface The following is possible on the touch screen:
- Calling up pages, menus and input masks
 - Calling up help information
 - Displaying the operating data of the knitting machine
 - Accessing the functions of the knitting machine
 - Inputting values for controlling the knitting machine
 - Processing the knitting program
- These functions are called up with the following keys and elements:
- Function keys
 - Input elements
- Function keys In the following sections two groups of functions keys are shown:
- Standard function keys; these are displayed in standard configuration
 - Additional function keys; these can be called up with a switchover key

Display and operating elements

Function keys in the main menu



Function keys in the "Main menu"






















Key	Function	Key	Function
	Load/save data		Comb Take-down
	Editing the knitting program		Fabric Take-down
	Carriage Speed		Same SEN area size
	Racking Correction		Stitch tension
	Set-up Pattern		Yarn Carrier
	Setup2 Editor		Release clamps
	Machine start		Service
	Machine stop		Machine settings
	Changeable monitoring		Order menu
	cycle counters & counters		Sequence knitting (see programming manual)
	Manual interventions		YLC (special attachment with its own instructions)

Function keys in the "Main menu"

Function keys in the main menu (with belt take-down)


















Function keys in the "Main menu"

Key	Function	Key	Function
	Load/save data		Belt take-down
	Editing the knitting program		Same SEN area size
	Carriage Speed		Stitch tension
	Racking Correction		Yarn Carrier
	Set-up Pattern		Release clamps
	Setup2 Editor		Service
	Machine start		Machine settings
	Machine stop		Order menu
	Changeable monitoring		Sequence knitting (see programming manual)
	cycle counters & counters		YLC (special attachment with its own instructions)
	Manual interventions		

Function keys in the "Main menu"

Display and operating elements

Standard function keys




Key	Function
	return to "Main menu"
	Return to previous page
	Proceed to the next page
	Calling up help
	Return to previous help page
	Display list of the last messages and references
	Confirm input
	Call up command line and output window for direct commands
	Order menu: Reset counter of already fabrics to "0"
	Switch over to 100 % of programmed carriage speed
	Switch over to 75 % of programmed carriage speed
	Switch over to status line
	Switch over to selection/input elements
	Confirm message
	Switch over to "additional function keys"

Standard function keys

Additional function keys The additional function keys can be called up from any window with the "Additional function keys" key.

These additional function keys are described in the corresponding chapters.

The following additional function keys are displayed in all windows.

Key	Function
	Call up input window for a direct Sintral command. This is carried out within a menu or window, i.e. you do not need to leave the menu or call up the "Direct command" window.
	Editing the knitting program
	Switch over to standard function keys









Additional function keys in all windows

Input elements In the following sections three groups of input elements are shown:








- Standard input elements; these are displayed when an input field is activated by briefly touching in
- Selection elements; these are displayed when a selection field is activated by briefly touching it
- Virtual keyboard; this can be displayed for inputs

Display and operating elements

Standard input elements









Element	Function
	Reduce value by one step
	Increase value by one step
	Undo a change, the last value saved is displayed again
	Undo a change, the previous value is displayed again
	Confirm input, save changes, end setting process
	Delete character to left of cursor
	Position the cursor at the start of the line
	Position the cursor at the end of the line

Standard input elements

Element	Function
	Only one switch can be active at a time
	Position switch (on/off)
	Check box (on/off)
	Arrow switch (left/right) or (up/down)
	Slider
	Reduce current value by one step
	Increase current value by one step

Switches and linear regulators

Selection elements

Element	Function
	Fold open selection field
	Fold closed selection field
	Move cursor: one line upwards
	Move cursor: one line downwards
	Move cursor: one character to left
	Move cursor: one character to the right
	Move cursor: to first input of selection field
	Move cursor: to last input of selection field






Selection elements

Virtual keyboard To input letters and numbers, the virtual keyboard can be displayed. Either a number block appears for inputting numbers or an alphanumeric keyboard appears for entering letters and numbers.

The virtual keyboard contains three switchover keys:

- SHIFT key
- CPS LCK key
- CTRL key

To use a shift key, e.g. to enter a special character, first press the shift key and then the key with the special character. To return to normal characters, press the switchover key again.

Key	Function
	Switch on virtual keyboard
	Switch off virtual keyboard
	SHIFT key: switch over between uppercase and lowercase letters and between numbers and special characters
	CPS LCK key: switch over between uppercase and lowercase letters; the setting of numbers or special characters is maintained
	CTRL key: switch over to function keys F1 to F10 and keyboard codes (short cuts)

Switchover keys

3 Producing with the knitting machine

This chapter contains information on:

- Preparing production and shift changes [▢59]
- Threading up yarn [▢67]
- Production [▢75]
- Producing with knitting orders (order menu) [▢96]
- Eliminating errors in the fabric [▢101]
- Starting the machine after a fault [▢107]

3.1 Preparing production and shift changes

This chapter contains information on:

- Loading files, libraries and pattern folders [▢59]
- Entering piece number or number of courses [▢64]
- Setting touch screen [▢65]

3.1.1 Loading files, libraries and pattern folders

Files (Sintral, Jacquard, Setup), libraries (Auto-Sintral) and folders can be loaded from the following sources (data carriers):

- Removable data carrier (on the USB socket)
for example: USB-Memory-Stick, floppy disk drive, CD drive, DVD drive, external hard disk
- Hard disk of the computer in the knitting machine
- Online
- Network drive



NOTICE

Computer viruses!


Loss of data or production. Computer viruses can creep into the machine through unscanned data via USB port or network.

→ Bring in only virus free data on to the knitting machine.

Preparing production and shift changes


The socket for the USB-Memory-Stick is located:

- On the left side of the machine above the cover.
- On the right side of the display.



USB-sockets

Always set these settings before loading:



Key	Function
<input checked="" type="checkbox"/> EALL	Delete previous pattern
<input checked="" type="checkbox"/> EAY	Delete all yarn carrier positions
<input checked="" type="checkbox"/> SP1	After the pattern is loaded, the function is automatically executed "Start Program from Line 1". This means that you need not take the "detour" over the window "Machine start" in order to start the knitting program with the "SP from Line 1" key.

i The "Activate EALL" function is only executed when a Sintral file is loaded. Not only the entire previous pattern (Sin, Jac, Set) is deleted from memory, but also the contents of cycle counters, counters and NP values are reset to their home position.

Loading knitting program:


1. From the "Main menu" call up the "Load & Save" window.
2. Set the desired path with one of the "Direct pattern folder selection" keys.
3. Use the PAT/SIN/JAC/SET/LIB keys to select whether the entire pattern of the current machine (PAT) or individual file types are to be listed.
4. Select a file from the file list by tapping it.
5. Tap the "Load" key.
6. For the following prompt, press the "1" button to confirm,
- or -
→ tap the "0" key to cancel.
7. Call up "Main menu".




If the "Sintral Editor" window appears, the loaded knitting program contains an error. Correct this error before you start the production.

Setup1 or Setup2


You can quickly recognize whether it is a pattern with Setup1 or Setup2 data









- 1 Setup1 pattern
- 2  Setup2 pattern

A Setup2 pattern is saved in a zip file. The icon of compressed (zipped) folder is displayed in front of the pattern.


Load data (Setup2)






Key	Function
	Call up the "Load & save" window
	Load pattern
	Load the pattern with selected Setup data
	Display the content of the Zip file
	Close the zip file
	Call up "Main menu"

Keys for loading a knitting program

Load data (Setup1)




"Load & save" window

Key	Function
	Call up the "Load & save" window
	Load pattern
	Call up "Main menu"

Keys for loading a knitting program

"Invalid character" error message (Setup1, Setup2)

Check the knitting program for special or foreign language characters. Only the characters of the ASCII character set may be used.





ASCII character set

Further information:

- Selecting the current folder [▢257]
- Working with files, libraries and folders [▢245]
- Go to help in function and error list [▢268]
- Overview of the Setup2 Editor of the CMS [▢280]
- KnitLAN connection [▢269]


3.1.2 Entering piece number or number of courses

Key	Function
	Call up the "Cycle counters & counters" window
	Call up "Main menu"

Keys for entering the piece number or number of courses

Entering piece number or number of courses:

1. Call up the "Cycle counters & counters " window from the "Main menu".



"Cycle counters & counters" window

2. If you produce pieces, enter the "piece number".





- or -

- If you produce yard goods, set the maximum number of courses with the "MT" counter to define the length of the fabric.

3. Call up "Main menu".


3.1.3 Setting touch screen

Calibrating touch screen The calibration is particularly important when persons of different heights work at the same machine. In the case of different viewing angles, the position of the keys may change. So that you always press the proper keys, calibrate the touch screen at the beginning of your shift.


Key	Function
	Call up the "Service" menu
	Call up the "Set touch screen" window.
	"Calibrate" key
	Call up "Main menu"

Keys for calibrating the touch screen

Calibrating touch screen:

	NOTICE
	<p>Incorrect adjustment of the touch screen!</p> <p>Permanent incorrect adjustment: If you set the touch screen incorrectly, the keys on the screen are no longer accessible. The program can only be readjusted with a keyboard (Stoll helpline).</p> <p>→ During calibration, touch the touch screen within the target circles only!</p>


1. Call up the "Service" menu from the "Main menu".
2. Call up the "Set the touch screen" window from the "Service" menu.
 - ▷ The "Set touch screen" window appears.



"Set touch screen" window

3. Tap the "Calibrate" key.

- ▷ The setting window appears. A target circle is located on the upper, left side.



Setting window with target circle

4. Tap exactly on the target circle.

- ▷ A second target circle appears on the lower right-hand side.

5. Tap exactly on the target circle.

- ▷ A third target circle appears on the upper, right-hand side.

6. Tap exactly on the target circle.


- ▷ A message box appears. The request in the message box is not important, as there is no mouse cursor here.

7. Press on the "Yes" key.

8. Call up "Main menu".

Setting screen brightness

Two key buttons for brightness setting are located on the rear of the input unit.



Setting screen brightness

The screen display is made brighter with key button (1) and darker with key button (2).






3.2 Threading up yarn

Various courses of yarn are provided for threading up the yarn on the knitting machine. The optimal course of yarn depends on the yarn and pattern.

Further information:

- Courses of yarn [23]

3.2.1 Calling up yarn carrier assignment and allocation

Key	Function
	Call up "Machine start" window
	Call up "Main menu"
	Call up the "Yarn carrier" window
	Call up "Additional function keys"
	Call up "Allocation yarn carrier" window

Keys for calling up the assignment and allocation of the yarn carriers

Calling up the assignment and allocation of the yarn carriers:


1. Call up the window "Machine start" from the "Main menu".



"Machine start" window


2. Type "SP from line 1" key.
 - ▷ The computer searches in the knitting program to see which yarn carriers are required.
3. Call up "Main menu".

4. Call up the "Yarn carrier" window.



Yarn carrier allocation in the "Yarn carrier" window

5. On tandem machines also call up the allocation of the yarn carriers to both carriage assembly.
6. Call up "Additional function keys".
7. Call up the "Allocation yarn carrier" window.



"Allocation yarn carrier" window

8. Call up "Main menu".

3.2.2 Putting up bobbins

When the threads of several bobbins are led to one yarn carrier, supply approximately the same number of threads to the yarn carrier from each side.

→ Put up the bobbins on the knitting machine or on the additional bobbin board.

3.2.3 Threading threads through yarn guide bracket

1. Push the yarn guide brackets to the side so that a yarn guide bracket hangs over each bobbin.
2. Thread each thread through a yarn guide bracket.

3.2.4 Threading threads through yarn control device





Fig. 51: Path of the thread through the yarn control device

1. Bring thread break control in work position.
Pull thread break control a little towards left till it is not held by the stopping cam anymore.
2. Thread each thread through a yarn control device as shown in the picture.

3.2.5 Thread the yarns through the yarn length measuring device *







Path of the thread through the yarn length measuring device

- Push thread upward with both hands through the threading gap and lay it around the measuring wheel.

Further information:

- Symbols in this document [14]

3.2.6 Threading up threads into friction feed wheel *

	Course of yarn	
1	 <p>Standard setting</p>	 <p>Insufficient yarn delivery</p>
2	 <p>Standard setting</p>	 <p>Greater yarn delivery (grey) Insufficient yarn delivery (black)</p>

Further information:

- Adjusting yarn delivery on friction feed wheel * [131]


3.2.7 Thread up the yarn into the permanent brake

The permanent brake (1) will be used together with the friction feed wheel.



Thread-up into the permanent brake only the yarn that is processed with the friction feed wheel.

Make sure that you thread-up the yarn vertically downwards.




Path of the yarn through the permanent brake



With the thread also running over the friction feed wheel, threading-up is easier if you activate the friction feed wheel shortly (60 seconds). For this purpose activate shortly the corresponding feed wheel ("Manual interventions" window), see [105].

1. Guide the yarn downwards behind the brake discs.
 2. Insert the yarn between the two brake discs.
 3. Pull the yarn somewhat towards the machine center to open the brake discs.
 4. Release the yarn tension again.
- ▶ The brake discs close and the yarn glides into the open eyelet.
 - Threading up thread into yarn carrier [105]

3.2.8 Threading threads through safety door



Make sure that you thread-up the thread vertically through the lateral safety door.

1. Bring the Lateral yarn tensioner in still position (1) (anchoring). Thereby the active thread clamp is open.




With the thread also running over the friction feed wheel, threading-up is easier if you activate the friction feed wheel shortly (60 seconds). For this purpose activate shortly the corresponding feed wheel ("Manual interventions" window), see [▢105].

2. Thread the thread through one of the eyelets (2) on the lateral safety door. Use Eyelet number 3 to 10 when the thread is coming from the friction feed wheel. So the clamp positions of the active thread clamp are positioned exactly under it.
Use Eyelet number 1 and 2 or from eyelet no.11: for the thread if you working without the feed wheel.
 3. Thread the thread vertically downwards in the eyelet (3) of the lateral yarn tensioner. For quicker orientation a vertically running riffle is attached in the safety door.
 4. Feed the thread through the yarn deflector (4) to the yarn carrier.
 5. Bring lateral yarn tensioner in work position (5).
- Threading up thread into yarn carrier [▢105]

3.2.9 Threading up yarns into yarn deflector (CMS 520 C, CMS 830 C)

Lead the yarns through the yarn deflector (1) to the yarn carrier.



The height of the yarn deflector is adjustable.

Attention: If the yarn deflector is set too deep, then it may collide with the suction tube of the fluff absorption.

The yarn deflector can be assembled in two positions:





- Opening of the eyelets downwards (standard setting) – easier threading-up
- Opening of the eyelets upwards – for this, loosen the screws (2), and turn the front and rear yarn deflectors upwards. Retighten the screws.



With the thread also running over the friction feed wheel, threading-up is easier if you activate the friction feed wheel shortly (60 seconds). For this purpose activate shortly the corresponding feed wheel ("Manual interventions" window), see [105].

- Threading up thread into yarn carrier [105]

3.2.10 Threading up yarns into yarn carrier

<p>Thread-up the threads into the respective next eyelet on the yarn carrier.</p>	
<p>If several yarn carriers of one track are used and the threads are led to the yarn carriers from the same side.</p>	
<p>If several bobbins are used for one yarn carrier.</p> <ul style="list-style-type: none"> ◆ Threading-up yarns from left and right. ◆ Make sure that almost the same number of threads are used from left and right. 	
<p>CMS 520 C, CMS 830 C The yarn carrier has two additional eyelets. Up to 5 thin yarns can be threaded into each eyelet.</p>	



With the thread also running over the friction feed wheel, threading-up is easier if you activate the friction feed wheel shortly (60 seconds). For this purpose activate shortly the corresponding feed wheel ("Manual interventions" window), see [105].




- Threading up thread into yarn carrier [105]

3.3 Production

This chapter contains information on:

- Starting machine [▢75]
- Calling up report and shift counters [▢78]
- Stopping machine [▢85]
- Switch off machine at the end of work [▢87]
- Monitoring the running time [▢89]
- Measuring the running time [▢94]


3.3.1 Starting machine

Key	Function
	Call up "Machine start" window
	Call up "Additional function keys"
	Call up the "Changeable monitoring" menu

Keys for starting the machine

✓ A pattern is loaded.


1. Call up the window "Machine start" from the "Main menu".



"Machine start" window

2. In "Start" field, tap on "SP from line 1" key.
3. Call up "Additional function keys".
4. Call up the "Changeable monitoring" window.
 - ▷ Machine data and the program sequence are displayed in the "Changeable Monitoring" window during production.

5. Start the machine with the engaging rod.



Engaging rod

- 1 Carriage stopped
- 2 reduced speed
- 3 normal speed

Pattern changes - Apply shape counters



Use this function only for the following machines:

- Machine without comb take-down
- Machine with comb take-down but without use of comb

The machine compares automatically the shape counters (old-new) in order to be able to adjust the new knitting width (widening or narrowing) with the pattern change. The values of the shape counters of the previous pattern are necessary for this.






You can enter the values of the previous pattern manually or simply apply them by the "Apply shape counter" key.

The condition is that the pattern was created as Fully Fashion knitting program on the M1plus.



Also with a basic pattern (pattern without shape) you can use this helpful function (see the tip at the end of the section).

Key	Function
	Call up "Machine start" window
	Call up "Additional function keys"
	"Apply shape counter" key

Keys to apply the shape counters

Apply shape counter:

1. Call up the window "Machine start" from the "Main menu".
2. Tap on "Additional function keys".
3. Tap the "Apply shape counter" key.
Confirm the prompt that follows with "YES".
 - ▷ The values of the shape counter are applied to the new pattern.
4. Tap the "SP from line 1" key.

Converting a basic pattern into a shaped pattern



A small trick - with an impressive effect

Using a small trick you can easily convert a basic pattern into a fully fashion pattern on the M1plus.

Converting a basic pattern into a shaped pattern:

- Open the basic pattern on the M1plus.
(The technical processing has not yet been done.)
- Select the "Generate Pure Shape" function in the "Shape" menu.
-> An empty, rectangular shape with the size of the pattern will be opened.
- Carry out technical processing
- ▶ The basic pattern is automatically converted into a fully fashion pattern, the corresponding specifications are entered into the knitting program (PF0, "ff-trans" function, this function contains the casting-off and widening until the new knitting width).

Further information:

- Configuring monitoring [153]

3.3.2 Calling up report and shift counters

The control collects all operating data recorded since the operating system was first read in and since the current knitting program was started. These data help you optimize the performance and loading of the knitting machine.

Report The individual types of operating data (1) are listed on the left side. The left-hand table (2) shows the continuing listing of all data accrued after loading the operating system. The data of this table cannot be deleted. The data of the right table (3) can be deleted with the "Report0" key.






The production data can be listed during a certain period of time. This may consist of part of a shift, day or week.

1		F	%	H	M	Report0					
SIN		0		37	18					37	18
RUN *		0	100.00	37	18		100.00			37	18
V=V		0	0.00	0	0	0	0.00			0	0
/-\		0	0.00	0	0	0	0.00			0	0
000		0	0.00	0	0	0	0.00			0	0
>!		0	0.00	0	0	0	0.00			0	0
-/)		0	0.00	0	0	0	0.00			0	0
%		0	0.00	0	0	0	0.00			0	0
PR		0	0.00	0	0	0	0.00			0	0
MS~		0	0.00	0	0	0	0.00			0	0
->/		0	0.00	0	0	0	0.00			0	0
V[]		0	0.00	0	0	0	0.00			0	0
#<>					0						0
#ML					0						0
ST					0						0

"Report" window

Label	Data shown
"F"	No. of errors or no. of stop motions
"%", "H", "M"	Percent, hours, minutes
"SIN"	Working time of the control unit (SINTRAL)
"RUN"	Production period
"V=V"	Stop by stopping at the engaging rod
"/-\"	Stop by yarn control device, yarn feed
"000"	Stop by piece counter
">!"	Stop by stop resistance
"-/) "	Stop by position needle sensor
"%"	Stop by fabric take-down
"PR"	Stop by programming
"MS~"	Machine stop (further causes of the stoppage)
"->/"	Stop by shock stop motion
"V[]"	Stop by racking error
"#<>"	Total number of strokes
"#ML"	Number of strokes at reduced speed
"ST"	Number of produced fabric pieces

Data in "Report" window

Key	Function
	Call up the "Service" menu
	Call up "Statistics" menu
	Call up "Report" window
	Save report
	Call up "Main menu"

Keys for calling up the report

Calling up or saving report:

1. Call up the "Service" menu from the "Main menu".
2. Call up "Statistics" menu.
3. Call up the "Report" window.
4. To delete the operating data in the report, tap the "Report0" key.

- or -

→ To save the operating data, tap the "Save Report" key.


- ▷ The data will be saved on the selected data carrier. It will be saved on the data carrier that is set in the "Copy service data" window.
File name: STOLL machine number and the file name extension ".rep"
(e. g. "5320081234.rep").

5. Call up "Main menu".

Further information:

- Copying service data [182]

Shift counter A total of five shift counters are available. A complete report is generated for each shift. The table has the same structure as the report. Column "F" shows the number of stop motions during the shift.



"Shift counter" window

Key	Function
	Call up the "Service" menu
	Call up "Statistics" menu
	Call up "Shift counter" window
	Call up "Main menu"

Keys for calling up the shift counter

Calling up or saving shift counter:

1. Call up the "Service" menu from the "Main menu".
 2. Call up "Statistics" menu.
 3. Call up "Shift counter" window.
 4. To activate a shift, tap the corresponding key in the "Shift On" field.
 5. If data of an earlier shift are displayed, tap the corresponding key in the "Delete shift" field (reset shift counter).
- or -
- To delete all shift counters at once, tap the key (1).
 6. To save the shift data, tap the key (2).


- ▷ The data will be saved on the selected data carrier. It will be saved on the data carrier that is set in the "Copy service data" window.
File name: STOLL machine number, date, time and the file name extension ".sft" (e. g. "56600101234_31_10_08_1105.sft").

7. Call up "Main menu".

Further information:

- Copying service data [182]

Automatic shift changeover Once the start time and the ending time of each shift have been entered, the shift changeover automatically occurs after the entered time.



Key	Function
	Call up the "Service" menu
	Call up "Statistics" menu
	Call up "Shift counter" window
	Call up "Additional function keys"
	Call up the "Automatic shift change" window
	Confirm entries
	Call up "Main menu"

Keys for setting the automatic shift change

Setting the automatic shift change:

1. Call up the "Service" menu from the "Main menu".
2. Call up "Statistics" menu.
3. Call up "Shift counter" window.
4. Call up "Additional function keys".
5. Call up the "Automatic shift change" window.

6. Turn off the switch (1) so that no checking is carried out during the input and no error messages are displayed.
7. Set the time.
Tap on the corresponding field and set the desired time using the slider.
8. Activate the checkbox of the desired shift.
9. Set the time for all the shifts; to do so repeat the steps 7 to 8.
10. Confirm entries.
11. Turn on the switch (1).
▷ The entries are automatically checked.
12. Call up "Main menu".



→ The shift times may not overlap.

→ The total time is to be 24 hours.

If the actual working time is less than 24 hours, then an additional shift that covers the remaining time is to be determined.





→ Set the time and the time zone on the knitting machine if necessary, see page [425].

- Configure machine [425]
- Configure machine [425]

3.3.3 Stopping machine

The knitting machine can be stopped in the following ways:


- Disengage the engaging rod
- Actuate the stop motion device, e.g. open a cover
- Stop the machine in the "Machine stop" window

Key	Function
	Call up "Main menu"
	Call up "Machine stop" window
	Reset conditions to standard values (Reset).
	End setting process and save changes

Keys for stopping the knitting machine

Stop the knitting machine in the "Machine stop" window:

1. Call up "Machine stop" window from "Main menu".



"Machine stop" window

2. If the knitting machine is to stop at the next reversing point of the carriage assembly, tap the key "Machine stop".

3. If the knitting machine is to stop when a certain condition is fulfilled, select a condition in the field "Conditional stop".

Stop in minutes	Remaining running time in minutes
Stop in Sintral line	When the set Sintral line is reached
Stop in Jacquard line	When the set jacquard line is reached
Stop with #/RS	When the counter or cycle counter has reached the set value
Stop at fabric end	When the fabric is knitted completely

4. Enter corresponding value for the condition. Confirm setting.




When a conditional stop is activated, a stop icon is displayed in the status line.

3.3.4 Switch off machine at the end of work



Do not switch-off machine at the main switch, but via the "Machine Stop" window.

Reason: The computer will be shut down by current of the battery pack when switching off the main switch.



"Machine stop" window

Switch in "Switch off machine" field	Machine switches off automatically
"If stopped"	Each time machine stops
"When piece counter = 0"	After completing the set number of pieces
"If fabric complete"	after completing the current fabric
"If stopped: Waiting time"	If the machine has stopped, then the main switch is automatically switched off at the end of the set time (in hours).

Configuration of the automatic switching off in the "Machine stop" window

Key	Function
	Call up "Machine stop" window
	Confirm entries
	Call up "Main menu"

Keys for configuring the automatic machine switching off

Configuring automatic machine switching off:

1. Call up "Machine stop" window from "Main menu".
2. In the "Switch off machine" field activate the desired check box.
3. Confirm entries.

▶ When the machine switches off, the main switch moves from "1" to "0".

While switching off the main switch, the fabric remains tensioned in the fabric take-down. This can lead to a visible stretching on a delicate fabric. To prevent this, the fabric take-down can be released.

Further information:

- Setting machine parameters [□178]

3.3.5 Monitoring the running time



In order to display the "Running time control" window it must be activated in the "Knit report configuration" window. (BootOkc -> Restart and Configuration -> Knit report configuration -> Additional function keys)

The running times of sequence lists, sequences or orders, their individual elements or individual patterns are recorded and displayed in the "Running time control" window.

This adds extensive knitting process data to the commands **MIN**, **MINSEQ** and **MINSEQEL**:

- Display of the running time of a pattern (sequence, sequence element, order).
The current, last, minimum, maximum and average running times are displayed respectively.
- Display of the expected remaining running time of a pattern (sequence, sequence element, order).
- Display of the number of pieces that have been knitted and are still to be knitted.
- Display of running time with or without loading and standby times.

Key	Function
	Call up the "Service" window
	Call up "Statistics" window
	Call up the "Running time control" window
	Call up the "Running time data sequence" window or the "Running time data pattern" window
	Call up the "Catalog running time data" window
	Returning to the previous window
	Call up the "Main menu"


Keys for the "Running time control" window

Production

Open the "Running time control" window

1. Call up the "Service" window in the "Main menu".
2. Call up the "Running time control" window in the "Service" window.

The "Running time control" window can alternatively be called up by using the additional functions keys in the "Sequence menu" or "Sequence list" window.




"Running time control" window







Field/Key	Meaning	
1	Total running time	Display of the estimated total running time
2	gross	Display of the total production time including loading and standing times as well as manual interventions.
	Net	Display of the pure machine running time from SP (Start Program) to piece finished .
3/4	No.	Current number
	Sequence/Sequence element name	Name of the pattern or the sequence
	current	Previous running time
	last	Running time of last knitted panel
	min.	Minimum running time.
	max.	Maximum running time
	Ø	Average running time
	Fbcs	Number of pieces knitted
Total	Total number of pieces to be knitted.	

Meaning of the elements in the "Running time control" window.

Functional description for the "Catalog running time data" window



"Catalog running time data" window

Key	Meaning
	"Load" selected file and corresponding data
	"Save" selected file in the current folder
	"Delete file" that was selected
	delete all files
	"Update": Re-determine the contents of the current folder
	"Select current folder": Dialog box for selecting the current storage folder
Data older than 6 weeks	Delete (activated by default) The data are deleted automatically when they get older than 6 weeks. This saves storage space. Keep: The files are not deleted.

Keys in the "Catalog running time data" window

1. Call up the "Service" window in the "Main menu".
2. Call up the "Running time control" window in the "Service" window.
3. Call up "Additional function keys".
4. Call up the "Catalog running time data" window.

5. Select the desired path with the "Current folder selection" key.
6. Select file.
7. Select action (load, save, delete).
8. If an additional prompt appears, tap the "1" key to confirm.

- or -

➔ Press the key "0" to cancel.

Display of the remaining running time

Display of the expected remaining running time (net) of a pattern (sequence, sequence element, order).

Depending on the file you selected in the "Running time control" window, the title of the window changes.

- For a sequence, the title is "Running time data sequence".
- For a single pattern or a sequence element, the title is "Running time data pattern".

"Running time data sequence" ("Running time data pattern") window

Entry	Meaning
Name	Name of sequence, sequence element or pattern
Remaining running time	Display of the remaining running time (average net remaining running time x fabrics which are still to be knitted = remaining running time). Format: Minutes, seconds
End time	Display of the end time. Format: Date, time Possible only after a run-through
Running time piece	The shortest and the longest running times are displayed to facilitate the evaluation of the expected remaining running time.

Data in the "Running time data sequence" window or in the "Running time data pattern" window

1. Call up the "Service" window in the "Main menu".
2. Call up the "Running time control" window in the "Service" window.
3. Select sequence, sequence element or pattern.
4. Call up "Additional function keys".

5. Call up the "Running time data sequence" window or the "Running time data pattern" window
 - ▶ The "Running time data sequence" or the "Running time data pattern" window is displayed with the associated data.
6. Close the window by using the "Return to previous window" key.

Further information:

- Carrying out restart with machine configuration (Restart and Configuration) [454]

3.3.6 Measuring the running time



In order to display the "Running time control" window it must be activated in the "Knit report configuration" window. (BootOkc -> Restart and Configuration -> Knit report configuration -> Additional function keys)

Manual measurements of running time can be carried out (stop watch function) in the "Measurements of running time" window. The functions start, stop and backup are deleted with the additional function keys.



"Measurement of running time" window

Key	Function
	Call up the "Service" window
	Call up "Statistics" window
	Call up "Measurement of running time" window
	Start measurement of running time (start)
	Stop measurement of running time (Stop)
	Set display at 0 (Reset)
	Call up the "Main menu"

Keys for the "Measurement of running time" window

Stopping the running time:

- ✓ A pattern file has to be loaded (1).
- 1. If necessary set display with "Reset" at 0.
- 2. Tap on "Start".
 - ▷ In the "Running time" (2) field time that has passed since "Start" was activated is shown in the format hh:mm.ss.
- 3. Starting the knitting process.
- 4. After the knitting process has been completed, tap "Stop".
 - ▶ The stopped time is displayed in the "Running time" (2) field.

Further information:

- Carrying out restart with machine configuration (Restart and Configuration) [☐454]

3.4 Producing with knitting orders (order menu)


This chapter contains information on:

- Creating and managing order menu [▢96]
- Setting or changing counters for order menu [▢98]
- Saving/loading order menu [▢99]

3.4.1 Creating and managing order menu

Using the order menu, the various making-up sizes of an item (knitting program) in a list are gather together and processed one after another. The number of pieces and cycle counters are specified for each making-up size.









A knitting order (line) is processed until the number of fabrics in the "ST1" and "ST2" columns are the same. The machine automatically switches over to the next size and produces the set piece number. Knitting is carried out line by line from top to bottom.



"Order menu" window

Column	Data shown
1	Current order number
2	Name of the order
3 ("ST1")	Number of pieces to be produced
4 ("ST2")	Piece number already produced
5 to 11	Cycle counters and counters
12 ("#51")	left border
13 ("#52")	right border

Data in the "Order menu" window

Key	Function
	Call up the "Order menu" window
	Confirm entries
	Call up "Additional function keys"
	Reset values in column "ST2" (counter for the previously produced pieces) to "0".
	delete all information in the order menu
	"Copy line" contents
	"Insert line" contents
	"Activate knitting order"

Keys for processing the "Order menu"

Processing the order menu:

1. Call up the "Order menu" window from the "Main menu".
 2. Touch the line to be edited.
 - ▷ The line appears at the bottom edge of the window.
 3. Tap the fields of the selected line and enter the desired values and name.
- or -
- ➔ Call up "Additional function keys", copy contents of a line and insert it at desired location again.
 - ▶ If the order is active, "ORDER" appears in the status line.





Status line with active knitting order



Missing pieces of an order can be knitted afterward by changing "ST2". When the last order is carried out, a check is performed to determine whether any parts are still to be knitted. The machine will not be stopped until all orders have been completed.

3.4.2 Setting or changing counters for order menu

In the Sintral program, the knitting of different pieces or sizes can be controlled from a program via counters.

Key	Function
	Call up the "Order menu" window
	End setting process and save changes


Keys for setting the counters

Use another cycle counter or counter:



Do not use the counters "#1" to "#39", as they are set to "0" during start-up!

1. Call up the "Order menu" window from the "Main menu".
 - ▷ The "Order menu" window appears.
2. Tap the desired column (cycle counter or counter) in the header of the table.
 - ▷ The setting window appears.



Setting window for changing cycle counters and counters




3. Assign a cycle counter or a counter.
4. Confirm entries.
5. The "Order menu" appears again.



The values of the cycle counters and counters are copied from the machine at the beginning of an order. If they are modified during knitting, they will take effect starting with the next piece.

3.4.3 Saving/loading order menu


The information in the order menu can be saved, loaded and deleted in the "Catalog order data" window.

Key	Function
	Call up the "Order menu" window
	Call up "Additional function keys"
	Call up the "Catalog order data" window

Keys for the "Catalog order data" window

Functional description for working in the "Catalog order data":


1. Call up the "Order menu" window from the "Main menu".
2. Call up "Additional function keys".
3. Call up the "Catalog order data" window.



"Catalog order data" window

4. Set the desired path with one of the "Direct pattern folder selection" keys.
5. Select file.
6. Select action.
7. If an additional prompt appears, tap the "1" key to confirm,
 - or -
 → tap the "0" key to cancel.
8. Call up "Main menu".

Actions in "Catalog order data" window



"Catalog order data" window

Key	Function
	"Direct folder selection": predefined folder selection
	"Load" selected file and corresponding pattern elements
	"Save" selected pattern elements in the current folder
	"Delete selected file"
	"Display file" which is selected
	"Update": Update the contents of the folder
	Call up "Direct Help" for the key pressed next




Keys in "Catalog order data" window

Further information:

- Selecting the current folder [▢257]
- Displaying file in pattern editor [▢250]

3.5 Eliminating errors in the fabric

If the fabric piece is not to be completed properly, two options in the "Machine start" window can be used.



Key	Function
	Call up "Additional function keys"
	The cycle currently being knitted is canceled and the other cycles will be knitted as programmed.
	The machine automatically begins with a new fabric if the following conditions are met: The racking device is in the home position The yarn carriers are in starting position The carriage direction allows beginning again. As long as these conditions are not met, cycles will only be knitted once.

Keys to interrupt a fabric

This chapter contains information on:

- Starting again after pressing off fabric [▢101]
- Threading up thread into yarn carrier [▢105]
- Removing fabric winding around fabric take-down [▢106]

3.5.1 Starting again after pressing off fabric

Key	Function
	Call up "Machine start" window
	Confirm entries

Keys for starting again after pressing off fabric

Eliminating errors in the fabric

For machines without a comb take-down


After pressing off fabric, a problem arises where stitches are pressed off and therefore further knitting is not possible. To be able to continue, we recommend calling up the "Picking-up after pressing-off" function. It allows you to begin knitting even without fabric.

Normally, each knitting program includes the "Picking-up after pressing-off" function. With older knitting programs, this function is found from line 950 on; with the pattern workstation M1, it is activated via "#90".

The machine detects which pattern workstation was used to generate the pattern. A knitting program of M1 contains the ID "<M1>" on line 1. Likewise, program point "P.aft. press-off" in the "Machine start" window is adapted automatically.

"Picking-up after pressing-off" function with older knitting programs (e.g. SIRIX)

1. If threads are broken, thread them up again.
2. Call up "Machine start" window.
3. Call up the "Picking-up after pressing-off" function. Tap the "P.aft. press-off from line" key for this purpose.



"Machine start" window

4. Start the machine with the engaging rod.


	NOTICE
<p>If you notice defective needles while picking-up after pressing-off:</p> <p>→ Stop picking-up after pressing-off and replace the defective needles.</p>	

5. When the fabric is long enough to be placed in the main take-down, or the belt take-down, stop the machine with the engaging rod.
6. Open the main take-down or the belt take-down, place the fabric in the main take-down or the belt take-down and close the take-down.
7. To start the knitting program, tap the "SP from line 1" key.
8. Start the machine with the engaging rod.

"Picking-up after pressing-off" function with an M1 pattern

Requirements:

- The knitting program was generated on M1
- When the pattern is generated, the "P.aft. press-off" menu item is activated



"Machine start" window

Setting	Function
#90=0	"Picking-up after pressing-off" function is deactivated
#90=1	"Picking-up after pressing-off" function is activated. A specific row number (gauge x 4) is knitted, depending on the gauge of the machine. A total of 40 knitting rows are processed for a machine of gauge E10.
#90=n	If this is too many knitting rows, "#90" can be set to another number. Two knitting rows, similar to the "Picking-up after pressing-off" function, are repeated as often as "#90" is set. Example: #90=15. A total of 30 knitting rows (2 x 15) are processed.
#L, #R	Setting the fabric width for the "Picking-up after pressing-off" function. Standard setting: Starting width (#L=#51, #R=#52)

1. If threads are broken, thread them up again.
2. Call up "Machine start" window.
3. Call up the "Picking-up after pressing-off" function. Tap the "P.aft. press-off M1 from line" key for this purpose.
4. Tap on the input fields. Enter values and confirm inputs.
5. Start the machine with the engaging rod.

	NOTICE
<p>If you notice defective needles while picking-up after pressing-off:</p> <p>→ Stop picking-up after pressing-off and replace the defective needles.</p>	



Eliminating errors in the fabric

6. When the set number of knitting rows has been processed, the machine stops automatically.
 - ▷ The "Place fabric in fabric take-down" message appears.
7. When the fabric is long enough to be placed in the main take-down or the belt take-down, open the take-down, place the fabric in the take-down and close the take-down.
8. If the fabric cannot be placed in the main take-down or the belt take-down, repeat points 2 through 8.
9. Start the machine with the engaging rod. The knitting program is started automatically.

Further information:


- Threading up yarn [▢67]

3.5.2 Threading up thread into yarn carrier

Key	Function
	Call up "Manual interventions" window
	Call up "Machine start" window

Keys for threading up thread into yarn carrier

1. Call up "Manual interventions" window.
2. Tap the (1) "YC bolt up" key.
3. Note the position of the yarn carrier and push the yarn carrier outward below the carriage.
4. Thread-up yarn carrier.




You can switch on shortly the corresponding feed wheel (60 seconds) to ensure that the yarns run easily over the rollers. Turn on the switch (2) or (3) for this.

5. Push the yarn carrier into its previous position again.
6. Tap the (4) "YC bolt bottom" key.
7. To move the carriage assembly slowly, pull the engaging rod slightly toward the front.
8. When knitting slowly, make sure that the thread is laid in the needles.
9. To continue knitting, start the machine with the engaging rod.

- or -

- ➔ If the fabric is defective, call up the "Machine start" window and tap the "SP from line 1" key to knit the fabric again.


3.5.3 Removing fabric winding around fabric take-down

Key	Function
	Call up "Take-down" window

Key for removing fabric winding around fabric take-down

Fabric winding in main take-down

1. To remove the fabric winding, call up the "Take-down" window.



"Take-down" window

2. Tap the "Main take-down Op." key (1).
3. Pull the fabric smooth and free the take-down rollers from loose threads and fabric remainders

- or -

- Press the "Main take-down Backw." (2) key until the fabric winding can be removed.

4. Tap the "Main take-down Clo." key to close the main take-down.
5. To continue knitting, start the machine with the engaging rod.

Fabric winding in auxiliary take-down



1. To remove the fabric winding, call up the "Take-down" window.
2. Remove needle bed or position it at an angle.
3. Tap the "Auxiliary take-down Op." key (3).
4. Press the "Auxiliary take-down backw." key until the fabric winding can be removed.
5. Free the take-down rollers from loose threads and fabric remainders.
6. To close the auxiliary take-down, tap the "Auxiliary take-down Clo." key.
7. Screw on the needle bed again tight.
8. To continue knitting, start the machine with the engaging rod.

Further information:

- Remove needle bed or position it at an angle [▢355]

3.6 Starting the machine after a fault


The knitting machine control constantly controls the yarn, the fabric, all movable parts of machine, the motors and the electronic components. If an error occurs, the machine stops. The signal light glows yellow, a pictogram appears on the touch screen and a horn goes off. The most common error causes are shown in the pictographs on the touch screen. If an error occurs, one pictograph appears, and in the case of several errors the corresponding pictographs appear consecutively. Errors which occur seldom (e. g. hardware errors) are shown with a common pictograph.

Key	Function
	"Information on error remedies" A big and a small mark appear alternatively
	Confirm error message

Keys for starting machine after a fault

Starting the machine after a fault:

- To get detailed information on an error, tap the pictograph.
 - ▷ The "Current messages" window appears. If the error can be remedied by changing the settings, a function key appears in the middle of the lower screen bar.




"Current messages" window

- 1 Pictograph
- 2 Error code
- 3 Text of message

- To change the settings, tap the function key in the middle of the bottom line of the screen and eliminate the error.

- or -

- ➔ If additional information is required, tap the desired error message and tap the "Information on error remedies" key. The possible fault causes and their remedy are displayed.



Further information for an error message

3. Eliminate the error.
4. Confirm the error message.
5. To continue knitting, start the machine with the engaging rod.





3.6.1 Message and tip retrospective view

Message history

If an error occurs, it is not only displayed in the "Current messages" window, it is also written into an additional memory. The error messages for the respective day are saved in this memory.

A new memory is automatically selected for each day. There are a total of seven memories so that the error messages of the last 7 days are available. As a result, you can create an overview of which error messages have occurred over the past several days.


When switching off the machine main switch, the error messages currently present in the "Current messages" window are deleted, however the daily memories with the error messages are not deleted.

Key	Function
	Call up "Info" window
	Call up "Additional function keys"
	Call up message retrospective view:
	Key for daily message retrospective view (the key for the message retrospective view of the past day is shown in the picture)

Keys for calling up retrospective view of error messages

Call up message retrospective view:

1. Call up "Info" window.
 2. Call up "Additional function keys".
 3. Call up message retrospective view:
 4. Call up "Additional function keys".
- ▷ A list of the keys of the message retrospective views appears.







List of message retrospective views

5. Call up the desired daily retrospective view.

Eliminating errors in the fabric

Tips history The tips for the error messages are also saved. As with the message retrospective view, there are seven daily memories so that the tips of the last 7 days are available. As a result, you can create an overview of which tips have occurred over the past several days.

Key	Function
	Call up "Info" window
	Call up "Additional function keys"
	Display tip retrospective view
	Key for daily tip retrospective view (the key for the tip retrospective view of the past day is shown in the picture)






Keys for displaying tip retrospective view

Displaying tip retrospective view:

1. Call up "Info" window.
2. Call up "Additional function keys".
3. Display tip retrospective view.
4. Call up "Additional function keys".
 - ▷ A list of the keys of the tip histories appears.
5. Call up the desired daily retrospective view.

3.6.2 Suppressing error messages


If, for example, a change is made to a knitting program and an error message is present, the knitting program or other windows are covered by the current error message. This may interrupt your work. To prevent this from happening, the error message can be suppressed. Only the display on the touch screen is suppressed, not the stop motion of the knitting machine.

Key	Function
	Call up "Additional function keys"
	Suppress error messages ("Activating setting-up operation")
	Returning to the previous window
	"Setting-up operation active" symbol
	Enabling error messages again ("Deactivating setting-up operation")

Keys for suppressing error messages

Eliminating errors in the fabric

- Suppressing error messages
1. If an error message is displayed, call up the "Additional function keys" button.



Suppressing error messages

2. Press the "Suppress error message" key.
 - ▷ The "Setting-up operation" message appears. The error messages are suppressed until this is changed back. You are automatically brought back to the previous window and can continue working.
3. As a reminder that the error messages are being suppressed, the "Setting-up operation active" symbol appears in the upper right corner of each window.
4. The currently active and suppressed error messages can be viewed. Tap the "Setting-up operation active" symbol for this.

Enabling suppressed error messages again

1. Touch "Setting-up operation active" symbol.
2. Call up "Additional function keys".
3. Press the "Enable error messages again" key.

Automatic enabling

If there are no more stop motions, set-up mode is deactivated automatically.

4 Adjusting knitting machine

This chapter contains information on:

- Basic settings [▢113]
- Advanced adjustments [▢167]
- Working with files [▢228]
- Working with the Sintral editor [▢255]
- KnitLAN connection [▢262]
- Defining user profile [▢265]




4.1 Basic settings

This chapter contains the adjustment instructions and other information on:

- Adjusting carriage speed [▢114]
- Setting stitch tension [▢117]
- Adjusting yarn carriers [▢121]
- Staggering yarn carriers [▢129]
- Adjusting yarn tension [▢132]
- Adjusting yarn delivery on friction feed wheel * [▢134]
- Adjusting storage feed wheel MSF 3 * [▢136]
- Adjusting knitting areas [▢137]
- Adjusting take-down [▢138]
- Processing fabric take-down menu [▢141]
- Setting Cycle Counter and Quantity of Fabrics [▢145]
- Adjusting shape counters [▢146]
- Setting counters [▢148]
- Switch illumination on and off [▢149]
- Setting value for releasing thread clamp [▢150]
- Configuration symbol bar [▢151]
- Configuring monitoring [▢152]
- Setting up the pattern [▢156]
- Racking correction [▢164]

4.1.1 Adjusting carriage speed

Different carriage speeds can be entered for different knitting situations. The indirect carriage speed only becomes effective when it is slower than the normal speed.

Key	Function
	Call up "Carriage speed" window
	Confirm entries
	Call up "Main menu"

Keys for entering the carriage speed

Adjusting carriage speed:

1. Call up the "Carriage speed" window.
2. Tap the input fields for the carriage speed and enter the desired values.
3. Confirm entries.
4. Call up "Main menu".

Further information:

- Setting machine parameters [176]
- Economic production and the influencing factors [1]

Carriage speed (Setup2)

Name	Value	Comment
MSEC	0.70	
MSEC0	0.00	Standard-S0
MSEC1	0.00	Standard-Umhängen
MSEC1	0.70	
MSECC	0.30	

Name	Value	Number of Rows	Comment
MSECK	0.00	1	

Name	Value	Comment
MSEC2	1.00	Standard-Stricken
MSEC3	0.70	Stricken3
MSEC4	1.00	Stricken6
MSEC7	0.05	
MSEC8	0.05	


-  Take-down
-  Yarn carrier
-  Stitch length
-  Speed
-  Cycle counter
-  Yarn length

"Carriage speed" window

	Explanation	Value range (meters/second)
MSECK	Carriage speed for small knots over m rows, standard: 1 row	Minimum value: 0.05 Maximum value: 1.20 Step width: 0.05
MSEC	Speed (normal speed)	Minimum value: 0.05 Maximum value: 1.20 Step width: 0.05
MSEC0	Speed for empty rows (S0)	Minimum value: 0.05 Maximum value: 1.40 Step width: 0.05
MSEC1	Speed for transfer rows	Minimum value: 0.05 Maximum value: 1.20 Step width: 0.05
MSECI	Speed with Intarsia Yarn Carrier (CMS ADF-3: Specification is not taken into account)	Minimum value: 0.05 Maximum value: 1.00 (CMS-C: 0.7) Step width: 0.05
MSECC	Speed outside the needle bed when the yarn carrier is brought in the clamp or taken out of the clamp.	Minimum value: 0.05 Maximum value: 0.50 Step width: 0.05
MSEC2-20	Speed for knitting rows	Minimum value: 0.05 Maximum value: 1.20 Step width: 0.05
Comment	Comment	ASCII Characters

Basic settings

Carriage speed (Setup1)






"Carriage speed" window

Input field	Meaning	Input values
"Normal MSEC"	Carriage speed with normal yarn carriers	0.05 to 1.20 m/s Step width: 0.05
"Intarsia MSEC1"	Carriage speed with intarsia yarn carriers	0.05 to 1.00 m/s Step width: 0.05
"Knot selectable MSECK"	Carriage speed after small knots	0.05 to 1.20 m/s Step width: 0.05
"for row (s)"	Number of rows with reduced carriage speed after small knots	1 to 12 rows Step width: 1
"MSECC"	Carriage speed outside the needle bed when the yarn carrier is brought in the clamp or taken out of the clamp.	0.05 to 0.50 m/s Step width: 0.05
"MSECNPJ=n"	Display of the carriage speed for NPJ	
"MSEC0=n"	Indirect carriage speed "n" with empty rows ("S0")	"n" = 0.05 to 1.40 m/s Step width: 0.05
"MSEC1=n"	Indirect carriage speed "n" with transfer rows	"n" = 0.05 to 1.20 m/s Step width: 0.05
"MSEC2=n" to "MSEC9=n"	Indirect carriage speed "n" with knitting rows	"n" = 0.05 to 1.20 m/s Step width: 0.05

Input fields in "Carriage speed" window

4.1.2 Setting stitch tension

The stitch tension and thus the stitch size depend on the stitch cam values. It is possible to specify either the stitch tension as an absolute value or the stitch length.

Key	Function
	Call up "Stitch length" window
	Confirm entries
	Call up "Main menu"

Keys for setting the stitch tension

Setting stitch tension:








1. Call up the "Stitch length" window.
2. With Setup1: Set the switch in the "NP value/(mm)" field to "NP value" or "(mm)".
3. With Setup1 and Setup2:
Tap on the input field that is to be edited and enter the value.
4. Confirm entries.
5. Call up "Main menu".

Further information:

- [Stitch Tension Range \[2\]](#)
- [Stitch lengths \[5\]](#)
- [Economic production and the influencing factors \[1\]](#)

Basic settings

Stitch tension (Setup2)

NP				
Name	Value	Value [mm]	Comment	
NPK	0.00	<input type="checkbox"/>		    
Name	Value	Value [mm]	Comment	
NP1	9.00	<input type="checkbox"/>	Netz	
NP2	10.00	<input type="checkbox"/>	Schlauchnetz	
NP3	10.00	<input type="checkbox"/>	2x1/2x2-Rapport	
NP4	11.00	<input type="checkbox"/>	Übergang	
NP5	12.00	<input type="checkbox"/>	Struk. einflächig vorne	
NP6	12.00	<input type="checkbox"/>	Struk. einflächig hinten	
NP8	12.50	<input type="checkbox"/>		
NP9	12.00	<input type="checkbox"/>	Schutzreihen	
NP20	9.00	<input type="checkbox"/>	Anfang1	
NP21	10.00	<input type="checkbox"/>	Anfang2	
NP22	12.50	<input type="checkbox"/>	Anfang3	
NP24	12.00	<input type="checkbox"/>	Anfang5	
NP25	18.00	<input type="checkbox"/>	Kammfaden	

	Explanation	Value range
NPK	Correction for all stitch cams	Minimum value: -2 Maximum value: 2 Step width: 0.05
NP1 - NP100	Stitch cam position 1 to 100	
Value	Stitch length in NP values or mm	
Value [mm] <input type="checkbox"/>	Specification in NP values.	Minimum value: 6.5 Maximum value: 22.5 Step width: 0.05
Value [mm] <input checked="" type="checkbox"/>	Settings in millimeters. Setting the yarn length per stitch (Yarn Length Control).	Minimum value: 2.20 Maximum value: 33.00 Step width: 0.01
Comment	Comment	ASCII Characters

Further information:

- [Stitch Tension Range \[2\]](#)
- [Stitch lengths \[5\]](#)
- [Economic production and the influencing factors \[1\]](#)

NPR (tab) Correction of the stitch cam position for the right carriage (for tandem operation only)

	Explanation	Value range
NPR	Correction of the stitch cam position for the right carriage	
Front	Correction value depending on system in front or rear and on carriage direction to the left or to the right	Minimum value: -2 Maximum value: 2 Step width: 0.05
Rear		
<<		
>>		
NPxR	Correction value for the stitch cam position x (1-100) of the right carriage	
Value	Specification in NP values.	Minimum value: -2 Maximum value: 2 Step width: 0.05
Value [mm] <input checked="" type="checkbox"/>	Specification in millimeters.	Minimum value: -5.0 Maximum value: 5.0 Step width: 0.01
Comment	Comment	ASCII Characters

Further information:

- Table Tools [13]
- File tools [15]
- Helpers for Input [9]
- Overview of the Setup2 Editor of the CMS [7]
- Setup Data [1]
- Comparing Setup1 to Setup2 [3]

Basic settings

Stitch tension (Setup1)

The screenshot shows the 'Stitch length (NP 1-30)' window. It features a grid of input fields for NP values (NP1 to NP30). NP1 is set to 11.0, while NP2 through NP30 are set to 12.5. To the right of the grid are fields for NPK (0.0), NPR << (0.0 - 0.0), and NPR >> (0.0 - 0.0). At the bottom right, there is a section for 'NP value' with a unit selector set to '[mm]' and a value of 2.00.

"Stitch length" window

Edit box	Meaning
"NP#"	Stitch cam value (NP1-NP 100). Step width: 0.05. Call up NP31-NP100 with the help of the additional function keys.
"NPK"	Stitch cam correction value for all stitch cam positions. Step width: 0.05.
"NPR <<"	With tandem operation: Stitch cam correction values (front - back) from right to left carriage. Step width: 0.05. Carriage direction to the left.
"NPR >>"	With tandem operation: Stitch cam correction values (front - back) from right to left carriage. Step width: 0.05. Carriage direction to the right.
"NP value"	Setting stitch tension in NP values
"(mm)"	Setting the yarn length per stitch






Input fields for setting the stitch tension

Further information:


- [Stitch Tension Range \[2\]](#)
- [Stitch lengths \[5\]](#)
- [Economic production and the influencing factors \[1\]](#)

4.1.3 Adjusting yarn carriers



Adjusting yarn carriers

Key	Function
	Call up the "Yarn carrier" window
	Call up the "Adjusting yarn carrier" window
	Call up "Additional function keys"
	Call up desired knitting area
	Confirm entries

Keys for adjusting the yarn carriers



Yarn carrier
STOLL
THE RIGHT WAY TO KNIT

Y	SEN1	Y:=n	0/1	YG	YP	Ka	Kb	K<I>a	K<I>b	Type	I<>	Ba	Bb	Ua	Ub
1A	1	A	1	1	1	0.0	0.0			N		0	0	14.5	14.5
1B	1	A	1	1	1	0.0	0.0			N		0	0	14.5	14.5
1C	1	A	1	1	1	0.0	0.0			N		0	0	14.5	14.5
1D	1	A	1	1	1	0.0	0.0			N		0	0	14.5	14.5
2A	1	A	1	1	1	0.0	0.0			N		0	0	14.5	14.5
2B	1	A	1	1	1	0.0	0.0			N		0	0	14.5	14.5
2C	1	A	1	1	1	0.0	0.0			N		0	0	14.5	14.5
2D	1	A	1	1	1	0.0	0.0			N		0	0	14.5	14.5
3A	1	A	1	1	1	0.0	0.0			N		0	0	14.5	14.5
3B	1	A	1	1	1	0.0	0.0			N		0	0	14.5	14.5
3C	1	A	1	1	1	0.0	0.0			N		0	0	14.5	14.5


1A


Current YCI:

Current YDI:

Yarn carrier at needle bed border (EAY!) 

YDF 7

"Yarn carrier" window

Basic settings

Column	Data shown
Y	Specification of yarn carrier
SEN	Specification of SEN area in which yarn carrier works
Y: =n	Specification of yarn type
0/1	Yarn type switched on or off
YG	Home position of the yarn carrier for needle. . .
YP	Current yarn carrier position for needle. . .
Ka	Yarn carrier correction value (left) for not swiveled yarn carrier if the yarn carrier is positioned within the fabric. Value range: -120...0...120 . Step width: 0.5=1/32 inch=0.8 mm
Kb	Yarn carrier correction value (right) for not swiveled yarn carrier if the yarn carrier is positioned within the fabric. Value range: -120...0...120 . Step width: 0.5=1/32 inch=0.8 mm
K<l>a	Intarsia yarn carrier correction value (left) for swiveled intarsia yarn carrier Value range: -120...0...120 . Step width: 0.5=1/32 inch=0.8 mm
K<l>b	Intarsia yarn carrier correction value (right) for intarsia swiveled yarn carrier Value range: -120...0...120 . Step width: 0.5=1/32 inch=0.8 mm
Type	Display of the yarn carrier type: Normal yarn carrier (N), plating yarn carrier (P), double bow yarn carrier (PA), intarsia yarn carrier (I)
l<>	Swiveling direction of intarsia yarn carrier
Ba	Display of the yarn carrier braking value a (left)
Bb	Display of the yarn carrier braking value b (right)
Ua	Adjust the engaging width a (left) (when plating with normal yarn carriers).
Ub	Adjust the engaging width b (right) (when plating with normal yarn carriers).
MSEC	Carriage speed when this yarn carrier is used (technical fabrics)
V	Number of selvedge needles until first knitting needle (technical fabrics)
YDF	Additional distance of yarn carrier from fabric selvedge when fully fashion knitting. Value range: 1-20 needles.

Data in the "Yarn carrier" window

Adjusting yarn carriers:

1. Call up the "Yarn carrier" window.
 - ▷ In the default setting the yarn carriers are displayed in all knitting areas (SEN areas).
2. If only the yarn carriers of a certain SEN area are to be displayed, then call up "additional function keys" and tap the desired SEN area.
3. Tap the line (yarn carrier) that is to be processed.
 - ▷ The number of the yarn carrier appears at the bottom edge of the window, on the right of the "Adjusting yarn carriers" key.
4. Tap the "Adjusting yarn carriers" key.
5. Tap on the input field that is to be edited and enter the value.
6. Confirm entries.
7. Return to the "Yarn carrier" window.



Further information:

- Intarsia yarn carrier - Adjust stopping point (basic setting, braking value) *
[☐199]

Basic settings

Adjusting yarn carriers
(Setup2)

YD / YDI		YC / YCI		Y:Ua-b / Y:Noc					
Name	Y	Ka	Kb	K<I>a	K<I>b	MSEC	V	Comment	
⤴ YCI6	Y-1A	0.0	0.0	0.0	0.0	0.00	0		Take-down
	Y-2A	0.0	0.0	0.0	0.0	0.00	0		Yarn carrier
	Y-3A	0.0	0.0	0.0	0.0	0.00	0		Stitch length
	Y-6A	0.0	0.0	0.0	0.0	0.00	0		

Key	Function
	Confirm entries
	Return to the "Yarn carrier" window

Keys for adjusting the yarn carriers

	Explanation	Value range
⤴ YC	Direct yarn carrier correction Collapse ⤴ (reduced display) Expand ⤵ (expanded display)	
⤴ YCI	Yarn carrier correction index YCI1 to YCI20 Collapse ⤴ (reduced display) Expand ⤵ (expanded display)	
Y	Corrections of yarn carrier 1A to 8D	
Ka	Yarn carrier correction value (left) for not swiveled yarn carrier if the yarn carrier is positioned within the fabric.	Minimum value: -120 Maximum value: 120 Step width: 0.5=1/32 inch=0.8 mm
Kb	Yarn carrier correction value (right) for not swiveled yarn carrier if the yarn carrier is positioned within the fabric.	Minimum value: -120 Maximum value: 120 Step width: 0.5=1/32 inch=0.8 mm
K<I>a	Intarsia yarn carrier correction value (left) for swiveled intarsia yarn carrier	Minimum value: -120 Maximum value: 120 Step width: 0.5=1/32 inch=0.8 mm
K<I>b	Intarsia yarn carrier correction value (right) for intarsia swiveled yarn carrier	Minimum value: -120 Maximum value: 120 Step width: 0.5=1/32 inch=0.8 mm
MSEC	Carriage speed if this yarn carrier is used (technical fabrics).	

	Explanation	Value range
V	<p>Reduce carriage speed (n) for yarn carrier (n = 0..3). The speed is reduced to 75% from carriage reversal point until achievement of the operating range of the yarn carrier. Finally it can be chosen between the following possibilities:</p> <ul style="list-style-type: none"> ◆ 1 = Acceleration up to 100% ◆ 2 = Braking down to 50%, maintain speed over a fabric width of 2 inches, acceleration up to 100% ◆ 3 = Braking down to 50%, maintain speed over a fabric width of 5 inches, acceleration up to 100% ◆ 0 = Cancelling out of carriage speed specific to yarn carrier 	
Comment	Comment	ASCII Characters



Change engaging width (Ua, Ub)


For this call up the Y:Ua-b tab.

Further information:



- Intarsia yarn carrier - Adjust stopping point (basic setting, braking value) *
[199]

Basic settings

Adjusting yarn carriers
(Setup1)



"Adjust yarn carriers" window

Key	Function
	Save changes and end setting process
	End setting process without saving changes Return to the "Yarn carrier" window


Further information:

- Intarsia yarn carrier - Adjust stopping point (basic setting, braking value) *
[199]

Tandem machine: Correction of the yarn carriers in the right carriage (Setup1, Setup2)

If the carriages have a wide coupling, the stopping positions of the yarn carriers in the right carriage can be corrected (column "Right offset"). It may, for example, be necessary to carry out corrections at very fine fabrics or at special intarsia patterns. Possible reasons for a correction:





- different wear of the yarn carriers used in the left and right carriages
- different wear of the yarn carrier rails
- different lubrication
- different directions of the yarn feed in the left and right carriages



"Yarn carrier correction" window during tandem operation

Column	Data shown
"YL"	Specification of the yarn carrier in the left carriage.
"YR"	Specification of the yarn carrier in the right carriage.
"Oa"	Right carriage during tandem operation: Yarn carrier correction value a (stopping position on the left). Value range: -8...0...8 . Step width: 0.5=1/32 inch=0.8 mm The correction value refers to the stop value of the left carriage.
"-b"	Right carriage during tandem operation: Yarn carrier correction value b (stopping position on the right). Value range: -8...0...8 . Step width: 0.5=1/32 inch=0.8 mm

Data in the "Yarn carrier correction" window

Key	Function
	Call up the "Yarn carrier" window
	Call up "Additional function keys"
	Call up the "Yarn carrier correction" window
	Call up "Main menu"

Keys for correcting the yarn carriers

Enter correction of a yarn carrier:





1. Call up the "Yarn carrier" window from the "Main menu".
2. Call up "Additional function keys".
3. Call up the "Yarn carrier correction" window.
4. Enter new values for the yarn carrier.
5. Confirm entries.
6. Call up "Main menu".



The correction values are not pattern-dependent, but rather machine-dependent. These data are therefore not deleted when a new knitting program is loaded. The correction values always remain saved, even when the operating system is loaded again. If the correction is no longer required, the correction values have to be reset to "0" manually.

4.1.4 Staggering yarn carriers

Adjust the staggering of the yarn carriers at the fabric selvedge.


Key	Function
	Call up the "Yarn carrier" window
	Call up "Additional function keys"
	Call up "YC staggering" window
	Confirm entries

Keys for staggering the yarn carriers

Staggering the yarn carriers:

1. Call up the "Yarn carrier" window.
2. Call up "Additional function keys".
3. Call up the "YC staggering" window.
4. Tap on the input field that is to be edited and enter the value.
5. Confirm entries.

Staggering yarn carriers
(Setup2)



"YC staggering" window

Basic settings

The yarn carrier staggering is displayed in the window. If you want to change the staggering, call up the Setup2 editor.

YD / YDI		YC / YCI	Y:Ua-b / Y:Ncc		
Name	YD	Left	Right	Comment	
YD	YD8	32.0	32.0		
	YD7	27.0	18.0		
	YD6	9.0	4.0		
	YD5	15.0	22.0		
	YD4	22.0	15.0		
	YD3	18.0	27.0		
	YD2	4.0	9.0		
	YD1	8.0	12.0		
YDI6	YD8	32.0	32.0		
	YD7	27.0	18.0		

Take-down

Yarn carrier

Stitch length

Speed

Cycle counter


	Explanation	Value range
⌘ YD	Distance between yarn carriers and fabric selvedge Collapse ⌘ (reduced display) Expand ⇩ (expanded display)	
YD1 : YD8	Distance of the yarn carriers on track 1 to 8 from the left and right fabric selvedge	Minimum value: 0 Maximum value: 160 Step width: 0.5=1/32 inch=0.8 mm
⌘ YDI	Additional, indirect yarn carrier staggering (YDI1 to YDI20) Collapse ⌘ (reduced display) Expand ⇩ (expanded display)	Minimum value: 0 Maximum value: 160 Step width: 0.5=1/32 inch=0.8 mm
Comment	Comment	ASCII Characters

Staggering yarn carriers (Setup2)

Key	Function
	Call up the Setup2 Editor
	Confirm entries
	return to the "YC staggering" window

Keys for staggering the yarn carriers


1. In the "YC staggering" window call up the Setup2 editor
2. Tap on the input field that is to be edited and enter the value.
3. Confirm entries.
4. Return to the "YC staggering" window.

Staggering yarn carriers
(Setup1)

"YC staggering" window

1. Tap the input fields next to the yarn carriers and enter the values.
Value range: 0-160. Step width: $0.5 = 1/32$ inch = 0.8 mm
2. Confirm entries.

4.1.5 Adjusting yarn tension



Adjustment of yarn tension

The adjustment of yarn tension is done in the following sequence:

1. Lateral yarn tensioner: Adjusting the restoring force on the linear regulator (2).
2. Opening permanent brake
3. Adjusting yarn control device
4. Adjusting permanent brake
5. Lateral yarn tensioner: Adjusting the yarn tensioning path on the lock segment (3)



This sequence should help you to find the optimal adjustment of the yarn tension. Depending upon the type of fabric and the yarn characteristics it is possible that you may have to change the adjustments many times before you find the optimal adjustment.

These adjustments are the easiest to undertake while the machine is knitting.


Make sure that the braking and restoring force on all elements is set at the lowest possible.

Adjusting restoring force

1. Remove lateral yarn tensioner (1) from the stay.
2. Linear regulator (2) is to be set in a manner that the lateral yarn tensioner has enough strength to hold the thread tensioned always.
3. Control the setting while the machine is knitting.
In this case the thread must not sag rather it should always be tensioned by the yarn tensioner.

Opening permanent brake → Open the rotary knob (5) of the permanent brake (4) as wide as possible.


Adjusting yarn control device 1. Yarn brake (8) to be adjusted in such a manner that the thread break control does not move too much underneath such that the stop impulse gets released.



2. Adjust knot detectors for large knots (7) and for small knots (9) depending on yarn thickness and knots so, that they are triggered by an undesirable knot size.

Adjusting permanent brake → Adjust the permanent brakes (4) in such a manner that the lateral yarn tensioner swivels only a bit (approx. 25 degrees), when the yarn guide achieves it's left or right stopping position.
If a thread loop is formed between the friction feed wheel and the permanent brake then the thread brake on the yarn control device should be set a little stronger and the permanent brake should be set a little weaker.

Set the maximum slack take-up path of the yarn tensioner If desired the maximum slack take-up path of the yarn tensioner can be set from 80 to 35 degrees. This will be set with the lock segment (3). It has four lock positions (A – D).




Position	max. angle	Explanation
A	80	Home position of the lock segment. Active thread clamp in action Largest yarn tensioning path
B	65	Active thread clamp in action
C	50	Active thread clamp in action
D	35	Active thread clamp out of action Smallest yarn tensioning path

4.1.6 Adjusting yarn delivery on friction feed wheel *

The friction rollers have a constant peripheral speed and feed the maximum amount of thread consumed by the knitting machine. To adjust the yarn delivery to the actual consumption, the winding angle of the thread is modified. If the winding angle is enlarged, then the friction force increases and the friction feed wheel delivers more thread. The friction feed wheel should always feed somewhat more thread than the yarn carriers consume.

Depending on machine model and component type, there are different models of friction feed wheels.


Type 1



Adjusting the yarn delivery on the friction feed wheel

→ If the yarn delivery is to be reduced, then lead the yarn through the eyelet (1).

Type 2



Adjusting the yarn delivery on the friction feed wheel

Adjusting the yarn delivery:


1. Push the fixing device (1) toward the front.
2. If the yarn delivery is to be increased, turn the swivel bow (2) upward.
- or -
- If the yarn delivery is to be reduced, turn the swivel bow (2) downward.
3. Push the fixing device (1) toward the rear.
4. Switch on the knitting machine and start knitting.
5. Check the yarn delivery.
6. Set all swivel bows consecutively with the scale (3) as described in steps 1 to 5.

For very coarse yarn (valid for all types)

The distance between stop motion rail and friction roller is too small so that the yarn comes into contact with the stop motion rail and releases a stop impulse, then the machine stops.

Modifying the distance:

1. Remove the screw (5) and the stop motion rail (4).




Set the distance between stop motion rail and friction roller

2. Turn the stop motion rail by 180 degrees and assembly it again.
▶ A bigger distance (6) is between the stop motion rail and the friction roller.

Further information:

- Symbols in this document [□3]
- Threading up threads into friction feed wheel * [□13]

4.1.7 Adjusting storage feed wheel MSF 3 *



Storage feed wheel MSF 3

The optimal yarn tension depends on the yarn and the pattern. This adjustment is the easiest to undertake while the machine is knitting.

Adjusting the yarn tension:

1. Adjust the yarn tension at the rotary knob (1):
 - ▷ The contact pressure of the membrane (2) is changed this way.
2. Check: No thread loop may be formed between the feed wheel and the safety door.
3. The rotary knob has to engage in the brake (3).




You will find further information on the storage feed wheel MSF 3 in the operating instructions which are enclosed.

Further information:

- Symbols in this document [3]


4.1.8 Adjusting knitting areas

In the Sintral program up to four knitting areas (SEN areas) can be defined and switched on and off separately. If the knitting areas are not defined in the Sintral program, they can be adjusted in the "Knitting areas" window.

Key	Function
	Call up "Knitting areas" window
	Confirm entries
	Call up "Main menu"

Keys for adjusting the knitting areas

1. Call up the "Knitting areas" window.






"Knitting areas" window

2. Assign each knitting area ("SEN") a needle area.
3. Confirm entries.
 - ▷ The assigned areas are graphically shown.
4. To switch individual knitting areas on or off, tap the switch in the "Selection (manual)" column.
5. Call up "Main menu".

4.1.9 Adjusting take-down


Setting fabric take-down values

Key	Function
	Call up "Take-down" window
	Confirm entries
	Call up "Main menu"

Keys for setting the fabric take-down values

Setting the fabric take-down values:

1. Call up the "Take-down" window.
 - ▷ The current fabric take-down values are shown.



"Take-down" window





2. To enter the fabric take-down values, tap the input fields and enter the desired values.
3. Confirm entries.

Further information:

- Economic production and the influencing factors [1]

Adjusting the control of the fabric take-down:


During production, the control of knitting machine compares the current values with threshold values. If a threshold value is exceeded, the knitting machine stops and displays a fault.

Key	Function
	Call up "Additional function keys"
	Call up "Fabric take-down Control" window
	Confirm entries
	Return to "Take-down" window

Keys for adjusting fabric take-down control

Adjusting fabric take-down control:

1. Call up the "additional function keys" in the "Take-down" window.
2. Call up the "Fabric take-down Control" window.






"Fabric take-down Control" window

3. Enter the threshold values.
4. Confirm entries.
5. Return to the "Take-down" window.

Basic settings

Control comb take-down It is always only possible to carry out one comb function.

Key	Function
	Call up "Additional function keys"
	Call up "Comb" window
	Return to "Take-down" window

Keys for controlling comb take-down

Control comb take-down:

1. Call up the "additional function keys" in the "Take-down" window.
2. Call up the "Comb" window.







"Comb" window

3. To activate a function, touch a key.
4. Return to the "Take-down" window.

4.1.10 Processing fabric take-down menu

In the fabric take-down menu (WMF menu), the fabric take-down commands are combined into a single function which concerns a knitting situation.

Key	Function
	Call up "Take-down" window
	Call up "Additional function keys"
	Call up "WMF menu" window
	Confirm entries

Keys for adjusting the fabric take-down menu

Adjusting fabric take-down menu:

1. Call up the "additional function keys" in the "Take-down" window.
 2. Call up the "WMF menu" window.
 3. Touch the line to be edited.
 - ▷ The line appears at the bottom edge of the window.
 4. Tap the fields of the selected line and enter the desired values.
- or -
- Copy contents of a line and insert at desired location again.
 5. Confirm entries.
 6. Return to the "Take-down" window.

Save fabric take-down menu

If you save the pattern, the changes in the fabric take-down menu are saved in the setup file.

Further information:

- Working with files, libraries and folders [238]

Basic settings

Fabric take-down menu
(Setup2)

WMF		WM% / WMK%									Take-down
Name	WM min	WM max	N min	N max	WMI	WM^	WMC	WM+C	Comment		
WMF1	2.0	3.8	0	100	3	0	0	20	Vorwärts	Yarn carrier	
WMF2	0.0	0.0	0	0	0	0	0	10	Entlasten	Stitch length	
WMF3	0.0	0.0	0	0	0	0	0	0			
WMF4	0.0	0.0	0	0	0	0	0	0			

	Explanation	Value range
WMF...	Fabric take-down function	WMF1 to WMF50
WM min	Minimum fabric take-down value (with Fully Fashion)	Minimum value: 0 Maximum value: 31.5 Step width: 0.1
WM max	Maximum fabric take-down value (value must always be specified)	Minimum value: 0 Maximum value: 31.5 Step width: 0.1
N min	Minimum quantity of needles (with Fully Fashion)	Minimum value: 0 Maximum value: Needle number of the CMS Step width: 1
N max	Maximum quantity of needles (with Fully Fashion)	Minimum value: 0 Maximum value: Needle number of the CMS Step width: 1
WMI	Fabric take-down impulse	Minimum value: 0 Maximum value: 15 Step width: 1
WM^	Open the brake of the active take-down system (main take-down or comb take-down) for a maximum of 2.5 seconds, take-down roller or comb take-down turn back by a maximum number of the indicated degrees (depending on the fabric tension and the fabric take-down value). CMS 5xx, 7xx, 8xx, CMS ADF-3: 9-60 degrees CMS 9xx: 9-120 degrees If either of both the conditions is fulfilled, then the brake is closed again. Fabric take-down value (n=0-31.5) becomes active again at the reversion.	No turning back: 0 Minimum value: 9 Maximum value: 120 Step width: 1

	Explanation	Value range
WMC	Set the speed control of the active take-down system (main take-down or comb take-down) to the value n (0-32). If the take-down system turns too quickly, the machine is stopped. 0= no stop motion, 1= insensitive, 32= very sensitive	Minimum value: 0 Maximum value: 32 Step width: 1
WM+C	Monitoring of main take-down. If the take-down has not been used after n (0-100) knitting rows, the machine will stop. (0 = no supervision)	Minimum value: 0 Maximum value: 100 Step width: 1
WMK+C	Controlling the comb. If the comb has not moved after n (0-100) knitting rows, the machine will stop. (0 = no supervision)	Minimum value: 0 Maximum value: 100 Step width: 1
Comment	Comment	ASCII Characters

Further information:

- Working with files, libraries and folders [238]

Basic settings

Fabric take-down menu
(Setup1)

WMF	WM		FF Needles		WMI	WM [^]	WMC	W+C	WM+C	WMK+C	W+=	W+P	Comment
	Min	Max	Min	Max									
1	0.0	0.0	0	0	0	0	0		0	0			
2	0.0	0.0	0	0	0	0	0		0	0			
3	0.0	0.0	0	0	0	0	0		0	0			
4	0.0	0.0	0	0	0	0	0		0	0			
5	0.0	0.0	0	0	0	0	0		0	0			
6	0.0	0.0	0	0	0	0	0		0	0			
7	0.0	0.0	0	0	0	0	0		0	0			
8	0.0	0.0	0	0	0	0	0		0	0			

Active WMF: 1

Key	Function
	Delete all information in the fabric take-down menu
	"Copy line" contents
	"Insert line" contents
	Confirm entries
	Return to "Take-down" window

Keys for adjusting the fabric take-down menu




Further information:

- Working with files, libraries and folders [D238]

4.1.12 Setting Cycle Counter and Quantity of Fabrics

The cycle counter specifies how often a pattern area is to be repeated. Which cycle counter controls which pattern area is defined in the knitting program.


The piece number specifies how many pieces are to be knitted. During production, the piece number is decreased by "1" as soon as a complete piece has been produced.

Key	Function
	Call up the "Cycle counters & counters" window
	Confirm entries
	Call up "Main menu"

Keys for adjusting the cycle counter and the piece number

Setting cycle counter and piece number:

1. Call up the "Cycle counters & counters" window.








The screenshot shows the "Cycle switch & counters" window. At the top, it says "#0 Cycle switch & counters" and the STOLL logo with the tagline "THE RIGHT WAY TO KNIT". Below this, there are several rows of input fields. The first row has "Piece number" set to 0 and "Still to be knitted" set to 0. Below that are rows for RS1 through RS19, each with a "0" and an input field. At the bottom, there are fields for #L, #LM, #RM, #R, #51, #53, #54, and #52, each with a "0" and an input field. Two black arrows are present: one pointing to the "Piece number" field and another pointing to the "MT" field.

"Cycle counters & counters" window

2. Set the cycle counters "RS1" to "RS19".
3. Set the piece number.
4. Confirm entries.
5. Call up "Main menu".

4.1.13 Adjusting shape counters


During fully fashion knitting the fabric selvages are controlled by the shape counters. When the values of the shape counters changes, then the fabric becomes broader or narrower. The alteration in the fabric width is mentioned in the knitting program. The shape counters should be changed manually only in exceptional cases, for example during designing.

Key	Function
	Call up the "Cycle counters & counters" window
	Call up "Additional function keys"
	Call up "Shape counters" window
	Confirm entries
	Call up "Main menu"

Keys for setting the shape counters

Setting the shape counters:

1. Call up the "Cycle counters & counters" window.
2. Call up "Additional function keys".
3. Call up "Shape counters" window.





"Shape counters" window

4. Set the counters to the desired value.
5. Confirm entries.

6. Call up "Main menu".





In the case of single-piece knitting, up to 4 shape counters can be used, in the case of double-piece knitting up to 8 shape counters.

	Shape counter	Counters for the start-width
	#L	#51
	#R	#52
	#LM	#53
	#RM	#54
	#L1	#55
	#R1	#56
	#LM1	#57
	#RM1	#58
	#L2	#59
	#R2	#60
	#LM2	#61
	#RM2	#62

The counters for start-width can be changed only in the knitting program or in the pattern preparation unit.

4.1.14 Setting counters

In addition to the piece counter and the cycle counters, there are also other counters. On the one hand, they can be used in the knitting program, e.g. to request conditions. On the other hand, they indicate various machine states.






Key	Function
	Call up the "Cycle counters & counters" window
	Call up "Additional function keys"
	Call up desired counter group
	Call up "Main menu"

Buttons for setting the counters

Setting counters:

1. Call up the "Cycle counters & counters" window.
2. Call up "Additional function keys".
3. Tap the key for the desired counter group.
4. Set counter to the desired value.
5. Call up "Main menu".

4.1.15 Switch illumination on and off

Key	Function
	Call up "Machine start" window
	Call up "Additional function keys"
	Switch on lighting
	Switch off lighting
	Call up "Main menu"

Keys for switching the lighting on and off

Switch the lighting on and off:

1. Call up "Machine start" window.
2. Call up "Additional function keys".
3. Switch on the lighting.
- or -
- Switch off the lighting.
4. Call up "Main menu".

Automatic switching off of the lighting

If the lighting is switched on, then you can set the duty cycle (window "Machine parameters").

Standard setting: Function active, duty cycle: 10 minutes (standard), value range: 0...60 minutes

With closed cover hoods	If the lighting is switched on, then it will switch off automatically at the end of the set time.	
When opening and closing the cover hoods	The lighting is switched on automatically when opening the covers.	
	If the covers are closed again, then it is checked whether the duty cycle has been reached.	
	Yes	The lighting will be switched off.
	No	The lighting will continue switched on until the remaining time is finished




Further information:

- Setting machine parameters [176]

4.1.16 Setting value for releasing thread clamp

The thread clamping and cutting device holds the thread of a yarn carrier not used for knitting at the moment. When the yarn carrier is used again, the carriage opens the clamping device after knitting a few rows and the yarn end is released. The clamp is released after 19 knitting rows as standard. This value can be set individually for each yarn carrier in the "Release clamps" window.

"Release clamps" window

Key	Function
	Call up "Release clamps" window
	Confirm entries
	Call up "Main menu"

Keys for entering the value for releasing thread clamp


Setting value for releasing thread clamp:

1. Call up the "Release clamps" window from the "Main menu".
2. Tap the input field of the corresponding yarn carrier and enter a value. In the default setting the value "20" which corresponds to 19 knitting rows (value - 1) is set.
3. Confirm entries.
4. Call up "Main menu".

4.1.17 Configuration symbol bar




The configurable toolbar allows you to jump directly to the individual windows without having to take the "Detour" through the main menu or using the "Additional functions" key. The toolbar is the headline or title bar of a window. You can include the symbols of those windows which you use most often in the toolbar.

The symbols can be called up in any window. To do so, tap the symbol on the top left of the title bar and the symbols are displayed. (Exception: Tap on "Go to mask" key in SINTRAL editor). To close the symbols again, tap the empty field next to them.



"Configuration toolbar" Window

Field/Key	Function
1	List of the windows which can be selected for the toolbar.
2	The toolbar contains the symbols of the selected windows. In the above figure the carriage speed has been selected.
3	Key used to set a symbol in the toolbar (2).
4	Key used to remove a symbol from the toolbar (2).
5	Change the position of a symbol in the toolbar (2). To do so, tap the symbol in the toolbar and use the corresponding key to move it forwards or backwards.
6	If there are more than 11 symbols in the toolbar, the display can be moved to the left or right with the arrow keys.

Key	Function
	Call up the "Service" window
	Call up "Configuration toolbar" window
	Call up "Main menu"

Keys for configuring the toolbar

Configuring toolbar:

1. Call up the "Service" window.
2. Call up "Configuration toolbar" window.
3. Tap the desired symbol (1).
4. Press the (3) key.

- or -

→ Double-tap on the symbol.


- ▷ The symbol is displayed in the toolbar (2). The character "X" before the symbol indicates that the symbol has been selected from the list (1) for the toolbar.

5. Call up "Main menu".

4.1.18 Configuring monitoring

The current Sintral line and the corresponding values for the cycle counters, Jacquards, stitch tension and counters are displayed in the "Changeable monitoring" window for each carriage stroke during productions.








You can specify yourself which values are to be displayed or have them determined automatically. (Exception: Those counters and repeat switches which are used exclusively in the Auto-Sintral program are not displayed.)



"Changeable monitoring" window

Field	Function
1	Display of the current Sintral line
2	White field with frame. The field can be linked to a value. The value is then displayed in this field. A thick frame around the field indicates that it cannot be covered by a function block (4).
3	Gray field. If a field (2) is limited to a value, the color changes from white to gray.
4	White field without frame. This is a function block. The display of a function block can be activated and deactivated.


Linking a field to a value

Key	Function
	Call up the "Changeable monitoring" window
	Call up "Additional function keys"
	"Automatic configuration"
	"Clear all fields" (reset)
	End setting process and save changes
	End setting process without saving changes
	Call up "Main menu"

Keys for linking a field

Linking a field to a value:

1. Call up the "Changeable monitoring" window from the "Main menu".
2. Touch a white field with a frame. The setting window appears.



Window for linking a field

3. Select the type of the value in the left column.
4. Select the value in the right column.
 - ▷ The selected value is displayed in the lower line.
5. Confirm entries.
6. If necessary, link further fields to a value.
7. Call up "Main menu".













If only one value is to be deleted, select the empty (white) field above "RS".

Basic settings

Activating the function block

Various function blocks can furthermore be displayed for the configurable values. The selected function blocks are positioned at fixed positions over the existing fields. They do not delete these, but just cover them, so that the fields are visible again when the function block is deactivated.





Key	Function
	Call up the "Changeable monitoring" window
	Call up "Additional function keys"
	Activate and de-activate the "Stitch tension" function block
	Activate and de-activate the "SEN area" function block
	Activate and de-activate the "Yarn carrier" function block
	Activate and de-activate the "Function name" function block
	Activate and de-activate the "Fabric take-down values" function block (Can only be activated, if the "STIXX" function block is deactivated.)
	Activate and de-activate the "Sintral print line" function block
	Activate/deactivate "STIXX" function block (Can only be activated, if the "Fabric take-down values" function block is deactivated.)
	Call up "Main menu"

Keys for activating a function block

1. Call up the "Changeable monitoring" window from the "Main menu".
2. Call up "Additional function keys".
3. Activate the desired function blocks.
4. Call up "Main menu".


Saving, loading, deleting
settings ...

The configuration carried out by you can be saved, loaded and deleted.

Key	Function
	Call up the "Changeable monitoring" window
	Call up "Additional function keys"
	Call up "Catalog Monitoring" window
	Call up "Main menu"

Keys for calling up the "Catalog Monitoring" window

1. Call up the "Changeable monitoring" window from the "Main menu".
2. Call up "Additional function keys".
3. Call up "Catalog Monitoring" window.




"Catalog Monitoring" window

4. Select the desired program point (1) (loading, saving, deleting ...).
5. Call up "Main menu".


4.1.19 Setting up the pattern

This menu can be used for fine adjustment of a pattern at the knitting machine. While the machine is knitting, the corresponding data of the knitting program are displayed for every carriage stroke. If required, changes can be carried out directly in this menu via setting windows, or the corresponding menu is opened for your input. To do so, touch the corresponding field.

Key	Function
	Call up the "Setting up the pattern" menu

Key for calling up the "Setting up the pattern" menu

The window is structured into various areas:






"Setting up the pattern" window

Area	Explanation
1	Display of: Carriage direction, cycle counters, SEN area, coupling width (for tandem machine), counters. The active cycle counter is highlighted. The values cannot be modified.
2	Setting up of the knitting systems: Needle action, stitch tension, yarn carrier, jacquard line.
3	Current Sintral line
4	Fabric take-down values or fabric take-down function
5	Status line: Here the individual values can be changed or the corresponding setting menu called up.
6	Actions for yarn carrier plunger, fabric take-down, comb take-down and auxiliary take-down
7	Call up "Stitch length" window
8	Additional yarn carrier distance for fully fashion knitting

Changing a value The values are changed by means of a virtual keyboard. If a value can be changed, a keyboard bar which allows a value to be entered, is displayed in the title bar of the menu.




Numerical keyboard

Element	Function
	End setting process without saving changes
	Undo a change, the previous value is displayed again
	End setting process and save changes

Input elements

Changing a value:

1. Tap the corresponding field. The setting window appears, for example:




"Yarn carrier" window

2. The keyboard bar appears in the title bar. Use it to carry out the changes.
3. Confirm input.

Basic settings

Setting up of the knitting systems


The stitch tension, needle action, yarn carrier and jacquard line are displayed for every knitting system. The corresponding menu is opened if the yarn carrier, stitch tension or jacquard line is touched.



"Change NP value" window

Area	Show	Change
1	Stitch tension (rear knitting system)	Value can be changed at indirect specification (NP6=9.2)
2	Needle action (rear knitting system)	
3	Number of the knitting system	
4	Yarn Carrier	Yarn Carrier Correction Yarn carrier stopping position
5	Needle action (front knitting system)	
6	Stitch tension (front knitting system)	Value can be changed at indirect specification (NP5=9.2)
7		Jacquard line

Stitch tension Not only the value of the stitch tension is displayed, but also the type of specification.
































"Display of the stitch tension" window

Type	Explanation	Setting possibility
1	Direct specification: "- -" (NP=12.5)	
2	Indirect specification: "5" (NP5=9.2)	Value can be changed
3	Jacquard-controlled stitch tension: "J1" (NPJ1=12.5). Presentation at flexible stitch: J1!	
4	Change the stitch tension	The "Stitch length" window appears. All the values can be changed.

Basic settings


Symbols for the needle actions

The needle actions are represented by symbols so that you know immediately which needle action is being carried out in one knitting system.

Symbol	Meaning	Symbol	Meaning
	Miss-knit		Front Stitch
	Rear Stitch		Front Tuck
	Rear Tuck		Cast-off
	Transfer to Front		Transfer to rear
	Transfer to the front and rear		Split-stitch to the front
	Split-stitch to the rear		Split-stitch to the front and rear
	Split-stitch to the front, stitch to the rear		Split-stitch to the rear, stitch to the front
	Stitch to the front, tuck to the front		Stitch to the rear, tuck to the rear
	Stitch to the front, tuck to the front, miss-knit		Stitch to the rear, tuck to the rear, miss-knit
	Transfer to the front, cast off to the rear		Transfer to the rear, cast off to the front
	Transfer to the front and rear, cast off to the front and rear		Cast-off, tuck to the front (post loop sinking)
	Cast-off, tuck to the rear (post loop sinking)		Transfer to front additional needle bed
	Transfer to rear additional needle bed		Transfer to rear and front additional needle bed
	Transfer to front additional needle bed, transfer to the front and rear		Transfer to front additional needle bed, knit at the front
	Transfer to rear additional needle bed to the rear, knit at the rear		

Symbols of the needle actions

Yarn Carrier If this field is touched, the "Yarn carrier" window opens up.



"Yarn carrier" window

Area	Explanation
1	Display of the current yarn carrier specification. After this specification (End character " : ") further information is available about this yarn carrier: N = Normal yarn carrier I = Intarsia yarn carrier S = Selected H = Home C = Yarn carrier is clamped and cut off ! = Yarn carrier is stopped outside the SEN area PA = Plating yarn carrier (double bow) P = Plating yarn carrier (double eyelet) < = Intarsia yarn carrier swivels to the left > = Intarsia yarn carrier swivels to the right
2	Definition of the yarn carrier (display only)
3	Yarn carrier correction with an application (selected knitting) at the left or right edge.
4	Correction for swiveled intarsia yarn carrier on the left and on the right selvedge.
5	Yarn carrier stopping position at the left or right fabric selvedge.
6	Activate or deactivate the yarn carrier plunger.

Jacquard line If this field is touched, the "Sintral editor" window opens up. The cursor is automatically positioned before the current jacquard line. The jacquard is displayed by default as compressed.



If the jacquard is unpacked, then depicted uncompressed and the jacquard line exceeds 1,200 characters, it can no longer be displayed. An error message indicates this condition.

Basic settings


Window with selection possibilities

Actions can be selected in the following windows:

- Comb actions
- Fabric take-down, auxiliary take-down and yarn carrier plunger
- Status Bar
- Sintral line


Comb actions

Various actions for the comb take-down can be selected by tapping the key (1).



"Comb actions" window

The "Select comb actions" window appears.




"Select comb actions" window

Key	Explanation
= ^ =	Comb take-down upwards, grip elastic yarn
= - =	Comb take-down in waiting position
= R =	Comb take-down reference run
= S =	Comb take-down at upper limit switch
= H =	Opening the comb hooks
= X =	Open the comb brake
= % =	Close the comb brake
= 0 =	Comb take-down at lower limit switch
Cancel	This key can be used to cancel an action as long as it is being carried out.

Actions for fabric take-down, auxiliary take-down, yarn carrier plunger

The keys (1) can be used to select actions for the fabric take-down, auxiliary take-down and the yarn carrier plungers. The possible action is always displayed on the key.




"Actions for fabric take-down, ... " window

Key	Explanation
= C =	Close Fabric Take-down
= W =	Open Fabric Take-down
Y^	De-activate all the yarn carrier plungers
Yv	Activate all the yarn carrier plungers
W+1	Close Auxiliary Take-down
W+0	Open Auxiliary Take-down

Status Bar

The elements displayed in gray in the status line can be selected. To do so, tap one of the gray fields.



"Status line" window

At some elements the gray field is divided. This means: If the front field is touched, the complete setting menu for this element appears. If the rear part of the gray field is touched, the window for changing the value appears.



Sintral line

If this field is touched, the "Sintral editor" window opens up. The cursor is automatically positioned before the current Sintral line.

4.1.20 Racking correction

To achieve the optimum delivering position even with different stitch tensions, the racking specification can be provided with a correction. Usually, the correction value is provided with a "?" when writing the knitting program.

During knitting, the machine automatically stops in the reversing position before the line with the correction specification is knitted. Now the optimum value can be entered.

Key	Function
	Call up the "Racking correction" window
	Confirm entries


Button for calling up the "Racking correction" window


Adjusting racking correction value:


1. Call up the "Racking correction" window from the "Main menu".
 2. Press the input field for the racking correction and enter the value.
- or -
- If a racking correction is to be changed, then tap the corresponding button and enter the value in the input field.
3. Confirm input.


Racking correction (Setup2)


Name	VK	Direction	VV	V+/-	Comment
VCI1	1	>	1	24	
VCI4	0	>	1	24	
VCI5	0	>	1	24	
VCI8	0	>	1	24	
VCI10	1	>	1	24	


 Take-down


 Yarn carrier

 Stitch length

 Speed

 Cycle counter


 Yarn length

 Racking

	Explanation	Value range
VCI...	Racking function	VCI1 to VCI50
VK	Racking correction by m steps (0-10)	Step width: 1/70 of the needle distance
Dir	Direction of the racking correction < - to the left > - to the right ? - not defined, will be defined on the machine	
VV	Racking speed n (1-32), without an instruction VV=32	
V+/-	V+ - OVERRACKING, in addition to the racking specification positive value: OVERRACKING in racking direction negative value: OVERRACKING in opposite to the racking direction	(n=1-24, step width: 1/8 of the needle distance)
Comment	Comment	ASCII Characters

Advanced adjustments





Racking correction (Setup1)



"Racking correction" window

Saving/loading racking corrections (Setup1)

The racking corrections are not only pattern-dependent, but also machine-dependent. As a result, these settings can be saved on the hard disk or copied back from it.

Key	Function
	Call up "Additional function keys"
	Delete all racking corrections
	Save racking corrections on hard disk
	Copy back racking corrections from hard disk to machine memory

Buttons for saving/loading racking corrections


1. Call up the "Additional function keys" in the "Racking correction" window.
2. Tap the desired button.

4.2 Advanced adjustments


This chapter contains information on:

- Switching on and off aggregates * [168]
- Setting language [171]
- Adjusting sensor mechanism * [172]
- Setting needle bed parameters [174]
- Setting machine parameters [176]
- Setting switch-off time when a power failure occurs [178]
- Copying service data [180]
- Carry out the reference run [182]
- Adjusting racking position correction VPK [185]
- Adjusting basic racking correction VGK [187]
- Correcting position of stitch cams [190]
- Adjusting needle brushes [192]
- Adjusting needle detector [193]
- Adjusting yarn carriers [193]
- Adjusting yarn carrier limiters [195]
- Adjusting yarn carrier guide [196]
- Adjusting the brushes of the central lubrication * [196]
- Adjusting intarsia yarn carrier (type 1) * [197]
- Adjusting intarsia yarn carriers (type 2) * [198]
- Shifting intarsia yarn carriers in area of carriage assembly * [199]
- Intarsia yarn carrier - Adjust stopping point (basic setting, braking value) * [199]
- Intarsia yarn carrier - check the pressure plates * [209]
- Intarsia yarn carrier - Correct stopping point (correction value) * [211]
- Float slider (holding-down jack control) [212]
- Normal yarn carrier type 2 [215]
- Plating – the different possibilities [217]
- Plating - Double bow yarn carrier [219]
- Plating - Plating yarn carrier carriage [221]
- Changing the position of the knock-over wire [224]
- Overview of all machine data [226]

4.2.1 Switching on and off aggregates *

Key	Function
	Call up the "Machine settings" window.

Keys for calling up the "Machine settings" window



"Machine settings" window

	Explanation
1	Switch on or off lighting in machine area
2	Switch fabric sensors on and off (not in the case of machines with comb take-down)
3	Switching right or left feed wheel on or off. If the feed wheel is not required, we recommend switching it off. This saves energy.
4	Setting the clamping depth of the cutting needles (only in case of a Setup1 pattern). With negative values, the cutting needles will be taken down lower. If a large NPK correction is carried out, or if several threads are processed, it may be necessary for the cutting needles to be taken-down lower to ensure reliable cut-off. Setting range: -10 to 10. Standard setting: "0". i With a Setup2 pattern: Setup2 Editor -> "Yarn carrier" menu -> "Y:Ua-b / Y:Ncc" tab

	Explanation	
5	<p>Switch fluff absorption on or off.</p> <p>The needle beds in the knitting area are vacuumed off with the fluff absorption automatically. This does not interrupt ongoing knitting process. We recommend switching on the fluff absorption permanently.</p> <p>The settings for the fluff absorption always remain saved, even when the operating system is loaded again.</p>	
	Interval	<p>Periodic switch on and off of the suction device.</p> <p>After n courses: Number of courses without suction (1 course = 2 rows)</p> <p>For n courses: Number of courses with suction</p>
	Stroke	<p>"optimised": The cleaning row is carried out only in SEN area.</p> <p>"maximum": The cleaning row is carried out over the entire needle bed.</p>









	Explanation		
6	Clean the selection systems. Some brushes are fixed on the exterior part of the needle bed. The carriage runs so far outwards that the brushes can clean the selection systems. This does not interrupt ongoing knitting process.		
	After n courses	Number of courses till the needle selection systems get cleaned (1 course = 2 rows)	
	Carriage Direction	"< >": to left and right "<": to left only	
		"optimized" The course of the carriage is being analyzed. If the carriage runs over the brushes, e.g. when it runs outwards to the clamping-cutting bed, then this course and the cleaning course will be carried out together. If the brushes are not overrun after the preset number of carriage strokes, then a cleaning course will be carried out. Only with machines with PEP function (Productivity Enhancement Pack)	
		Type	Component Type
	CMS 530 HP	621	003
		627	002
CMS 520 HP	620	002	
	628		
CMS 502 HP	637	000	
	638		
CMS 822 HP	623	002	
	632		

Further information:

- Symbols in this document [▢3]
- Central lubrication [▢27]
- Suction and cleaning row [▢26]

4.2.2 Setting language


The windows and the messages on the touch screen can be displayed in different languages.

Key	Function
	Call up the "Service" menu
	Call up the "Basic settings" menu
	Call up the "Language" window
	Tap the "Select Path" key.
	Confirm input
	Save changes and end setting process
	End setting process without saving changes
	Call up "Main menu"

Keys for setting the language

Set language:

1. Call up the "Service" menu.
2. Call up the "Basic settings" menu.
3. Call up the "Language" window.



"Language" window

4. Select a language present in the machine from the column on the left. Confirm input.
5. If the language has not been loaded yet, it must be reloaded now. The languages are, for example, saved on a floppy disk, the USB memory stick or the M1. To select the storage location, the corresponding source directory must be selected. Tap the "Select path" key. Select the new path. Save changes and end setting process.
6. Select the language in the right column. If the language is loaded, it appears in the column on the left. Repeat step 4.
7. Call up the "Main menu".

4.2.3 Adjusting sensor mechanism *








"Sensors" window

Field	Data shown
1	Stop resistance Value range: 1-32, 1=not sensitive, 32=very sensitive
2	Carriage speed after small knots
3	Activating/deactivating of horn and selection of volume in three degrees: 0=off 1=low, 2=middle, 3=loud Intermittent Tone Switching on/off an intermittent tone for the horn. Interval (sec) The time (pause) between two intervals is adjustable (max. 60 seconds).
4 *	If the comb take-down moves upward for fabric transfer, a light barrier checks whether the previously produced knitted panel has completely been ejected.
5 *	Monitoring of main take-down. If the fabric take-down roller has not turned after "n" (0-100) knitting rows, a stop motion is carried out (0=monitoring off).

Field	Data shown
6 *	Monitoring of main take-down. If the roller turns too quickly, a stop motion is carried out (e.g. when the fabric is ejected). Value range: 1-32, 1=not sensitive, 32=very sensitive
7 *	Monitoring of auxiliary take-down. If the auxiliary take-down has not turned after "n" (0-100) knitting rows, a stop motion is carried out (0=monitoring off).

* does not apply in case of machines with belt take-down

Key	Function
	Call up the "Machine settings" window.
	Call up "Additional function keys"
	Call up "Sensors" window
	Confirm input
	Call up "Main menu"

Keys for adjusting the sensor mechanism

Adjusting sensor mechanism:


1. Call up the "Machine settings" window.
2. Call up "Additional function keys".
3. Call up the "Sensors" window.
4. Enter the value on the appropriate line.
5. Confirm input.
6. Call up "Main menu".

Further information:

- Stop resistance [▢32]
- Adjusting carriage speed [▢114]
- Symbols in this document [▢3]






4.2.4 Setting needle bed parameters

The needle bed parameters are used to make the needle-bed-specific settings. They serve for the fine adjustment of the needle beds. The needle bed parameters always remain saved, even when the operating system is read in again.



"Needle bed parameters" window

Field	Data shown
1	Racking ground correction (VGK)
2	Racking position correction (VPK)
3	Shock stop motion for the front and rear needle beds and additional needle bed. Value range: 1-32, 1=not sensitive, 32=very sensitive

Key	Function
	Confirm input
	Call up the "Service" menu
	Call up the "Basic settings" menu
	Open the "Needle bed parameters" window
	Call up "Main menu"

Keys for setting the needle bed parameters

Setting needle bed parameters:


1. Call up "Main menu".
2. Call up the "Service" menu.
3. Call up "Basic Settings" menu.
4. Open the "Needle bed parameters" window.
5. Enter the value on the appropriate line.
6. Confirm input.
7. Call up the "Main menu".
8. Save the change in the machine adjustments on the USB memory stick.

Further information:


- Adjusting basic racking correction VGK [187]
- Adjusting racking position correction VPK [185]
- Shock stop [32]
- Saving all machine data on the USB-Memory-Stick [15]
- Overview of all machine data [226]






4.2.5 Setting machine parameters

The machine parameters are used to make the machine-specific settings. They serve for the fine adjustment of the machine. The machine parameters always remain saved, even when the operating system is loaded again.



"Machine parameters" window

Field	Data shown
1	Releasing fabric take-down when switching off the main switch. With a delicate fabric no stitch elongations occur then.
2	Following a machine stop the machine runs for several rows at reduced speed. Value range: 0-6, 0=off
3	Automatic deactivation of lighting after a certain time. Duty cycle: 10 minutes (standard), value range: 0...60 minutes Recommendation: LED lamp: 0 minutes, fluorescent lamp 10 minutes
4	Speed outside the SEN area (MSECOS) Standard: 1.2 m/sec (maximal speed)
5	Maximum carriage speed with open cover hoods if the engaging rod is held in position 3 (production). Value range in input field "MSECCO": 0.00 to 0.20 m/s, standard: 0.05, step width: 0.05, 0.00=carriage does not move.
6	carriage speed, if key  is active. Reduction of normal speed to percentage specification "n". Default: 70 %

Key	Function
	Confirm input
	Call up the "Service" menu
	Call up the "Basic settings" menu
	Call up "Machine parameters" window
	Call up "Main menu"

Keys for setting the machine parameters

Set machine parameters:


1. Call up "Main menu".
2. Call up the "Service" menu.
3. Call up "Basic Settings" menu.
4. Call up the "Machine parameters" window.
5. Enter the value on the appropriate line.
6. Confirm input.
7. Call up the "Main menu".
8. Save the change in the machine adjustments on the USB memory stick.

Further information:


- Engaging rod [▢43]
- Saving all machine data on the USB-Memory-Stick [▢15]

4.2.6 Setting switch-off time when a power failure occurs

The machine is immediately stopped when a power failure (longer than 45 milliseconds) occurs. The knitting program, operating system and the machine-specific data are not lost. The battery card (with the accumulators) ensures this. A pictograph indicating the power failure appears on the touch screen.










"Power failure" pictograph

	DANGER
	<p>Life-threatening high voltage!</p> <p>Electrical shock may cause death or serious injuries.</p> <p>→ Even in the case of power failure, do not work on the electrical system of the machine without interrupting the power supply .</p>

→ Set machine main switch to "0".


- | | |
|-----------------------|---|
| Longer power failure | <p>If the power failure lasts more than 30 seconds (standard setting), the computer of the knitting machine is automatically shut down. The time until the computer shuts down can be set from 2 to 180 seconds.</p> <p>If you are sure that the power failure has been in effect for a longer period of time, you can switch off the main switch with "Switch off main switch".</p> <p>The set time always remain saved, even when the operating system is loaded again.</p> |
| Shorter power failure | <p>If the power supply is restored within the set time, confirm the power failure message with the "Confirm message" key. To continue knitting, start the machine with the engaging rod.</p> |
| Conditions | <p>If the battery voltage is too low ("Battery voltage low" message appears), it is not possible to extend the power failure time.</p> <p>If a STIXX device is used with the machine, a check is automatically performed to determine which device it is.</p> <ul style="list-style-type: none"> ■ The extension of the power failure time is possible with an ASCON device and a new STIXX device (ID 236 275). ■ This is not possible with an older device, as the STIXX correction values cannot be saved and are therefore lost during a power failure. The power failure time is automatically reduced to 2 seconds. If a higher time is set, a message appears stating that this is not possible. |

Key	Function
	Confirm message
	Switch off main switch
	Call up the "Service" menu
	Call up the "Basic settings" menu
	Call up "Machine parameters" window
	Confirm input
	Call up "Main menu"

Keys for adjusting the power failure time

Set power failure time:

1. Call up the "Service" menu from the "Main menu".
2. Call up the "Machine parameters" window from the "Basic settings" menu.




The screenshot shows the 'Machine parameters' window with the following settings:

- Correction take-down (WAK): 31
- Comb adj. position (ACV): 0
- Release fabric take-down when switching off:
- Slow rows after machine stop: 0
- Extension of power failure (sec): 30
- Corr.comb take-down (WKK): 31


3. Enter the desired time.
4. Confirm input.
5. Call up "Main menu".

4.2.7 Copying service data




With this menu the service data can be copied on a data carrier.



"Copy service data" window

Label	Explanation
Copy Logfiles	If the machine computer has serious problems, e.g. it does not react to any inputs or the program crashes any longer, the cause is very important for Stoll. The computer saves the data up to the fault internally in so-called "Logfiles". These files can be saved and sent to the Stoll helpline so that Stoll can carry out an exact error diagnostics.
Copy Dongle	The machine settings do not only contain the machine data, but also the machine options, the machine configuration, the report and other internal control information. It is important to back up the data, e.g. when the hard disk is replaced.
Copy Print	For the Stoll technician only
Copy Report	The operating data are saved with the STOLL machine number.
Copy Mc	<p>The machine data include the machine-specific settings (correction values). The data will be saved in a zip-file.</p> <p>When delivering the knitting machine, the machine data was printed out and put on the right control cabinet.</p>  <p>Machine data sheet at the right control cabinet</p>
Select language with next startup	With next switching on of the machine, the language selection appears. The setting is reset after switching on.

Keys in the "Copy service data" window

Key	Function
	Call up the "Service" menu
	Call up "Copy service data" window
	Call up "Main menu"

Keys for copying the service data

Copy service data:

1. Call up the "Service" menu from the "Main menu".
2. Call up the "Copy service data" window.
3. Select the desired data carrier e.g. . USB memory stick (Drive F:).
4. Tap the desired button.
 - ▷ The data are saved.
5. Call up "Main menu".

Further information:











- Calling up report and shift counters [21]
- Saving all machine data on the USB-Memory-Stick [15]
- Overview of all machine data [226]

4.2.8 Carry out the reference run

Following all repair and conversion work on the carriage assembly or on the needle bed, a reference run must be carried out.

The reference run is carried out with the following steps:

- Calling up and noting the machine data
- Carrying out the reference run
- Calling up and correcting the machine data
- Loading the knitting program and determining the racking reference data

Key	Function
	Call up the "Service" menu
	Call up the "Basic settings" menu
	Returning to the previous window
	Call up "Machine parameters" window
	Open the "Needle bed parameters" window
	Call up "NPK values" window
	Call up "Needle selection" window
	Call up "Reference runs" window
	Call up "Main menu"
	Call up "Machine start" window

Keys for carrying out a reference run

Call up and note machine data

1. Call up the "Service" menu.
2. Call up "Basic Settings" menu.
3. Call up the "Machine parameters" window.
4. Compare the displayed values with the values on the machine data sheet. If necessary, correct the values on the machine data sheet (see the "Copy Mc" description [180]).
5. Switch back to the previous window.
6. Call up the "Needle bed parameters" window.
7. Compare the displayed values with the values on the machine data sheet. If necessary, correct the values on the machine data sheet.
8. Switch back to the previous window.
9. Call up the "NPK values" window.
10. Compare the displayed values with the values on the machine data sheet. If necessary, correct the values on the machine data sheet.
11. Switch back to the previous window.
12. Call up the "Needle selection" window.
13. Compare the displayed values with the values on the machine data sheet. If necessary, correct the values on the machine data sheet.
14. Call up "Main menu".

Carry out the reference run

1. If the racking device is not in the home position, cast-off the stitches of a needle bed.
 2. Call up the "Service" menu.
 3. Call up the "Reference runs" window.
 4. The reference data is determined at the left or right end of the needle bed. If the carriage is located in the left half of the needle bed, tap the "SR!<" key.
- or -
- If the carriage is located in the right half of the needle bed, tap the "SR!>" key.



Reference run with older machines (before August 2013):
The reference data is determined at the center of the needle bed.

The carriage moves automatically in both directions

During the reference run, the carriage can move independently into both directions.

The carriage stops automatically as soon as the reference data is determined. The engaging rod falls down.

5. Start the machine with the engaging rod.
 - ▷ The carriage assembly carries out a reference run and stops as soon as it has determined the reference data. The engaging rod falls down.
6. The message "Reference run complete" is displayed on the touch screen.

Calling up and correcting
machine data

7. The reference run is complete, the machine is ready to knit.
The carriage is positioned at the correct position for you to be able to start the production.
8. Switch back to the previous window.
1. Call up the "Basic settings" menu.
2. Call up the "Machine parameters" window.
3. Compare the displayed values with the target values on the machine data sheet and if necessary correct the values in the window "Machine parameter" and confirm them.
4. Switch back to the previous window.
5. Call up the "Needle bed parameters" window.
6. Compare the displayed values with the values on the machine data sheet. If necessary, correct the values on the machine data sheet.
7. Switch back to the previous window.
8. Call up the "NPK values" window.
9. Compare the displayed values with the target values on the machine data sheet. If necessary, correct the values in the "NPK values" window and confirm them.
10. Switch back to the previous window.
11. Call up the "Needle selection" window.
12. Compare the displayed values with the target values on the machine data sheet. If necessary, correct the values in the "needle selection" window and confirm them.
13. Call up the "Main menu".

Load knitting program and
determine racking reference
data

1. Load the knitting program.
2. Call up the "Machine start" window.
3. Tap on the key "SP from line 1".
4. Start the machine with the engaging rod.
 - ▷ The carriage assembly moves slowly and stops in the right reversing position.
5. Wait until the "Racking finished" Message appears on the touch screen.
6. To switch on the needle selection, tap the needle selection "On" key in the "Machine start" window.
- ▶ The reference run is complete, the machine is ready to knit.





Further information:

- Copying service data [▢180]
- Copying service data [▢180]

4.2.9 Adjusting racking position correction VPK

The fine adjustment of the transfer racking is carried out by means of the VPK value. With the "Racking position correction (VPK)" the rear needle bed is aligned exactly relative to the front needle bed.


The VPK value always remains saved, even if the operating system is imported again.

Key	Function
	Call up the "Service" menu
	Call up the "Service Racking" window
	Confirm input
	Call up "Main menu"

Keys for setting VPK value

Adjusting VPK:

1. Program an empty row with transfer racking and fix the knitting specification [4].
2. Push up two opposing needles in the center of the needle bed.
3. Check whether the needle hook of the front needle dips into the pelerine spring of the rear needle.
4. If this is not the case: Push back needles and correct racking device.
5. Call up "Main menu".
6. Call up the "Service" menu.
7. Call up the "Service Racking" window.



"Service Racking" window

8. Enter the value in the "VPK" line using the linear regulator.

-1...-8	Correction to the left (1 step = 0.18 – 0.25 mm, according to the machine gauge)
+1...+8	Correction to the right (1 step = 0.18 – 0.25 mm, according to the machine gauge)

9. Confirm input.

▷ The needle bed moves lightly to the left or right.

10. Repeat steps 2 to 9 until the needle hook of the front needle dips into the pelerine spring of the rear needle.

11. The NPK values are automatically saved in the data specific to the machine (dongle data).

▶ The setting process is complete.



If you want, you can save VPK-value additionally:

→ on a USB memory stick [▢15]

→ on a network drive (button "Copy Dongle") [▢180]

■ Helpful knitting rows [▢4]

■ Copying service data [▢180]





■ Saving all machine data on the USB-Memory-Stick [▢15]

4.2.10 Adjusting basic racking correction VGK

The position of the rear needle bed relative to the front needle bed is set with the VGK value (factory setting).

If part of the racking device is replaced, e.g. the racking motor or the racking belt, the VGK value has to be set anew. During installation, make sure that the front and rear needle beds are opposite each other.

The VGK value always remains saved, even if the operating system is imported again.


Key	Function
	Call up the "Service" menu
	Call up the "Service Racking" window
	Confirm input
	Call up "Main menu"

Keys for setting VGK value

Setting VGK:

✓ Cast-off the stitches on both needle beds.

1. Call up "Main menu".
2. Call up the "Service" menu.
3. Call up the "Service Racking" window.



"Service Racking" window

4. Enter and confirm the value "0" in the line "VPK".

5. Tap the "Racking adjusting run" key. A message appears, answer this with "Yes".
 - ▷ The needle bed moves to the left and right. The racking will be synchronized.
6. Tap the "Reference run V>REF" key. A message appears, answer this with "Yes".
 - ▷ The needle bed moves to the left and right. The racking is carrying out a reference run.
7. Program an empty row with half racking and fix the knitting specification [□4].
8. Push up several opposing needles at various positions of the needle bed (left, center, right) on both needle beds until the needle hooks touch each other.
9. Check whether the needle hooks of the front and rear needle bed are exactly in a line.
10. If this is not the case: Push back needles somewhat so that they do not touch each other anymore. In the "VGK" line, enter the value using the linear regulator.

-1...-150	Correction to the left (1 step = 0.01 mm)
+1...+150	Correction to the right (1 step = 0.01 mm)

11. Confirm input.
 - ▷ The needle bed moves lightly to the left or right.
12. Check whether the needle hooks of the front and rear needle bed are exactly in a line.
13. If this is not the case, repeat steps 10 to 12 until the needle hooks of the front and rear needle beds are exactly positioned in one line.
14. The VGK value is automatically saved in the data specific to the machine (dongle data).
15. Adjust VPK value [□185].
(To be able to determine the VGK value you had to set the VPK value to "0" (in step 4). After having determined the VGK value you must set the VPK value again.)
 - ▶ The setting process is complete.



If you want, you can save the VGK-value additionally:

→ on a USB memory stick [□15]

→ on a network drive (button "Copy Dongle") [□180]

**Wrong selection - individual needles miss-knit**

If a wrong selection occurs, then the synchronisation "Impulse sensor – control – selection system" is not optimal anymore. This has been caused by the big difference between the old and new VGK values.

→ The test "Needle selection displacement" must be carried out for re-establishing the synchronisation [▢71].

Further information:

- Helpful knitting rows [▢4]
- Copying service data [▢180]
- Saving all machine data on the USB-Memory-Stick [▢15]
- Needle selection displacement [▢71]
- Adjusting racking position correction VPK [▢185]

4.2.11 Correcting position of stitch cams

Each stitch cam can be corrected for each carriage direction


- for knitting
- for knitting with split-stitch technique

Reduce stitch tension: Value without sign or with "+" sign

Increase stitch tension: Value with "-" sign








The second stitch cam of a system is always corrected, as only it is active.

The stitch cams are numbered consecutively from left to right, regardless of the carriage direction.



	Meaning
System 1 - n	Number of knitting system counted from left to right
<<	Carriage direction to the left
>>	Carriage direction to the right
n.n	Correction value for knitting
\$ n.n	Correction value for knitting with split-stitch technique

Meaning of displays in NPK values window

Key	Function
	Call up the "Service" menu
	Call up the "Basic settings" menu
	Call up "NPK values" window
	Reduce current value by one step
	Increase current value by one step
	End the setting process and save the changed values.
	Call up "Main menu"

Keys for correction of stitch cam position (NPK value)

Correcting position of stitch cams:

1. Call up "Main menu".
2. Call up the "Service" menu.
3. Call up the "Basic settings" menu.
4. Call up the "NPK values" window.
5. Change the NPK values for knitting and for knitting with split-stitch stitch and confirm the changes.
 - ▷ The values are automatically saved in the data specific to the machine (dongle data).
 - ▶ The setting process is complete.



If you want, you can additionally save the values:

- on a USB memory stick [15]
- on a network drive (button "Copy Dongle") [180]


Further information:

- Copying service data [180]
- Saving all machine data on the USB-Memory-Stick [15]

4.2.12 Adjusting needle brushes

The needle brushes must be adjusted when errors occur during stitch formation, e.g. drop stitches.


The needle brushes open the needle latches for laying in the thread. They are swivel-mounted so, that they are always inclined in the direction of travel of the carriage assembly.



Inclination of needle brushes

The needle brushes are correctly adjusted when

- the brushes project an equal distance over both sides of the holder. The markings on the brush are visible on both sides.
- the canted surfaces (3) opposite each other
- the brushes do not touch the needle hooks of the fully raised needles (RR). The distance (4) is to be 0.5 mm to 1 mm.

Key	Function
	Call up "Manual interventions" window


Key for calling up "Manual interventions" window

Adjusting needle brushes:

1. Release hexagon nut (2).
2. Adjust needle brush at screw (1).
3. Retighten hexagon nut (2).
4. Adjust needle brushes on all systems.
5. Call up "Manual interventions" window.
6. Move carriage assembly at low speed. To do this, press "Move stepwise" button and check the setting of the needle brushes.

4.2.14 Adjusting needle detector

The needle detector is correctly adjusted if:



Adjusting the needle detector

- it is near the holding-down jacks of the rear needle bed, however does not tap them
- the lower end of the needle detector is at the level of the needle hooks

	NOTICE
<p>Damage to the needle detector!</p> <p>If several yarn carriers are stopped at the same place, the needle detector will be damaged, as the yarn carriers cannot avoid the needle detector.</p> <p>→ Always stagger yarn carriers.</p>	

→ Staggering yarn carriers.

Further information:

- Staggering yarn carriers [129]

4.2.15 Adjusting yarn carriers

The yarn carriers are correctly adjusted if


- the distance between the cam center of the knitting system and the yarn carrier in each system is identical in both carriage directions
- the thread is laid on the open latch at exactly the same point by each yarn carrier for both selvedge needles
- the yarn carrier tips move exactly between the needle beds in the needle cross and the distance between yarn carrier tips and the closed needle latch is 0.5 mm to 1 mm
- the yarn carrier in the clamping and cutting area does not press the cutting needle located in the working position
- the yarn carriers of the track 1 and 8 are also set 0.5 mm higher so that they do not touch the limiters (3)

Key	Function
	Call up "Manual interventions" window

Key for calling up "Manual interventions" window



Adjusting yarn carriers:

1. Remove needle brushes by loosening screws (1).



Screws of needle brushes

2. Park the carriage assembly in needle space.



Adjusting yarn carriers

3. Adjust yarn carriers if necessary. When doing so, the carriage assembly must be stopped in the needle area.
4. Call up "Manual interventions" window.
5. Move carriage assembly at low speed. To do this, press "Move stepwise" button and check adjustment of yarn carriers.


Further information:

- Replacing yarn carrier [▢39]

4.2.16 Adjusting yarn carrier limiters

The yarn carrier limiters are correctly adjusted if


- each yarn carrier is positioned after its clamping point and before the following clamping point.
- the yarn carrier limiter is about 8 mm away from its yarn carrier (CMS 830 C, CMS 520 C: 15 mm)



Adjusting yarn carrier limiters

Adjusting yarn carrier limiters:

1. Position the yarn carrier (1) on the track 1 exactly between the clamping point 1 and 2.
2. Loosen the screws (2) on the yarn carrier limiter.
3. Displace the yarn carrier limiter until it is 8 mm away from the yarn carrier (CMS 830 C, CMS 520 C: 15 mm).
At this distance, the edge of the yarn carrier carriage and the start of the bevel at the yarn carrier limiter are located at the same height.
4. Retighten the screws (2).
5. Repeat this setting process for all the yarn carriers.




Staggering of yarn carrier limiters

4.2.17 Adjusting yarn carrier guide

The yarn carrier guide must be adjusted if the yarn carrier can be lifted from the yarn carrier rail or a yarn carrier plunger is not put out of action.

Adjusting yarn carrier guide:

1. To check whether the yarn carrier can be lifted from the yarn carrier rail, take the left and right sides of the yarn carrier housing in both hands and move the yarn carrier housing upward and downward.




Adjusting yarn carrier guide

2. If necessary push the setting key inwards with the adjusting key from the accessories till the yarn carrier cannot be raised erect any more.
3. Turn the setting key back by one-eighth of a turn.

4.2.18 Adjusting the brushes of the central lubrication *

The brushes have been adjusted correctly if they touch the working butts lightly.



Brushes of the central lubrication

Adjusting the brushes of the central lubrication:

1. Release hexagon nut (2).
2. Adjust brushes on hexagon nut (1).
3. Retighten hexagon nut (2).
4. Adjust all brushes.

Further information:

- Symbols in this document [□3]


4.2.19 Adjusting intarsia yarn carrier (type 1) *

The yarn carriers are correctly adjusted if

- an unswiveled yarn carrier passes by a swiveled yarn carrier
- the distance between the cam center of the knitting system and the yarn carrier in each system is identical in both carriage directions
- the thread is laid on the open latch at exactly the same point by each yarn carrier for both selvedge needles
- the yarn carrier tips move exactly between the needle beds in the needle cross and the distance between yarn carrier tips and the closed needle latch is 0.5 mm to 1 mm
- the yarn carriers of the track 1 and 8 are also set 0.5 mm higher so that they do not touch the limiters (3)


Adjusting intarsia yarn carriers:

1. Remove needle brushes by loosening screws (1).



Screws of needle brushes

2. Park the carriage assembly in needle space.



Adjusting the intarsia yarn carriers

3. To adjust the height of the yarn carrier, loosen the screw (1).
4. Adjust the height of the yarn carrier and retighten the screw (1).
5. To adjust the position of the yarn carrier head relative to the needle beds, loosen the screw (2).
6. Adjust the position of the yarn carrier head relative to the needle beds, retighten the screw (2) and coat it with a screw locking compound (e.g. Loctite 221).

Further information:

- Symbols in this document [▢3]
- Intarsia yarn carrier * [▢23]
- Mount intarsia yarn carrier * [▢40]


4.2.20 Adjusting intarsia yarn carriers (type 2) *

The yarn carriers are correctly adjusted if

- an unswiveled yarn carrier passes by a swiveled yarn carrier
- the distance between the cam center of the knitting system and the yarn carrier in each system is identical in both carriage directions
- the thread is laid on the open latch at exactly the same point by each yarn carrier for both selvedge needles
- the yarn carrier tips move exactly between the needle beds in the needle cross and the distance between yarn carrier tips and the closed needle latch is 0.5 mm to 1 mm
- the yarn carriers of the track 1 and 8 are also set 0.5 mm higher so that they do not touch the limiters (4)


Adjusting intarsia yarn carriers:

1. Remove needle brushes by loosening screws (1).



Screws of needle brushes

2. Park the carriage assembly in needle space.
3. To adjust the height of the yarn carrier, loosen the screw (2).



Adjusting the intarsia yarn carriers

4. Adjust the height of the yarn carrier and retighten the screw (2).
5. In order to laterally adjust the position of the yarn carrier tip, bend the yarn carrier bow carefully (without using force) with the adjusting part (3).


Further information:

- Symbols in this document [▢3]
- Intarsia yarn carrier * [▢23]
- Mount intarsia yarn carrier * [▢40]

4.2.21 Shifting intarsia yarn carriers in area of carriage assembly *

Intarsia yarn carriers located in the area of the carriage assembly cannot be shifted by hand. They are shifted with the shifting device from the accessories.

Shift yarn carriers in area of carriage assembly:



Shifting device

→ Press the lifters inward with the shifting device from the accessories and shift one or more yarn carriers out of the area of the carriage assembly.


Further information:

- Symbols in this document [□3]

4.2.22 Intarsia yarn carrier - Adjust stopping point (basic setting, braking value) *

With an intarsia yarn carrier it is important that it is stopped exactly above the last needle of its knitting area. Otherwise the following error possibilities will be:

- During the knitting it may cause erroneous switchings as the control calculated the yarn carrier on another position than it is actually located on. Consequence: The yarn carrier is not swivelled or it is not taken along.
- The yarn can be knitted-in and this way an uncleaned colour edge would be the result.



Stopping position (on the left: wrong, on the right: correct)

If the intarsia yarn carrier does not stop exactly above the last needle, you have to correct the braking value and **not** the correction value.

i

Difference: braking value - correction value

Braking value: mechanical adjustment of the yarn carrier
Correction value: knitting-technical and pattern related correction of the yarn carrier

An adjusting program is available for controlling the stopping positions. With this program you can easily check and adjust the braking values of the intarsia yarn carrier.

When creating the intarsia pattern on the M1plus (starting with version 5.3) you specify that the adjusting program is to be integrated in the pattern.

On the knitting machine you run the adjusting program before or also during the production. An embroidery stitch line is knitted with all the Intarsia yarn carriers used in the pattern for you to be able to check the correct stopping position quickly and easily.

You can correct the stopping position of the yarn carrier changing the braking values for the yarn carrier.

Further information:

- Symbols in this document [3]

Which yarn carriers are located on the machine.

Carry out this section:

- with machines without clamping and cutting bed
- if the clamping and cutting bed is switched off









Only with these machines you can change the yarn carrier equipment.

With all the other machines there is predefined a permanent yarn carrier equipment that cannot be changed. The functions "Move", "Delete", "Activate" are deactivated (grayed out).
-> Skip this section. It continues on Page [204].

Check the yarn carrier equipment before the production starts. It is possible that the number of the yarn carriers has changed:

- several yarn carriers were removed for the previous pattern
- more (or less) yarn carriers are needed for the new pattern

The computer has to know about the new yarn carrier equipment to be able to allocate its specific braking value to every yarn carrier and also to a new yarn carrier.

Key	Function
	Call up the "Yarn carrier" window
	Call up the "Yarn carrier braking values" window
	Save changes and end setting process
	Call up "Additional function keys"
	Reset the default setting of yarn carrier arrangement
	Call up "Main menu"

Keys for calling up the yarn carrier braking values


Correcting the stopping position of the yarn carrier:

- ✓ The knitting program must not be started (the "SP from line 1" key in the "Machine start " window must not be activated)

1. Call up the "Yarn carrier" window.

2. Call up the "Yarn carrier braking values" window.

▷ The last yarn carrier equipment saved is displayed.



"Yarn carrier braking values window"


<table border="1" style="margin: auto;"> <tr><td style="text-align: center;">2.1</td></tr> <tr><td style="text-align: center;">YB: 0 0</td></tr> </table>	2.1	YB: 0 0	Yarn carrier present.
2.1			
YB: 0 0			
<table border="1" style="margin: auto;"> <tr><td style="text-align: center;">7.3</td></tr> <tr><td style="text-align: center;">YB: 0 0</td></tr> </table>	7.3	YB: 0 0	The yarn carrier is not present. It has been deleted manually.
7.3			
YB: 0 0			
<ul style="list-style-type: none"> ◆ A maximum of 4 yarn carriers can be located on each yarn carrier track. The counting is carried out from the left to the right: n.1, n.2, n.3, n.4. (This is called a physical numbering.) ◆ If a yarn carrier is present, then its braking values are displayed. ◆ In the middle of the window you can see a vertical separating line. at the left of the separating line: The yarn carriers are positioned on the left machine side at the right of the separating line: The yarn carriers are positioned on the right machine side 			

3. Check the displayed yarn carrier equipment.

4. If necessary adapt the yarn carrier equipment to the new pattern (yarn carrier home position).

5. Click the required yarn carrier.

▷ The setting window appears.



Moving yarn carriers	to the Left	Only possible if no other yarn carrier is located on the left hand-side.
	to the Right	Only possible if no other yarn carrier is located on the right hand-side.
Delete yarn carrier	Only the rightmost yarn carrier can be deleted. Delete from the right to the left. i : Delete the yarn carrier only if you really are going to remove it from the machine. Its braking values are deleted. If you reassembly the yarn carrier, then the braking values must be redetermined.	
Activate yarn carrier	Reactivate a deleted yarn carrier. Activate from the left to the right. If two or more yarn carriers are to be activated, then activate the yarn carrier furthest to the left first.	
i : If an action is not possible, the key is inactive (gray)		

6. Save changes and end setting process for this yarn carrier.

7. Repeat the steps 5 to 6 until all the yarn carriers are located on their correct positions (yarn carrier home position).

8. Call up "Main menu".

Further information:

- Checking the braking values with the adjusting program [□204]

Advanced adjustments

Checking the braking values with the adjusting program

An adjusting program is available for controlling the stopping positions. An ornamental stitch line is knitted with all the Intarsia yarn carriers used in the pattern for you to be able to check the correct stopping position quickly and easily.



- | | |
|-----------------------------|--|
| 1 Adjustment program Part 1 | 3 Embroidery stitch lines of the intarsia yarn carriers (vertical line, one needle wide) |
| 2 Adjustment program Part 2 | 4 Pattern |










When creating the intarsia pattern on the M1plus (starting with version 5.3 or higher) you specify that the adjusting program is to be integrated in the pattern. For this purpose activate the "Generate adjusting program" check box ("Pattern parameters" -> "Configuration" -> "Intarsia tab" -> "Valuate braking values for Intarsia yarn carriers" section).

On the knitting machine you run the adjusting program before or also during the production.

What is the structure of the adjustment program?

- All the intarsia yarn carriers, which are used in the pattern and swivel, are included in the adjustment program.
- Depending on the number of yarn carriers and the fabric width, the intarsia yarn carriers will be distributed on one or more partial programs.
- Program start: Set the cycle counter "RS39" ("RS18" with Setup1) to "1" After the program start the "RS39" is automatically set to the value "99" to ensure that a sufficient number of knitting rows is knitted for the adjustment of the yarn carriers.
- Proceed to the next partial program: with the "ctrl W" key
- Program end: set with the "ctrl W" key or the cycle counter "RS39" to "0".


Check the braking values

Key	Function
	Call up "Machine start" window
	Call up the "Cycle counters & counters" window
	Call up the "Yarn carrier" window
	Call up the "Yarn carrier braking values" window
	Save changes and end setting process
	End setting process without saving changes return to the "Yarn carrier braking values" window
	Call up "Additional function keys"
	Reset the braking values to standard values (with the machine stopped only)
	<ul style="list-style-type: none"> ◆ proceed to the next partial program. ◆ Exit the adjustment program.

Keys to check the braking values

Checking the braking values:

- ✓ If there are yarn carrier correction values entered in the knitting program, they have to be set to "0" temporarily. The correction value affects the stopping time and falsifies the checking of the braking value. (Note the correction values so that they can be entered again later on).
1. The knitting program is loaded and started (the "SP from line 1" key in the "Machine start " window)
 2. Call up the "Cycle counters & counters" window, and set "RS 39" to "1" (Start adjustment program) (Setup1: RS18=1).
 - ▷ The adjustment program is called up.
 3. Start the machine with the engaging rod.
 - ▷ The first part of the adjustment program is started.
 4. Knit some rows.
 5. Check the stopping position of the different yarn carriers.



- 1 Wrong stopping position
- 2 Correct stopping position (left color field edge)
The yarn is located vertically, at the left of the needle center.
- 3 Correct stopping position (right color field edge)
The yarn is located vertically, at the right of the needle center.

- 6. If the stopping position is wrong correct the braking value for the yarn carrier.
- 7. Call up the "Yarn carrier" window.
- 8. Call up the "Yarn carrier braking values" window.

YC braking values				STOLL THE RIGHT WAY TO KNIT	
8	8.1 YB: 0 0	8.2 YB: 0 0	8.3 YB: 0 0	8.4 YB: 0 0	
7	7.1 YB: 0 0	7.2 YB: 0 0	7.3 YB: 0 0	7.4 YB: 0 0	
6	6.1 YB: 0 0	6.2 YB: 0 0	Y-6A N A YB: 0 0	6.4 YB: 0 0	
5	5.1 YB: -4 -6	5.2 YB: 9 9	Y-5A N A YB: 0 0	5.4 YB: 0 0	
4	4.1 YB: 9 9	Y-4A N A YB: 9 9	Y-4B N A YB: 0 0	4.4 YB: 0 0	
3	3.1 YB: 0 0	3.2 YB: 0 0	Y-3A N A YB: 2 3	3.4 YB: 0 0	
2	2.1 YB: 0 0	Y-2A N A YB: 0 0	Y-2B N A YB: 0 0	2.4 YB: 0 0	
1	1.1 YB: 0 0	Y-1A N A YB: 0 0	1.3 YB: 0 0	1.4 YB: 0 0	

"Yarn carrier braking values" window

Y-3A N A
YB: 2 3

Yarn carrier designation (Y-3A)
(Sintral numbering)

Display of the yarn carrier type (N)

Display of the yarn type (A)


Braking value (YB)
left: 2, right: 3

2.1
YB: 0 0

The yarn carrier is present (is not used in the current knitting program)

9. Tap on the corresponding yarn carrier.

▷ The setting window appears.



Ba: braking value
left
Bb: braking value
right


Value range: -9...0...9.
Step width: 1=1/32 inch=0.8 mm
Default: 0

i: In case of large deviations from the default value appears a note prompting you to check the yarn carrier.

10. Enter the braking value (Ba, Bb).

-1...-9: if the yarn carrier is stopped to late (after the needle)

+1...+9: if the yarn carrier is stopped to early (before the needle)



11. Save changes and end setting process for this yarn carrier.

12. If the stopping position of further yarn carriers is wrong repeat the steps 9 to 11.

13. Knit some rows.

14. Check the stopping positions. If necessary, repeat the steps 9 to 11.

15. Repeat several times the checking of both swivel directions of the intarsia yarn carrier.

16. If there are further yarn carriers to be checked, then proceed to the next partial program. (Additional function keys ->"ctrl W" key).

17. Repeat the steps 9 to 15.

18. If all of the yarn carriers are checked, tap the "ctrl W" key. It will be proceeded to the next partial program automatically.

- or -

→ If all the partial programs are processed, the adjustment program is automatically exited and the production is started.

▶ The checking is completed.

i

If you have set the yarn carrier correction values to "0", then enter the noted values in the knitting program.

i

→ If some braking values are modified, then the data are automatically saved in the data specific to the machine (dongle data).

→ The braking values do not depend on the patterns, but on the machine. These data are therefore not deleted when a new knitting program is loaded.

→ The braking values always remain saved, even when the operating system is loaded again.

→ If the braking values are no longer required, they have to be reset to "0" manually.

→ Check the braking values from time to time as the conditions may change.

→ With tandem operation: Separate braking values cannot be entered for the yarn carriers in the right carriage.

Possible reasons for the wrong stopping position

- Different lubrication
- Different cleaning of the yarn carrier rails
- Temperature variation during the production
- Adjusting yarn carrier guide
- Pressure plates are worn
- The yarn carrier is bent (very different braking values for the left and the right-hand side)


Further information:

- Adjusting yarn carrier guide [▢196]
- Intarsia yarn carrier - check the pressure plates * [▢209]

4.2.23 Intarsia yarn carrier - check the pressure plates *


Turning over or replacing the small pressure plates (intarsia yarn carrier type 1)

1. Dismantle yarn carrier.



Dismantling of small pressure plate

2. Loosen but do not remove the screws (1).
3. Lift the clamping lever (2) out of the locating screw (3) and remove it. When doing this, make sure that the spring pin (5) remains in the housing (4).
4. Check whether the thickness designation 2.04 or 2.06 is visible on the built-in pressure plate.
5. Remove the pressure plate from the clamping lever.

NOTICE	
	<p>Complicated adjustment work is required when replacing the pressure plates!</p> <p>If the various thicknesses and positions of the pressure plates are interchanged, complicated adjustment work is required to set the stopping point of the yarn carrier correctly.</p> <p>→ Do not interchange the various thicknesses and positions of the pressure plates!</p>

6. If the marking 2.04 or 2.06 was visible on the built-in pressure plate, turn over the pressure plate and reinsert it.
- or -
- If the marking 2.04 or 2.06 was not visible on the built-in pressure plate, insert a new pressure plate of the same thickness with the marking facing upward.
7. Press the spring pin (5) into the spring part (4) and insert the clamping lever (2).
 8. Tighten the screws (1).
 9. Make sure that the lifter (6) moves smoothly.


Further information:

- Replacing yarn carrier [▢39]
- Symbols in this document [▢3]

Advanced adjustments

Turning over or replacing the small pressure plates (intarsia yarn carrier type 2)

1. Dismantle yarn carrier.



Dismantling of small pressure plate

2. Remove the screws (1).
3. Remove the parts (2). Make sure that the springs (3) are not lost.
4. Lift the clamping lever (4) out of the locating pin and remove it downwards. Make sure that the spring pin (5) remains in the housing.
5. Check whether the thickness designation 2, 4 or 6 is visible on the built-in small pressure plates.
6. Remove the pressure plate from the clamping lever.



NOTICE

Complicated adjustment work is required when replacing the pressure plates!

If the various thicknesses and positions of the pressure plates are interchanged, complicated adjustment work is required to set the stopping point of the yarn carrier correctly.



→ Do not interchange the various thicknesses and positions of the pressure plates!

7. If the marking 2, 4 or 6 is visible on the built-in small pressure plate, turn over the pressure plate and reinsert it.
- or -
- If the marking is not visible, the pressure plate is already turned over. Replace the pressure plate by a new one with the same thickness. When assembling, make sure that the marking is visible.
8. Press the spring pin (5) into the housing and insert the clamping lever (4).
 9. Insert the parts (2) and tighten the screws (1).
 10. Make sure that the lifter (6) moves smoothly.

Further information:

- Replacing yarn carrier [39]

4.2.24 Intarsia yarn carrier - Correct stopping point (correction value) *

Key	Function
	Call up the "Yarn carrier" window
	Call up the "Adjusting yarn carrier" window

Keys for correcting the stopping point


1. Call up the "Yarn carrier" window.
2. Tap the "Adjusting yarn carriers" key.
3. Enter the yarn carrier correction value.
4. Confirm entries.
5. Return to the "Yarn carrier" window.

Further information:

- Adjusting yarn carriers [▢121]
- Intarsia yarn carrier - Adjust stopping point (basic setting, braking value) * [▢199]
- Intarsia yarn carrier - check the pressure plates * [▢209]
- Adjusting yarn carriers (Setup2) [▢124]
- Adjusting yarn carriers (Setup1) [▢126]
- Symbols in this document [▢3]


4.2.25 Float slider (holding-down jack control)

Valid for:	Type	Component type (or higher)	Gauge
CMS 530	642	Not possible	E10 E12 E14 E16
	621	002	E18 E6.2 E7.2 E8.2
CMS 822	623	004	

Problem	When swiveling the Intarsia yarn carrier, thread loops occur, which lead to errors in the fabric (thread loops, holes, drop stitches).
Basic	At the time of swiveling the Intarsia yarn carrier, the holding-down jacks are simultaneously closed. With some yarns this can cause problems - the thread piece "needle-yarn carrier" is clamped by the holding-down jacks. This thread piece cannot be pulled back by the lateral yarn tensioners. A thread loop is built, which can be knitted-in by the following knitting system.
Rectification	<p>Modify the holding-down jack control.</p> <p>The opening angle of the float slider is adjustable. In the "open" position the holding-down jacks will no longer close completely so that the thread will not be clamped.</p> <p>: Knitting-in the Intarsia yarn carrier.</p> <p>With longer floats it is possible that the tuck loop will not be laid-in reliably, for example with tuck {5} - - v - - or stitch {5} - - o - -.</p> <p>Rectification</p> <p>In the "Yarn Field Allocation" select the following for knitting-in.</p> <ul style="list-style-type: none"> ◆ Module for knitting-in: Float {0} - knitting-in ◆ Binding or knot at the start: Knot Split
Tip	<p>If possible:</p> <ul style="list-style-type: none"> ◆ knit pattern with half racking (V#) ◆ Adjust the float slider in the "open" position

CMS 530 Change the opening angle of the float slider:

1. Loosen the screw (1) with an Allen key (SW 3).



2. Using the Allen key move the screw and with it the float slider downward.
 - ▷ The end of the float slider protrudes from the base plate.
3. Tighten the screw (1).
4. Repeat the process on the other side of the holding-down jack control.
5. Repeat this operation with all the holding-down jack controls of the machine.

CMS 822

Key	Function
	Call up "Manual interventions" window
	Call up the "Service" menu
	Call up the "Holding-down jack control" window
	Call up "Main menu"


Keys for opening the holding-down jacks

Change the opening angle of the float slider:

1. Program an empty row and fix the knitting specification.
2. From the "Main menu" call up the "Manual interventions" window.
3. Tap the "On" key in the "Carr.revers.outs.n.bed" field.
4. Start the machine with the engaging rod and stop it again when the left carriage is located shortly after the left reversing position.
5. Start with the conversion of the float sliders at the left carriage.
6. Call up the "Service" menu from the "Main menu".

Advanced adjustments

7. Call up the "Holding-down jack control" window.
8. In the "Open/Close jacks" box, tap on the "Open" key.
 - ▷ The holding-down jacks are opened.
9. Lift the lever (1) somewhat and rotate it 90 degrees outwards until it engages again.
10. Repeat the process on the other side of the holding-down jack control.
11. Loosen the screw (2) with an Allen key (SW 3).




12. Using the Allen key move the screw and with it the float slider to the (B) position.
13. Tighten the screw (2).
14. Repeat this operation with the holding-down jack controls in the left carriage.
15. Move the carriage to the right and stop it again, if the right carriage is located shortly after the right reversing position.
16. Repeat the steps 6 to 14 for the right carriage.

4.2.26 Normal yarn carrier type 2


Normal yarn carrier type 1

Normal yarn carriers and intarsia yarn carriers cannot be used on the same track.



Reason: The disengaging arms (1) of the normal yarn carrier collide with the intarsia yarn carrier or the yarn carrier limiter.

Possible combinations for normal yarn carriers type1 and type2:




Each combination can be used with itself or with another combination.

1: Equip the yarn carrier tracks from inward to outward.

Normal yarn carrier type 2

That's why a new normal yarn carrier has been developed.



It has got no disengaging arms but lifters (2), similar to the intarsia yarn carrier. Thus, this yarn carrier can be used with intarsia yarn carriers on the same track.

The normal yarn carrier type 2 is used for:

- "normal" knitting




The yarn carrier knits for example the 2x1 fabric start, and some intarsia yarn carriers are additionally located on the same rail.

You had to use an intarsia yarn carrier for the 2x1 fabric start so far (cost saving).


- Plating with 2 yarn carriers.

The normal yarn carrier type 2 is used for plating. This was not possible before.

The normal yarn carrier can be used with both types of intarsia yarn carriers on the same yarn carrier rail.

Normal yarn carrier type 2	Intarsia yarn carrier type 1	
Normal yarn carrier type 2	Intarsia yarn carrier type 2	
Normal yarn carrier type 2	Normal yarn carrier type 2	




Plating with the normal yarn carrier type 2

	Engaging width (a)	Machine
	43 mm	CMS 933
	46 mm	CMS 822
	29 mm	CMS 530
	Standard yarn carrier ("normal" knitting)	CMS 520 CMS 530 T
	23 mm	CMS 730 T
<p>i: only usable under certain conditions. Depending on the machine gauge ($\geq E10$) and the machine speed, the needle latches can be damaged. Remedy: Increase the engaging width.</p>		




Further information:

- Adjusting yarn carriers [193]

4.2.27 Plating – the different possibilities

		Remarks	Gauge / Machine
1 yarn carrier (assembled on one yarn carrier rail)	Double Bow Plating Yarn Carrier 	<ul style="list-style-type: none"> ◆ For thin, elastic yarn (e.g. lycra) ◆ adjustable engaging width ◆ The left and right engaging widths may be different ◆ Special yarn carrier ◆ Clamping/cutting (setting: 2x8) 	All gauges, except E3, E4 Further information [☐219]
2 yarn carriers (assembled on two yarn carrier rails)	Yarn carrier carriage with adjustable engaging width 	<ul style="list-style-type: none"> ◆ Engaging width individually adjustable (26 to 46 mm) ◆ The left and right engaging widths may be different 	All gauges, except E3, E4 not for: CMS 520 C CMS 830 C Further information [☐221]
	Normal yarn carrier type 2 	<ul style="list-style-type: none"> ◆ The only possibility of plating when intarsia yarn carriers are located on the same rail ◆ For intarsia yarn carriers of types 1 and 2 ◆ The yarn carrier is usable for a "normal" knitting with intarsia yarn carrier 	All gauges, except E3, E4 not for: CMS 502 CMS 520 C CMS 830 C Further information [☐215]

Advanced adjustments

		Remarks	Gauge / Machine		
2 yarn carriers (assembled on two yarn carrier rails)	2 yarn carrier carriages  43 mm: ID 257 241	<ul style="list-style-type: none"> ◆ The cheapest solution: Only one additional yarn carrier carriage (43 or 46 mm) has to be bought. The yarn carrier bow will be taken from a normal yarn carrier. ◆ Different yarn thicknesses can be processed (different yarn carrier bows are usable). ◆ Non-adjustable engaging width 	E10 E12 E14 E16 E18 E6.2 E7.2 E8.2 E9.2		
	2 yarn carrier carriages  46 mm: ID 244 998		E5 E7 E8 E2,5.2 E3,5.2 E5.2		
1 Yarn carrier + 1 yarn carrier carriage		<ul style="list-style-type: none"> ◆ Yarn carrier carriage (35 mm) The yarn carrier bow will be taken from a normal yarn carrier. ◆ Different yarn thicknesses can be processed. 	CMS 520 C CMS 830 C		
				E7, E8	E10, E12
			Track 2+7	ID 258 600	ID 258 603
			Track 3+6	ID 258 601	ID 258 604
			Track 4+5	ID 258 602	ID 258 605
	◆ Non-adjustable engaging width				

Further information:

- Plating - Double bow yarn carrier [219]
- Plating - Plating yarn carrier carriage [221]
- Normal yarn carrier type 2 [215]
- Plating - Double bow yarn carrier [219]
- Plating - Plating yarn carrier carriage [221]
- Normal yarn carrier type 2 [215]


4.2.28 Plating - Double bow yarn carrier

Clamping and cutting bed
2x16

When using 16 times clamping / cutting, every other clamping / cutting point has to be deactivated to ensure that both threads are reliably clamped and cut.

Carry out the settings in the "Machine Configuration 2" window.
(BootOkc -> Restart and Configuration -> Machine configuration 2)
Setting: 2x16/8

Adjust the double bow yarn carrier



1	Central bow (fixed)	Plating Yarn
2	Follower bow (movable, following the central bow)	Basic Yarn

Central bow (1) - adjust height:

1. Loosen the screw (3) (turn by 90 degrees).
2. Adjust the central bow the same way as the normal yarn carrier.
3. Retighten the screw.


Follower bow (2) - adjust height:

1. Loosen both screws (4) (turn by 90 degrees).
2. Adjust the height turning the screw (5).
Standard setting: 2 mm higher than the central bow.
3. Retighten both screws (4).
4. Turn the screw (5) enough to prevent it from touching the upper or lower edge. If the screw is making contact, then the yarn carrier does not move smoothly and will be damaged.

Advanced adjustments


Follower bow (2) - carry out the lateral adjustment:

1. A screw is located in the boring (6). Adjust it with an Allen key (2 mm) (Setting range: 0 - 2 mm).
2. The distance from the bow (2) to the bow (1) can be set individually on each side. A scale simplifies the setting of the distance.



Adjusting the distance for the left side (distance visible on the right scale)

Thread the double bow yarn carrier



Threading possibilities



Colored plating pattern

The light, visible thread on the fabric front side is the plating yarn (threaded in the fixed central bow)


The dark thread is the basic yarn (threaded in the movable follower bow)

i

When an elastic thread is knitted, it is said that it is plated which is technologically not quite correct. The yarn is actually knitted with the plating process, and from the technological point of view, the elastic thread is the basic yarn, and the visible one is the plating yarn.

4.2.29 Plating - Plating yarn carrier carriage

Not for CMS 520 C, CMS 830
C



Two yarn carriers which differ depending on the engaging width (1) on the yarn carrier carriage, are used for plating with normal yarn carriers. The engaging width is adjustable individually (23-46 mm) on this yarn carrier carriage.

Combination possibilities of the yarn carriers:

- 2 plating yarn carrier carriages
- 1 standard yarn carrier, and 1 plating yarn carrier carriage

Example for a plating pattern



Colored plating pattern

The light, visible yarn on the fabric front side is the plating yarn (yarn carrier with the smaller engaging width)

The dark yarn is the basic yarn (yarn carrier with the larger engaging width)

i


When an elastic thread is knitted, it is said that it is plated which is technologically not quite correct. The yarn is actually knitted with the plating process, and from the technological point of view, the elastic thread is the basic yarn, and the visible one is the plating yarn.

Clamping and cutting bed
2x16

When using 16 times clamping / cutting, every other clamping / cutting point has to be deactivated to ensure that both threads are reliably clamped and cut.

Carry out the settings in the "Machine Configuration 2" window.
(BootOkc -> Restart and Configuration -> Machine configuration 2)
Setting: 2x16/8

Setting



Adjust engaging width:

1. Loosen both screws (1).
2. Push insert (2) into the desired position.
A scale simplifies the adjustment.
3. Retighten both screws (1).
4. Repeat the setting process for the other side.

The entire engaging width consists of the value for the left (Ua) and the right (Ub) hand-side.

Both values may be equal (symmetrical setting) or may differ.

Recommended engaging width (specifications in millimetres)

Gauge	leading	Following
E10 E12 E14 E16 E18 E6.2 E7.2 E8.2 E9.2	29 Ua: 14.5 Ub: 14.5	43 Ua: 21.5 Ub: 21.5
E5 E7 E8 E2,5.2 E3,5.2 E5.2	29 Ua: 14.5 Ub: 14.5	46 Ua: 23.0 Ub: 23.0





The engaging width of the standard yarn carrier is 29 mm.

Settings on the knitting machine

If you change the engaging width, you have to enter the changed values (Ua, Ub).


- Setup2: "Yarn carrier" window ->"Adjust yarn carrier" window-> "Y:Ua-b / Y:Ncc" tab
- Setup1: "Yarn carrier" window -> "Adjust yarn carrier" window



4.2.30 Changing the position of the knock-over wire

Valid for:	Type	Component type (or higher)	Gauge
CMS 530	621	002	E12
CMS 520	620	001	E16
CMS 502	626		E18
CMS 740	630		E6.2 (E12m.10)
CMS 822	623		E7.2
CMS 933	773		E8.2

The position of the knock-over wire affects the stitch appearance.




- Position 1: Under normal circumstances the position of the knock-over wire does not need to be changed.
- Position 2: For some patterns it is possible to improve the stitch appearance if the stitch is taken down from the needle with a steeper angle.

		Application area	To be observed
1	Default	◆ all the fabric types	
2	Special	Only in case of a problem with: <ul style="list-style-type: none"> ◆ single jersey fabric ◆ Plating ◆ multi-system knitting 	<ul style="list-style-type: none"> ◆ Adapt the stitch tension of the net row. ◆ with a double jersey fabric the selvedge stitch might tear.


For replacing the knock-over wire you need a small pair of pliers.

1. Cast-off or transfer the stitches of the needle bed, which is converted.
2. Stop the carriage in the left reversing position.

3. Remove screw (3) on left and right-hand sides of jack bed. Use the special hexagon screwdriver from the accessories for this purpose.



4. Loosen the screw (4) on the left and right-hand sides of the jack bed.
5. Remove the limiter (5) on both sides.
6. Pull out the wire (1) with the pair of pliers.



7. Push in the wire in position (2).
8. Reassemble the needle bed in the reverse order.

4.2.31 Overview of all machine data

In the "Machine data sheet" window, the current values of the machine data are displayed (NPK, VPK, VGK, CMS ADF-3: Correction values of the yarn carriers).

The machine data include the machine-specific settings (correction values).



Key	Function
	Call up the "Service" window
	Call up "Diagnostics" window
	Call up the "Machine data sheet" window
	Call up "Main menu"


Keys for calling up the "Machine data sheet" window

Display Machine Data:

1. In the "Main menu", tap on the "Service" key.
 - ▷ The "Service" window is displayed.
2. Tap on the "Diagnostics" key.
 - ▷ The "Diagnostics" window is displayed.
3. Tap on the "Machine data sheet" key.
 - ▶ The "Machine data sheet" window with the current machine data is displayed.



You can compare the current values with the factory settings. These can be found on the printed data sheet at the right control cabinet.



4.3 Working with files



NOTICE

Computer viruses!

Loss of data or production. Computer viruses can creep into the machine through unscanned data via USB port or network.

→ Bring in only virus free data on to the knitting machine.


This chapter contains information on:

- Help on working in the windows [229]
- File manager [234]
- Working with files, libraries and folders [238]
- Displaying file in pattern editor [243]
- Clear knitting memory [245]
- Copying files [247]
- Selecting the current folder [250]
- Carrying out a program check [252]

4.3.1 Help on working in the windows

The following help items should be heeded so that you may work in the various windows.

Call up direct help

Key	Function
	Call up "Direct Help" for the key pressed next

"Direct help" key

→ To receive direct help on a specific key in the menu, first tap the "direct help" key and then the key for which you want help.

Positioning cursor

The text is entered at the point at which the cursor (insert mark) is located.

→ To move the cursor to a certain position, touch that position.

Marking text

A word or a text block is marked for being copied, moved or deleted.



1. To mark a word, tap the word twice.
 2. To mark a line, tap the line three times.
 3. To mark a text block, drag your finger from the starting position to the end position.
- or -

On the 1st level of the SINTRAL editor, use both keys "Set beginning of a marking" and "Set end of a marking".

Deactivating marking

→ To cancel a marking, touch any spot.

Setting/deactivating write protection

Key	Function
	"Set Write Protection": Set write protection of the selected file
	"Deactivate Write Protection": Deactivate write protection of the selected file

"Activate write protection" and "Deactivate write protection" key



→ If a write-protected file is loaded, the information "Write protection" appears in the status line of the SINTRAL editor.

Working with files

Entries in selection window Selection windows are open when some keys are selected. The following entry is possible:

- a text can be entered with the virtual keyboard
- a selection occurs manually by tapping a key



The entries must be confirmed by the "Confirm entry" key.

Key	Function	Key	Function
	Return to the 1st level in the SINTRAL editor		Confirm input and run in the SINTRAL editor

Function keys in the selection windows


Call up "Search" selection window

The corresponding location is sought when you enter line numbers or text and select the keys.

Key	Function
	"Search": search for a specific term
	"Carry on searching": Continue searching for a certain term

"Search" and "Continue" keys

1. Call up the "Search" selection window with the "Search" key.
 - ▷ The "Search for" window appears.



"Search" selection window

2. Enter the line number or text to be searched for with the virtual keyboard.
3. Select options for uppercase/lowercase letters and the search direction.
4. To start the "Search from begin", select the "Yes" key.
 - or -
 - Select the "No" key if you only want to search from here.
5. To activate the search, tap the top arrow key,
 - or -
 - To exit the window, tap the bottom arrow key.
6. To find other instances of the text, tap the "Continue" key,
 - or -
 - To start the next search, enter a new line number or text with the virtual keyboard.


**If the message "Search title not found" appears:**

Either the text searched for is not contained in the knitting program or the options are not set correctly.

- Check the text entered.
- Change the search direction.


Call up "Replace" selection window

This is replaced in the loaded file by entering line numbers and commands and selecting the keys.

Key	Function
	"Replace": search for a certain term and replace it by a new one

"Replace" key

1. Call up the "Replace" selection window. Answer the safety prompt.
 - ▷ The "Replace by" window appears.



"Replace" selection window

2. Enter the text to be replaced via "Search for" with the virtual keyboard.
3. Enter the text to be inserted via "Replace by" with the virtual keyboard.
4. Selecting the "All" key, the text (without prompt in Item 7) is replaced throughout the entire file.
5. Select options for uppercase/lowercase letters and the search direction.
6. To activate the search, tap the top arrow key,
 - or -
 - To exit the window, tap the bottom arrow key.

**If the message "Search title not found" appears:**

Either the text searched for is not contained in the knitting program or the options are not set correctly.

- Check the text entered.
- Change the search direction.

7. Answer the question in the newly opened selection window. Press the key "1" to confirm.


- or -

- For repeated prompting, press the "0" key if the term is only to be replaced once.
- Press the "ESC" key to cancel.

Working with files

Call up "Go to" selection window


You can jump to the corresponding point in the loaded file by entering line numbers or names and selecting the keys.

Key	Function
	"Go to" a certain position

"Go to" key

1. Call up the "Go to" selection window with the "Go to" key.

▷ The "Go to" window appears.



Selection window for "Go to" function key

2. Enter the line number or name to be searched for with the virtual keyboard.

3. To go to Sintral line numbers, tap the "Sintral line" key,

- or -

→ To execute a real line jump, tap the "Editor line" key,

→ To jump to the named line, tap the "Label" key.

4. To activate the search, tap the right arrow key,

- or -

→ To exit the window, tap the left arrow key.






Automatic calling of virtual keyboard

The virtual keyboard is automatically activated when various function keys are selected. Either a number block appears for inputting numbers or an alphanumeric keyboard appears for entering letters and numbers.

The virtual keyboard contains three switchover keys:

- SHIFT key
- CPS LCK key
- CTRL key


To use a shift key, e.g. to enter a special character, first press the shift key and then the key with the special character. To return to normal characters, press the switchover key again.

Key	Function
	Switch on virtual keyboard
	Switch off virtual keyboard
	SHIFT key: switch over between uppercase and lowercase letters and between numbers and special characters
	CPS LCK key: switch over between uppercase and lowercase letters; the setting of numbers or special characters is maintained
	CTRL key: switch over to function keys F1 to F10 and keyboard codes (short cuts)

Switchover keys

4.3.2 File manager

Files and folders (directories and images) are managed in "File -Manager" window.



"File manager" window

All actions pertaining to folders are mentioned on the left side. A new folder can be created, for example.


You have access to the following data media:

- USB Memory Stick
- Hard disk of the computer in the knitting machine
- Online
- Network





On the right hand-side the files from the selected folders are displayed. This list of files appears in alphabetical order (standard setting), and the number of existing files is displayed on the status line (Total!).

Setting the sort sequence

The sort sequence can individually be adjusted. To do so, click on the header line (1). Select and confirm the sort sequence in the "Sort by" window.



Setting the sort criteria

Key	Function
	Call up the "Load & save" window
	Call up "Additional function keys"
	Call up "File manager" window
	Call up "Main menu"


Keys for the "File manager" window

Call up "File manager" window:














1. From the "Main menu" call up the "Load & Save" window.
2. Call up "Additional function keys".
3. Call up the "File Manager" window.

Working with files

Actions in the "File manager" window




"File manager" window

Key	Function	Key	Function
	"Update": Refresh the contents of all the folders		"Delete all": Delete all files in the selected folder
	"Create folder": Create folder in the selected directory		"Display file": Display selected file
	"Copy folder": Copy selected folder, including contents (subfolders, files) to the target folder.		"Rename file": Change name of selected file
	"Delete folder": Delete selected folder, including contents (subfolders, files)		"Set Write Protection": Set write protection of the selected file
	"Rename folder": Change the name of the selected folder		"Deactivate Write Protection": Deactivate write protection of the selected file
	"Update": Update the contents of the folder		Call up "Direct Help" for the key pressed next
	"Delete file": Delete selected file		

Keys in the "File manager" window


Call up the selection window
"Create folder"

With the selection of a drive or a folder in the list on the left side, the key
"Create folder " appears.



"Create folder"key in window "File-Manager"

1. Tap the desired folder in the list on the left in which the new folder is to be created.
2. Call up the selection window with the key "Create folder".
 - ▷ The window "Create new folder" appears



Selection window "Create new folder"

3. Enter the name of the new folder with the virtual keyboard.
4. To save the new folder, press the right arrow key,
 - or -
 - To exit the window, tap the left arrow key.

Further information:

- KnitLAN connection [262]
- Selecting the current folder [250]

4.3.3 Working with files, libraries and folders

Working with files (Sintral, jacquard, setup), libraries (Auto-Sintral) and pattern folders occurs in the "Load & save".



The file list is divided into machine type, file name, type and changed_on:. Sorting is possible in each of the 4 columns by pressing the column header. In the status line of the list, the number of existing files (total:), the file size and the date/time of the last change to the selected file are displayed.

You have access to the following data media:

- Removable data carrier (on the USB socket)
for example: USB-Memory-Stick, floppy disk drive, CD drive, DVD drive, external hard disk
- Hard disk of the computer in the knitting machine
- Online
- Network drive




If "EALL" is activated when loading, the previously loaded pattern is completely deleted.


Keys	Function
	Call up the "Load & save" window
	Call up "Main menu"

Keys for "Load & save" window

Work with files and folders:

NOTICE	
	<p>Data loss!</p> <p>Files and folders might be deleted accidentally if you do not proceed carefully!</p> <p>→ Create a back-up copy of each folder!</p>

1. From the "Main menu" call up the "Load & Save" window.




"Load & save" window













2. Set the desired path with one of the "Direct pattern folder selection" keys.
3. Use the PAT/SIN/JAC/SET/LIB keys to select whether the entire pattern of the current machine (PAT) or individual file types are to be listed.
4. Select file.
5. Select action.
6. If an additional prompt appears, tap the "1" key to confirm,
- or -
→ Press the key "0" to cancel.
7. Call up "Main menu".





















Working with files

Actions in "Load & save" window



"Load & save" window

Key	Function
	"Direct folder selection": predefined folder selection
	"Current folder selection": Open the dialog box for definition of the current folder
	Display the content of the Zip file (for Setup2)
	Close the zip file (for Setup2)
	Load selected file and accompanying pattern elements
	Load pattern with selected setup data (for Setup2)
	Save selected pattern parts in the current folder
	Save pattern with selected setup data (for Setup2)
	Delete selected file
	Display selected file
	"Add": add selected file and corresponding pattern elements to pattern already loaded
	Editing the setup data (for Setup1)

Key	Function
	"Update": Update the contents of the folder
	Call up "Direct Help" for the key pressed next
 	Activate/deactivate "Entire pattern selection".
 	Activate/deactivate "Sintral selection"
 	Activate/deactivate "Jacquard selection"
 	Activate/deactivate "Setup selection"
 	Activate/deactivate "Library selection"
 	Activate/deactivate "EALL selection"
 	Activate/deactivate "EAY selection"
 	Activate/deactivate "SP1 selection"
 	Activate/deactivate "YLC selection"




Keys in "Load & save" window

Further information:

- KnitLAN connection [262]
- Selecting the current folder [250]
- Copying files [247]
- Displaying file in pattern editor [243]
- Setup2 Editor [6]
- Setup1 - Editing the setup file [34]

4.3.4 Displaying file in pattern editor

The selected file from the "Load & save" window is displayed in the "Pattern editor" window (preview).


Key	Function
	Call up the "Load & save" window
	"Display file" key
	Call up "Pattern editor" window

Keys for the "Pattern editor" window









Displaying file in pattern editor:

1. From the "Main menu" call up the "Load & Save" window.
2. Select the file to be viewed in the file list.
3. Tap the "Display file" key.
4. The "Pattern editor" window is open.

Actions in the "Pattern editor" window







"Pattern editor" window

Key	Function
	search for a specific term
	"Continue": Continue to find a certain term
	"Go to" a certain position
	Carry out the "Quick jump" corresponding mark (e.g. from FBEG to FEND)
	"Enlarge": Display text enlarged
	"Reduce": Display the text decreased
	"Function list": Toggle on/off the display of pattern functions.
	Call up "Direct Help" for the key pressed next

Keys in the "Pattern editor" window


4.3.5 Clear knitting memory

The current knitting program with which your knitting machine works is saved in the knitting memory. When you delete the knitting memory, this has no influence on the saved patterns and files on the data carriers.

Key	Function
	Call up the "Load & save" window
	Call up "Additional function keys"
	Call up "Delete knitting memory"
	Call up "Main menu"

Keys for deleting the knitting memory

- Clear knitting memory
1. Call up the "Load & save" window.



"Load & save" window

2. Call up "Additional function keys".
3. Call up "Delete knitting memory".
4. Call up "Main menu".




If the "EALL" key is not selected, individual files (sin, jac or Autosintra) of the knitting memory can be deleted.

Working with files

Deleting individual files in the knitting memory:

1. Call up the "Load & save" window.






"Load & save" window

2. Select the file via the SIN or JAC key.
3. Call up "Additional function keys".
4. Call up "Delete knitting memory".
5. Call up "Main menu".

4.3.6 Copying files

Files are copied from one drive to another in the "Copying catalog" window. This list of files appears in alphabetical order, the number of existing files is displayed on the status line (Total:) of the list.


In the following example, the files are copied from the hard disk to the USB memory stick (backup copy).

Key	Function
	Call up the "Load & save" window
	Call up "Additional function keys"
	Call up the "Copying catalogue" window

Keys for the "Copying catalog" window

Copy file from the hard disk to the USB memory stick :

1. Insert the USB memory stick into the USB socket.
2. From the "Main menu" call up the "Load & Save" window.
3. Call up "Additional function keys".
4. Call up the "Copying catalog" window.




Path specifications in the "Copying catalog" window

5. Check whether the path in the "Source" and "Target" lists is correctly displayed. The path is displayed at the end of each list.
6. If this is not so, change the path with the "Select current folder" key.
7. Tap the desired file in the left-hand list ("Source").
8. Tap the "Copy file" key.
 - ▷ When the file is copied, it appears in the right list ("Target").
9. To copy other files, repeat steps 7 and 8.

Working with files

Actions in "Copying catalog" window



Path specifications in the "Copying catalog" window


Key	Function	Key	Function
	"Copying a file": Copy file selected in Source to Target		"Deactivate Write Protection": Deactivate write protection of the selected file
	"Copy all": Copy all files from Source to Target		"Current folder selection": Open the dialog box for definition of the current folder
	Delete selected file		Call up "Direct Help" for the key pressed next
	"Delete all": Delete all files in the selected folder		"Change content": Exchange contents of Source and Target; Source is always on the left, Target on the right
	"Set Write Protection": Set write protection of the selected file		"Update": Update the contents of the folder

Keys in the "Copying catalog" window

Execute the action:


1. Tap the list for which the action is to be carried out.
2. Tap the desired button.
3. To carry out additional actions, repeat steps 1 and 2.

Setting the sort sequence The sort sequence can individually be adjusted. To do so, click on the header line (1).



"Copying catalog" window

Select and confirm the sort sequence in the "Sort by" window.



Setting the sort criteria

Further information:

- Selecting the current folder [□250]

4.3.7 Selecting the current folder




General information Pattern files can be saved to various drives (memory locations) of the knitting machine or to another computer on the network.

To load a file into the knitting machine from another drive, the entire path must be specified. By path, we mean the specification of where the file is located, for example on a drive of the M1 pattern workstation.

A path contains the following information:

1. Drive letter (or computer name) (e. g.: "D:" or "\\SERVER01")
2. Specification of the subdirectories (e. g.: "\\PATTERN" or "Stoll\M1\Extract")

Standard setting Following drives are set by default in the keys of "Direct folder selection":








Key	Drive	Explanation
	F:\	USB Memory Stick
	D:\	Hard disk
	Name:\	Network drive

Standard settings of the drives

Selecting the current folder The selection of the patterns from the "Load & save" window is applied in the "Catalog order data", "Catalog Sequence data" and "Catalog Sequence lists" windows.

(Exception: The specification in the "Copying catalog" window is only effective for this window.)


Using the "Select current folder" key, you specify the drive to which the 3 "Direct folder selection" keys are linked.

Key	Function
	Call up the "Load & save" window
  	"Direct folder selection" key The symbols of the 3 keys "Direct folder selection" are adapted based on the linked drive: <ul style="list-style-type: none"> ◆ USB Memory Stick ◆ Network drive (USB) ◆ Hard disk ◆ KnitLAN ◆ Floppy disk drive (USB)
	"Select the current folder" key
	End setting process and save changes
	End setting process without saving changes

Keys for changing a path

Change the path of "Direct folder selection" key:

1. From the "Main menu" call up the "Load & Save" window.
2. Tap "Direct folder selection" key for which the path is to be changed.
3. Tap on the "Current folder selection" key.
 - ▷ The input window "Select new folder " appears.




"Select new folder" window

4. Select the new path.

5. End setting process and save changes.

- ▶ In the "Load & Save " window, the display of the key "Direct folder selection" is adapted to the new path. The path is displayed below it.







Display of the set path

4.3.8 Carrying out a program check

If you carried out changes in the knitting program you can have your inputs checked. With it the knitting program will be checked for its knitting ability. If an error is detected, an error message will be displayed in the lower area of the window. Tapping the "?" key will display notes about the reason and remedy of the problem.

Please note that only program errors, so-called syntax errors can be found. Errors in the jacquard area cannot be detected.

During the program test, the pattern is displayed in the upper area and the TP messages in the lower area. The window size of both areas can be changed.


Key	Function
	Call up "Main menu"
	Call up "Editor" window
	Call up "Additional function keys"
	Call up "Program test" window

Keys for the "Program test" window












Call up "Program test" window:

- ✓ A knitting program is being loaded.
- 1. From the "Main menu" call up the "Editor" window.
- 2. Call up "additional function keys".
- 3. Call up the "Program Test" window.

Actions in "Program test" window



"Program test" window

Key	Function
	"Start program test": Start program test from 1st line
	"Start program test": Start program test from a certain line on
	"Interrupt program test": Interrupt program test and restart it
	"End program test"
	"Go to" a certain position
	Carry out the "Quick jump" corresponding mark (e.g. from FBEG to FEND)
	"Display warning": Activate/deactivate presentation of warnings during a program test
	"Enlarge": Display text enlarged
	"Reduce": Display the text decreased
	"Change size": Change window size of pattern and error output
	Call up "Direct Help" for the key pressed next

Keys in the "Program test" window


4.4 Working with the Sintral editor

Minor changes or additions to the knitting programs are processed with the Sintral editor. To be able to process a knitting program with the Sintral editor, the knitting machine must be stopped. During production you can view the knitting program only.

Further information:

- Help on working in the windows [☐229]


4.4.1 Activating Sintral editor

Key	Function
	Call up the "SINTRAL-editor" window

Key for the "Sintral Editor" window

→ Call up the "SINTRAL-editor" window.

▶ The window of the first level in the "SINTRAL Editor" appears. The file currently loaded is shown in this window.




















```

1 C CMS530.Zopf-LL-Rippe-530-E12 E12 29.10.2005 10:43:27 <M1> 4.0.020 Build 3 Release (de
2 C #137= C Zus.Anfanger.E20 (#137=16..18)
3 RS1=5 C 2x1 Rapport
4 RS2=10 C RS2
5 C RS17= C Abwerfen (RS17=0)
11 C NP1=9.0 Netz
12 C NP2=10.0 Schlauchnetz
13 C NP3=10.0 2x1/2x2-Rapport


```

Window of the first level in the "SINTRAL editor"

















Key	Function	Key	Function
	"Switch toolbar": Switch over toolbar to second level		search for a specific term
	Display the toolbar for "Mask jump".		"Continue": Continue to find a certain term
	"Start of marking": Set the beginning of a marking. An existing marking is removed.		"Replace": search for a certain term and replace it by a new one
	"End of marking": Set the end of a selection		"Go to" a certain position
	"Cut": Cut selected area		"Go to" submenu is opened
	"Copy": copy selected area		Carry out the "Quick jump" corresponding mark (e.g. from FBEG to FEND)
	"Insert": reinsert copied or cut area		Activate and deactivate display of "Keyboard"
	"Undo action": the previous action is undone (also possible several times)		Call up "Direct Help" for the key pressed next
	"Redo": Restore an undone action (also possible several times).		

Keys of the first level in the "SINTRAL editor"

2nd level of "SINTRAL Editor" Pressing the "Switch over toolbar" key, the window goes to the 2nd level of the "SINTRAL Editor".




Window of the second level in the "SINTRAL-Editor"

Key	Function	Key	Function
	"Switch toolbar": Switch over toolbar to first level		"Pack and unpack jacquard": Pack or unpack selected jacquard lines
	"Enlarge": Display text enlarged		"Set jacquard start": Set start of jacquard on current line
	"Reduce": Display the text decreased		Switch over between current pattern and "Auto-Sintral"
	"Remove tile window": Remove tile window (horizontally or vertically)		"Delete all": delete the complete pattern
	"Tile window horizontally": Tile window horizontally		"Delete" submenu is opened
	"Tile window vertically": Tile window vertically		"Sort" marked area ascending by line numbers
	"Function list": Toggle on/off the display of pattern functions.		"Renumber": Reissue line numbers in the selected area
	Activate and deactivate display of Sintral "error messages"		Call up "Direct Help" for the key pressed next

Additional keys of the second level of the "SINTRAL editor"


Working with the Sintral editor

"Auto-Sintral" function key To activate this key, "Auto-Sintral" must be loaded. In the editor now one can switch between the currently loaded pattern and "Auto-Sintral".



Key	Function
	Switch over between current pattern and "Auto-Sintral"

"Auto-Sintral" key

"Tile window horizontally" function key This function makes two editors available which work independently of one another. When opening, the jacquard is jumped to in the lower editor. The size of the division is changed via both arrow keys on the left or right sides at the bottom edge of the screen.




Window for the function "Tile window horizontally"

Key	Function	Key	Function
	enlarge lower part		enlarge upper part



Function keys for the function "Tile window horizontally"

"Tile window vertically"
function key

This function makes two editors available, which both always show the same lines. Vertical scrolling in one editor changes the second editor simultaneously. Horizontal scrolling only changes one editor, and the start of a long line can be displayed in the left editor and the rest on the right one. Selections will immediately be copied in the other editor. The size of the division is changed via both arrow keys on the left or right sides at the bottom edge of the screen.




Window for the "Tile window vertically" function

Key	Function	Key	Function
	enlarge right part		enlarge left part

Function keys for the function "Tile window vertically"

Call up "Go to" submenu Press the arrow key next to the "Go to" key. You can jump to the start or the end of the file or line using this submenu.




Window "Go to" submenu

Key	Function	Key	Function
	Go to the start of the file		Go to the start of the line
	Go to the end of the file		Go to the end of the line
	Go to the begin of jacquard		

Function keys in "Go to" submenu

Call up "Delete" - submenu Press the arrow key next to the "Delete" key. Sintral, jacquard or a line from the loaded file can be deleted via this submenu.





Window "Delete" submenu

Key	Function	Key	Function
	Delete Sintral from file		Delete specified line from file
	Delete jacquard from file		

Function keys in "Delete" submenu

4.4.2 Go to help in function and error list

After loading and checking a file, the corresponding functions and error messages can be displayed in the "SINTRAL editor". You can jump in these lists using the following keys.

Key	Function
	"Go to help for next"
	"Go to help for previous"

Keys for go to help

- To jump to the next function / to the next error in the knitting program, tap the "Go to help for next" key.
- or -
- To jump to the previous function / to the previous error in the knitting program, press the "Go to help for previous" key.

4.5 KnitLAN connection

Valid for:

This description applies only to machines for which the connection to the Stoll Nameserver is not active.
If the connection to the Stoll Nameserver is active, the "Network favorites" key is not available since the KnitLAN connection will be configured on the Stoll Nameserver.

The KnitLAN connection helps in the transmission of data and patterns between the machine and an M1 or an FTP-Server (FTP = File Transfer Protocol, network protocol for data transmission).

The KnitLAN connection takes the place of the previous online program. In this chapter the setting of the KnitLAN connection is described. The selection of computers for "My network" is described in the MCNET2 instructions.









You can use the KnitLAN connection for:

- Transmitting knitting programs
- Monitoring production
- Collecting machine data

Requirements:


- Machine and M1 are networking
- Operating system of the machine: V 1.2 (or higher)
- Software version of M1: V 3.9 (or higher)

Configure the KnitLAN connection:

Key	Function
	Call up the "Service" menu
	Call up the "Basic settings" menu
	Call up the "Network favorites" window
	Opens the understructure of the marked network.
	Closes the substructure of the marked network.
	Transfers the selected computer in the field "KnitLAN / ftp"
	Deletes the selected computer
	Call up "Main menu"

Keys for setting the KnitLAN connection

1. Call up the "Service" menu.
2. Call up the "Basic settings" menu.
3. Call up the "Network favorites" window.



"Network favorites" window


- 1 Display of network environment which machine is integrated in.
- 2 Opens the understructure of the marked network.
- 3 Computers which are used for KnitLAN (e. g. pattern workstations) or computers on which a FTP server is installed.
FTP = File transfer protocol (network protocol for data transmission).

Defining user profile

4. From the entire network (1) select the computer of the M1.
If only the entire network is displayed, then open the substructure with the (2) key.
5. Transfer the selected computer into the "KnitLAN / ftp" (3) field.
6. If another computer needs to be selected, repeat steps 4 and 5.
7. Call up the "Main menu".



You can apply the KnitLAN connection to one of the "Direct folder selection" keys. The key is indicated with the symbol "KnitLAN". You can see the contents of the folder on the M1 in the selection field.



Working on the M1:

1. The access to the KnitLAN directories ("D:\Stoll\M1\KnitLAN\Bootfiles" and "Mc-ReadWrite") must be open to run the online connection from the M1 to the OKC machines.
Select the directory, call up the Context Menu, Properties, Share tab, Share Folder
2. In the Windows firewall you have to call up the firewall settings and allow the Stoll FTP service as an exception. (Start -> Control panel -> Windows firewall -> Exceptions tab).
The program "Stoll FTP service" can be found under the installation path of the M1 (e.g. "C:\Program Files\Stoll\M1\Bin\ftpservice.exe")


Further information:

- Selecting the current folder [□250]

4.6 Defining user profile

In the standard configuration each knitting machine user can open and make changes to any window of the user interface. However, in some cases this is not desirable and not every user is to be able to change data and machine settings. This can be set with the "User profile" window. In this window, rights as to which changes may be carried out and which may not, can be assigned to a user or a user group. If a window is blocked, it can be called up and the data viewed, however changes are not possible (exception: the password is known to the user and he/she can enable the window).

The operating elements in a blocked window are shown on a light gray background.



Blocked window "Manual interventions"

The assignment of the rights is reserved for an authorized person and protected by a password.

Any number of user profiles can be defined, for example for:

- Knitters
- Personnel of the night shift
- Setup personnel (technicians)
- Foremen/Forewomen

NOTICE	
	<p>The window is protected by a password!</p> <p>When calling up a window, a password is always requested. This serves the purpose of security so that no unauthorized persons have access to this window.</p> <ul style="list-style-type: none"> → The password must remain secret. → Uppercase and lowercase letters can be used in a password.


→ Note the password and keep it in a safe place.



If the password is lost, the Stoll Helpline can help with a special password.

Defining user profile











The "User profile" window



"User profile" window

Field	Function
1	Selection list of the window to be enabled or disabled. It is possible to scroll down/up in the selection list with the scroll bar (2). Additional windows are then available for selection.
3	Switch for blocking or enabling a window
4	Reset all changes
5	Operations for the selected user profile
6	Select or define user profile

Defining user profile


Key	Function
	Call up the "Service" window
	Call up "User profile" window
	Confirm password
	Return to previous window (cancel process)
	Block window
	Enable window
	Call up "Additional function keys"
	Enable all windows
	Block all windows
	Call up "Main menu"

Keys for defining "User profile"

Defining user profile


Defining user profile:

1. Call up the "Service" window.
2. Call up "User profile" window.



Entering password

3. Enter and confirm the password with the keyboard. In the standard configuration, the first password is "MASK.ACCESS". It is written in uppercase letters and without quotation marks.








"User profile" window

4. Block window: Tap the corresponding window in the selection list (1) and tap on the "Block window" (3) switch.
 - or -
 - Tap the corresponding window in the selection list with a double click.
5. Enable window: If a window is blocked, then enable it again with a double click.
 - or -
 - Tap the switch (3).
6. Only enable a few windows: First block all windows ("Additional function keys" key and "Block all windows" key) and then enable the few windows again.
7. Enable all windows: Tap the "Additional function keys" key and enable all windows again with the "Enable all windows" key.
8. Give a name to the user profile and save it.
9. Define another user profile if necessary.
10. For the user profile to become effective, it must be activated with the "Load" key.
11. Call up "Main menu".

Saving, loading, deleting user profiles ...

The user profile can be saved, loaded and deleted.


So that the same user profiles are active on all knitting machines, save the user profiles to USB memory stick or a network drive and load them in each machine.

Key	Function
	Call up the "Service" window
	Call up "User profile" window
	Confirm password
	Confirm selection
	Call up "Main menu"

Keys for "Saving, loading, exporting user profile ..."

Saving, loading, deleting user profiles ...:

1. Call up the "Service" window.
2. Call up "User profile" window.








"User profile" window

3. Enter and confirm the password with the keyboard.
4. Select the desired program point (5) (loading, saving, deleting ...).
5. Select a user profile. Tap on the desired user profile in the field (6).
6. Confirm selection.
7. If additional user profiles are to be called up, repeat the steps 4 to 6.
8. Call up "Main menu".

Defining user profile


Enabling blocked window During production it may be necessary to open a blocked window and carry out a change or action. Or you find that it is necessary for this window to be enabled for the active user. Naturally, this is only possible for a person who knows the password.

Key	Function
	Call up "Additional function keys"
	Tap "Password"
	Confirm password
	Return to previous window (cancel process)
	Call up "User profile" window

Keys for "Enabling blocked window"

Enabling blocked window:

1. Display the "additional function keys" in the blocked window.
2. Tap the "Password" key.
3. Enter the password with the keyboard.








"Enabling blocked window" window


4. Enable window once by tapping the "Confirm password" key.
- or -
- Change the user profile by tapping the "User profile" key.

Change password From time to time you should change the password to be sure that it has not become known. Carry out this activity on all knitting machines.

If the knitting machine is connected with the STOLL pattern workstation, the password can be changed simultaneously on all the knitting machines with the help of on-line connection (see section "On-line commands" at the end of this chapter).

Key	Function
	Call up the "Service" window
	Call up "User profile" window
	Confirm password
	Call up "Additional function keys"
	"Change password"

Keys for "Change password"

	Call up "Main menu"
---	---------------------

Modify password:

1. Call up the "Service" window.
2. Call up "User profile" window.
3. Enter and confirm the password with the keyboard.
4. Call up "Additional function keys"
5. Tap the "Change password" key.

Modify password:

Please enter new password again:



"Change password" window


6. Type in the new password in the top line.
7. Type in the new password again in the bottom line.
8. Confirm the password.
9. Call up "Main menu".

Defining user profile

Examples of how a user profile can be specified

Example 1:

The machine settings are to be blocked. To do this, block the four windows in the selection list.



"User profile" window

Example 2:

When beginning work with user profiles, there is an uncertainty as to which windows are required for daily work and which are not. We suggest using the following procedure:

1. First block all windows.
2. The knitter begins working with the machine.
3. If something needs to be changed in a window, the knitter reports this and the window is enabled in the user profile.
4. Save the user profile.
5. Continue this stepwise determination of the user profile for a certain period of time. This may, for example, be for a working day or a week.

Online commands

If the knitting machine is connected with the STOLL pattern workstation, the password and the user profile can be changed simultaneously on all the machines with the help of the on-line connection. The condition is that the password is written in uppercase letters.

Commands	Function
setuserlevel Password User profile name Example: The password is "JOE", the user profile is "david". The complete command is: setuserlevel JOE david	Activate the same user profile on all knitting machines
setulword OldPassword NewPassword Example: The old password is "JOE", the new one is "JOHN". The complete command is: setulpassword JOE JOHN	Activate the same password on all knitting machines

Commands for activating user profile and password

To enter the commands on the pattern preparation unit the following steps are necessary:

1. In the "Machine explorer" select the "Private machines" directory tree.
2. Call up the context menu and select the program item "Online extras".
 - ▷ The "Extra functions" window appears.
3. In the "Direct command" field type-in the corresponding command and confirm.

5 Setup Data

The knitting program consists of:

- Sintral program (*.sin)
- Jacquard program (*.jac)
- Information about production:
 - Specification of the stitch length
 - Distance between yarn carriers and fabric selvedge
 - Carriage Speed...

You can handle this information about production as follows:

- define it with every pattern anew
- define it in a separate file which you can reuse with every pattern
This file is called Setup file

Your advantages working with a setup file:

- The setup-data are centralized in one setup-file
- Clear operation of all setup data on the machine.
- Clear separation of variable pattern parameters and constant Sintral knitting specifications.
- All the parameters that are relevant when knitting-in the pattern are located in the setup file.
- The complete pattern (Sintral, Jacquard, Setup) can be transferred to another machine.
You can reduce the machine set-up time of the pattern by this.
- The Setup file can be applied to other pattern.
You can reduce the machine set-up time of the pattern by this.

5.1 Background

A short review Setup-data were introduced for CMS machines (starting with ST 711) in 1998. Following data can be saved to the setup-file:

- WMF(Fabric take-down menu)
- NP (All NP values)
- YD (Position of yarn carriers at the fabric selvedge)
- MSEC (indirect MSEC-setting)
- YLC (Yarn Length Control STIXX/ASCON)

This was the first step to write the pattern related parameters into a separate file. The purpose is to reduce the time of setting up the machine. Some pattern related parameters were still written in Sintral functions. Leading to setup work when converting the pattern for other machines.

You can use the extended setup data from now on.

In order to distinguish them they will be called Setup2 and the previous data Setup1.


The target of Setup2 Transferring a pattern from one machine to another without changing the Sintral program.

Setup2 is extended by the following parameters:





- Yarn carrier staggering (YD / YDI)
- Correcting the Normal Yarn Carriers (YC / YCI)
- Cycle Counters
- Racking Corrections
- Correction of the stitch length of the right carriage with tandem operation (NPR)
- Yarn length control at the left and right-hand side
- Correction value for clamping depth (NCC)
- Comments

5.2 Comparing Setup1 to Setup2

	Setup1	Setup2
Fabric take-down functions (WMF)	8 functions	50 fabric take-down functions (WMF)
		50 Auxiliary take-down functions (W+F) Switching auxiliary take-down on and off (W+1, W+0)
		Tabs for WM% and WMK%
Belt take-down functions (WBF)	Not possible	50 belt take-down functions (WBF)
Yarn Carrier Staggering YD	One staggering (YD)	21 staggerings (YD, YDI1-YDI20)
Yarn carrier corrections	One correction	20 corrections (YCI1-YCI20) Some corrections for all 32 yarn carriers can be defined with each function.
	<ul style="list-style-type: none"> ◆ The Setup file does not contain the correction of the normal yarn carriers. ◆ Correction of Intarsia yarn carrier in the KI / K<I> tab 	<p>All yarn carrier corrections (normal and intarsia yarn carriers) are included in the YCI tab</p> <p>with tandem mode: the correction values for the right carriage are part of the Y:Oa-b tab</p>
Correction values for stitch cam position (NP)	100	100
Specifications for the carriage speed (MSEC)	9	20
Correction value for clamping depth (NCC)	no part of the setup-file	A correction value per yarn carrier is possible
Yarn length	Indications for yarn length control on the right	Indications for yarn length control on the right and left
Cycle Counters	no indications possible	39 cycle counters

	Setup1	Setup2
Racking Corrections	VKA to VKZ, no part of the setup-file	50 Indices for racking corrections (VCI)
Comments	no indications possible	for each indication possible
Correction of stitch length for right carriage in tandem mode (NPR)	Not possible	possible
Additional information such as: <ul style="list-style-type: none"> ◆ Machine Number ◆ Online Number ◆ Hostname 	Not possible	possible
File Extension (File Extension)	.set	.setx (XML file)
File extensions for extracted patterns (File Extension)	.sin; .jac and .set	.sin; .jac and .setx files in a compressed folder (.zip file) 

5.3 Using Setup1 or Setup2


Setup1	usable for all machines (OKC, ST 468, ST 268, ST 168, ST 811, ST 711)
Setup2	usable with all OKC machines (starting with V 2.1)
Converting Setup2 --> 1	<p>Possible with M1plus (starting with V. 5.2) only. Example:</p> <p>How to convert a Setup2 patter for a CMS 530 to a pattern for a CMS 330:</p> <ol style="list-style-type: none"> 1. Load the pattern and call up the "Change Machine/ Gauge/Setup Type..." menu. 2. Set the corresponding setup type for the machine in the "Machine Explorer". 3. Start technical processing.  or  4. Run the "Generate MC Program..." function. 5. Run the "Extract MC Program..." function. <p>▶ The sin; jac and set files will be generated.</p>
Converting Setup1 --> 2	<p>Setup1 patterns cannot be converted automatically into Setup2. Example:</p> <p>How to convert a Setup1 pattern for a CMS 330 to a Setup2 pattern for a CMS 530:</p> <ol style="list-style-type: none"> 1. Load the pattern and call up the "Change Machine/ Gauge/Setup Type..." menu. 2. Set the corresponding setup type for the machine in the "Machine Explorer". 3. Modify and complete the parameters and functions corresponding to Setup2. 4. Start technical processing.  or  5. Run the "Generate MC Program..." function. 6. Run the "Extract MC Program..." function. <p>▶ The sin; jac and setx-files will be saved to a zip-file.</p>

How to generate a setup-file?

- Generating it together with the pattern on the M1plus.
Starting with the 5.2 version of the M1plus you can choose among **Setup in Sintral**, Setup1, Setup2
- Generating it manually (with Setup1 only)

5.4 Loading knitting program

You can quickly recognize whether it is a pattern with Setup1 or Setup2 data



1 Setup1 pattern


2  Setup2 pattern




A Setup2 pattern is saved in a zip file. The icon of compressed (zipped) folder is displayed in front of the pattern.

5.5 Setup2 Editor

5.5.1 Overview of the Setup2 Editor of the CMS


The Setup2 data will be displayed in the "Setup2 Editor".



	Explanation
1	Row
2	Tabs of a menu
3	Table
4	Call-up the individual menus
5	Switch on or off the virtual keyboard  : The menu keys are covered by the active virtual keyboard. Switch off the virtual keyboard in order to switch to another menu.
6	Activate and deactivate the state line (only display of the values, no window call up possible)
7	Switch on or off the table tools
8	Activate/deactivate the display of the active "Don't Care" values
9	Apply a change to further patterns
10	Undo the last editing of a line
11	Undo the last editing of a cell
12	Save all values of the actual tab (table)
13	Call up the online help of the selected tab.
	With file mode only
	Save the Setup2 file (setx)


Calling up the Setup2 Editor on the machine

How to call up the Setup2 Editor with the Setup data of the actual pattern:

Key	Function
	Call up the "Setup2 Editor" window

Key to call-up the "Setup2 Editor" window

1. Call up the "Setup2 Editor" in the "Main menu".
 - ▷ The "Setup2 Editor" window appears.



How to open the Setup2 file in the Setup2 Editor:

You can edit Setup2 data independently to the running production by the file mode.



1. Call up the "Load & save" window.
2. Get the Zip file displayed.




3. Tap the Setup2 file (*.setx).
- ▶ The "Setup2 Editor" window appears in the file mode.

Helpers for Input Depending on the active input field appears:

- the numeric keyboard
- the alpha-numeric keyboard (for comments)
- the input helper for list fields
- The input helper for NP measure units

	Explanation
	Switch on the virtual keyboard
	Switch off virtual keyboard










The numeric keyboard

	Explanation
	1 Slider
	2 Shows the maximum value of the selected field
	3 Shows the minimum value of the selected field
	4 Increase or decrease the value by one step
	5 Apply value from the previous row The applied value will not be displayed. An entry field without entry has the "Don't Care" property. An entry field with "Don't Care" is empty. i : "0" does not correspond to "Don't Care"
	6 Move cursor: one field to the left
	7 Delete the number to the left of the cursor
	8 Move cursor: one field to the right
	9 Confirm input. The cursor jumps to the next field.





The alpha-numeric keyboard

Key	Function	
	TAB	Jump to the next field.
	CPS LCK	Shift between uppercase and lowercase letters; the setting of numbers or special characters is maintained
	SHIFT	Shift between uppercase and lowercase letters and between numbers and special characters
	BACKSPACE	Move the cursor by one step to left and delete the character there
	ENTER	Confirm input
	LEFT	Move the cursor by one step to left
	RIGHT	Move the cursor by one step to right






The input helper for list fields

Element	Function
	Fold open selection field
	Fold closed selection field
	Move cursor: one line upwards
	Move cursor: one line downwards
	Move cursor: one character to left
	Move cursor: one character to the right
	Move cursor: to first input of selection field
	Move cursor: to last input of selection field
	Confirm input

The input helper for NP measure units


Element	Function
	Switch all values to NP
	Switch all values to millimeters
	Switch a single value to mm
	Switch a single value to NP

The Input Helper for Yarn Carriers (YLC tab)

Element	Function
 <p>The input grid consists of 8 rows and 2 columns. The first column contains numbers 1 through 8. The second column contains letters A, B, C, and D in rows 3, 4, 5, and 6 respectively. All cells are highlighted in light blue.</p>	<p>Enter yarn carrier specification Example: 3A</p>
 <p>A rectangular button with a blue gradient and the text "Clear" in the center.</p>	<p>Delete entry</p>
 <p>A small square button with a blue gradient and a white left-pointing arrow.</p>	<p>Move cursor: one character to left</p>
 <p>A small square button with a blue gradient and a white right-pointing arrow.</p>	<p>Move cursor: one character to the right</p>
 <p>A rectangular button with a blue gradient and a white left-pointing arrow with a small square at its tail, representing an enter key.</p>	<p>Confirm input</p>


Adding a table row You will find only those entries in the selection list which are not yet part of the table.

Example:





Some NP are part of the table. Select NP indices in the "Add Rows" dialog box from those not yet listed in the table. Multiple selections are possible.

Apply the selected NP indices to the table with .

You can cancel the procedure with .








Switching on or off the table tools

	Explanation
	Switch on the table tools
	Switch off the table tools



Further information:

- Table Tools [287]

Table Tools



	Explanation
	Go to row. Select the desired line in the selection list The cursor jumps to the desired line of the table. I : Active with more than 21 lines.
	Adding a table row
	Delete the selected line
	Copying the values (of a line)
	Inserting the copied values
	Copying several lines ("Yarn Carrier", "YD/YDI" and "YC/YCI" tab)
	Pasting the copied lines ("Yarn Carrier", "YD/YDI" and "YC/YCI" tab)

Activate/deactivate the display of the active "Don't Care" values












	Explanation
	Activate the display of the active "Don't Care" values Only with the tab: WMF, W+F, YDI, YCI, VCI
	Deactivate the display of the active "Don't Care" values

Apply a change to further patterns

If you made a change, you can apply it additionally to the setup files of the other patterns or sequence elements.

	A dialog box appears. After confirming with "Yes", the change is saved in the current pattern and in all patterns of the current folder.
	With a sequence, the icon changes its appearance. A dialog box appears. If you confirm with "Yes", the change is saved in the current sequence element and in all the sequence elements of the sequence.

File tools

	Explanation	
	Display the content of the Zip file	In the "Load & save" window
	Close the zip file	
	Load pattern	
	Load the pattern with selected Setup data	
	Save Pattern	
	Save the pattern with selected Setup data. → Select the desired Setup data in the "Save with configuration" dialog box	
	Deleting file Delete selected file	
	Display selected file With a Setup2 file (.setx) the Setup2 Editor appears in the file mode	
	Add Add selected file and corresponding pattern elements to pattern already loaded.	
	Save the setup file	In the file mode of the "Setup2 Editor" only

5.5.2 Take-down

WMF (tab)

	Explanation	Value range
WMF...	Fabric take-down function	WMF1 to WMF50
WM min	Minimum fabric take-down value (with Fully Fashion)	Minimum value: 0 Maximum value: 31.5 Step width: 0.1
WM max	Maximum fabric take-down value (value must always be specified)	Minimum value: 0 Maximum value: 31.5 Step width: 0.1
N min	Minimum quantity of needles (with Fully Fashion)	Minimum value: 0 Maximum value: Needle number of the CMS Step width: 1
N max	Maximum quantity of needles (with Fully Fashion)	Minimum value: 0 Maximum value: Needle number of the CMS Step width: 1
WMI	Fabric take-down impulse	Minimum value: 0 Maximum value: 15 Step width: 1
WM^	Open the brake of the active take-down system (main take-down or comb take- down) for a maximum of 2.5 seconds, take-down roller or comb take-down turn back by a maximum number of the indicated degrees (depending on the fabric tension and the fabric take-down value). CMS 5xx, 7xx, 8xx, CMS ADF-3: 9-60 degrees CMS 9xx: 9-120 degrees If either of both the conditions is fulfilled, then the brake is closed again. Fabric take-down value (n=0-31.5) becomes active again at the reversion.	No turning back: 0 Minimum value: 9 Maximum value: 120 Step width: 1
WMC	Set the speed control of the active take- down system (main take-down or comb take-down) to the value n (0-32). If the take-down system turns too quickly, the machine is stopped. 0= no stop motion, 1= insensitive, 32= very sensitive	Minimum value: 0 Maximum value: 32 Step width: 1

	Explanation	Value range
WM+C	Monitoring of main take-down. If the take-down has not been used after n (0-100) knitting rows, the machine will stop. (0 = no supervision)	Minimum value: 0 Maximum value: 100 Step width: 1
WMK+C	Controlling the comb. If the comb has not moved after n (0-100) knitting rows, the machine will stop. (0 = no supervision)	Minimum value: 0 Maximum value: 100 Step width: 1
Comment	Comment	ASCII Characters

Further information:

- Table Tools [▢287]
- File tools [▢288]
- Helpers for Input [▢282]
- Overview of the Setup2 Editor of the CMS [▢280]
- Setup Data [▢274]
- Comparing Setup1 to Setup2 [▢276]



W+F (tab)

	Explanation	Value range
W+F...	Auxiliary Take-down function	W+F1 - W+F50
W+F On	<input checked="" type="checkbox"/> Switch on auxiliary take-down. The auxiliary take-down will be closed. The speed of the auxiliary take-down W+=n is active	
	<input type="checkbox"/> Switch off the auxiliary take-down. The auxiliary take-down will be opened.	
W+=	Input of the speed of the auxiliary take- down Turning value n (1-15)	Minimum value: 1 Maximum value: 15 Step width: 1
W+P	Contact pressure n (0-10), only for machines with 72 and 84 inch working width	Minimum value: 0 Maximum value: 10 Step width: 1
W+C	Monitoring of auxiliary take-down. If the auxiliary take-down has not been used after n (0-100) knitting rows, the machine will stop. (0 = no supervision)	Minimum value: 0 Maximum value: 100 Step width: 1
Comment	Comment	ASCII Characters

Further information:

- Table Tools [▢287]
- File tools [▢288]
- Helpers for Input [▢282]
- Overview of the Setup2 Editor of the CMS [▢280]
- Setup Data [▢274]
- Comparing Setup1 to Setup2 [▢276]

WM% WMK% (tab)

	Explanation	Value range	
WM%	Modify the fabric take-down value by n percent	-80 to 80	
WMK%	Changing the fabric take-down value by n percent while the comb take-down is working. The value is active till the fabric is taken down by the main take-down.	-80 to 80	
Comment	Comment		ASCII Characters
			All characters and numbers (UTF-8)

Further information:

- Table Tools [[287](#)]
- File tools [[288](#)]
- Helpers for Input [[282](#)]
- Overview of the Setup2 Editor of the CMS [[280](#)]
- Setup Data [[274](#)]
- Comparing Setup1 to Setup2 [[276](#)]

5.5.3 Yarn carrier

YD / YDI (tab) Staggering the yarn carriers at the fabric selvedge.

	Explanation	Value range
⌘ YD	Distance between yarn carriers and fabric selvedge Collapse ⌘ (reduced display) Expand ⇩ (expanded display)	
YD1 : YD8	Distance of the yarn carriers on track 1 to 8 from the left and right fabric selvedge	Minimum value: 0 Maximum value: 160 Step width: 0.5=1/32 inch=0.8 mm
⌘ YDI	Additional, indirect yarn carrier staggering (YDI1 to YDI20) Collapse ⌘ (reduced display) Expand ⇩ (expanded display)	Minimum value: 0 Maximum value: 160 Step width: 0.5=1/32 inch=0.8 mm
Comment	Comment	ASCII Characters

Further information:

- Table Tools [▢287]
- File tools [▢288]
- Helpers for Input [▢282]
- Overview of the Setup2 Editor of the CMS [▢280]
- Setup Data [▢274]
- Comparing Setup1 to Setup2 [▢276]

YC / YCI (tab) Yarn carrier corrections

	Explanation	Value range
⌘ YC	Direct yarn carrier correction Collapse ⌘ (reduced display) Expand ⇩ (expanded display)	
⌘ YCI	Yarn carrier correction index YCI1 to YCI20 Collapse ⌘ (reduced display) Expand ⇩ (expanded display)	
Y	Corrections of yarn carrier 1A to 8D	
Ka	Yarn carrier correction value (left) for not swiveled yarn carrier if the yarn carrier is positioned within the fabric.	Minimum value: -120 Maximum value: 120 Step width: 0.5=1/32 inch=0.8 mm
Kb	Yarn carrier correction value (right) for not swiveled yarn carrier if the yarn carrier is positioned within the fabric.	Minimum value: -120 Maximum value: 120 Step width: 0.5=1/32 inch=0.8 mm
K<I>a	Intarsia yarn carrier correction value (left) for swiveled intarsia yarn carrier	Minimum value: -120 Maximum value: 120 Step width: 0.5=1/32 inch=0.8 mm
K<I>b	Intarsia yarn carrier correction value (right) for intarsia swiveled yarn carrier	Minimum value: -120 Maximum value: 120 Step width: 0.5=1/32 inch=0.8 mm
MSEC	Carriage speed if this yarn carrier is used (technical fabrics).	
V	Reduce carriage speed (n) for yarn carrier (n = 0..3). The speed is reduced to 75% from carriage reversal point until achievement of the operating range of the yarn carrier. Finally it can be chosen between the following possibilities: <ul style="list-style-type: none"> ◆ 1 = Acceleration up to 100% ◆ 2 = Braking down to 50%, maintain speed over a fabric width of 2 inches, acceleration up to 100% ◆ 3 = Braking down to 50%, maintain speed over a fabric width of 5 inches, acceleration up to 100% ◆ 0 = Cancelling out of carriage speed specific to yarn carrier 	
Comment	Comment	ASCII Characters

Further information:

- Table Tools [287]
- File tools [288]
- Helpers for Input [282]
- Overview of the Setup2 Editor of the CMS [280]
- Setup Data [274]
- Comparing Setup1 to Setup2 [276]

Y:Oa-b (tab) Tandem machine: Correction of the yarn carriers in the right carriage

	Explanation	Value range
Y-1AR : Y-8DR	Specification of the yarn carrier in the right carriage.	
Oa	Right carriage during tandem operation: Yarn carrier correction value a (stopping position on the left). The correction value refers to the stop value of the left carriage.	Minimum value: -8 Maximum value: 8 Step width: 0.5=1/32 inch=0.8 mm
Ob	Right carriage during tandem operation: Yarn carrier correction value b (stopping position on the right).	Minimum value: -8 Maximum value: 8 Step width: 0.5=1/32 inch=0.8 mm
Comment	Comment	ASCII Characters


Further information:

- Table Tools [287]
- File tools [288]
- Helpers for Input [282]
- Overview of the Setup2 Editor of the CMS [280]
- Setup Data [274]
- Comparing Setup1 to Setup2 [276]

- Y:Ua-b / Y:Ncc (tab) ■ Adjusting the engaging width when plating with normal yarn carriers.
 ■ Control the clamping depth of the cutting needles

	Explanation	Value range
Y	Corrections of yarn carrier 1A to 8D	
Ua	Adjust the engaging width (left) when plating with normal yarn carriers.	Minimum value: 11.5 mm Maximum value: 23 mm (CMS-C: 35 mm) Step width: 0.5 mm
Ub	Adjust the engaging width (right) when plating with normal yarn carriers.	
NCC	Only for machines with clamping and cutting bed: Control of the clamping depth of the cutting needles. Standard setting: n=0 e.g.: sink the cutting needles by 5 steps deeper: NCC=5	Minimum value: -10 Maximum value: 10 Step width: 1
Comment	Comment	ASCII Characters

Engaging value for the left and right carriage direction



Further information:

- Table Tools [▢287]
- File tools [▢288]
- Helpers for Input [▢282]
- Overview of the Setup2 Editor of the CMS [▢280]
- Setup Data [▢274]
- Comparing Setup1 to Setup2 [▢276]

Width (tab) The M1plus enters the width of the inlay yarn carrier in the "Yarn carrier carriage width" field.

Further information:

- Table Tools [▢287]
- File tools [▢288]
- Helpers for Input [▢282]
- Overview of the Setup2 Editor of the CMS [▢280]
- Setup Data [▢274]
- Comparing Setup1 to Setup2 [▢276]

5.5.4 Stitch lengths

NP 1-100 (tab)

	Explanation	Value range
NPK	Correction for all stitch cams	Minimum value: -2 Maximum value: 2 Step width: 0.05
NP1 - NP100	Stitch cam position 1 to 100	
Value	Stitch length in NP values or mm	
Value [mm] <input type="checkbox"/>	Specification in NP values.	Minimum value: 6.5 Maximum value: 22.5 Step width: 0.05
Value [mm] <input checked="" type="checkbox"/>	Settings in millimeters. Setting the yarn length per stitch (Yarn Length Control).	Minimum value: 2.20 Maximum value: 33.00 Step width: 0.01
Comment	Comment	ASCII Characters

Further information:

- Table Tools [▢287]
- File tools [▢288]
- Helpers for Input [▢282]
- Overview of the Setup2 Editor of the CMS [▢280]

NPR (tab) Correction of the stitch cam position for the right carriage (for tandem operation only)

	Explanation	Value range
NPR	Correction of the stitch cam position for the right carriage	
Front	Correction value depending on system in front or rear and on carriage direction to the left or to the right	Minimum value: -2 Maximum value: 2 Step width: 0.05
Rear		
<<		
>>		
NPxR	Correction value for the stitch cam position x (1-100) of the right carriage	
Value	Specification in NP values.	Minimum value: -2 Maximum value: 2 Step width: 0.05
Value [mm] <input checked="" type="checkbox"/>	Specification in millimeters.	Minimum value: -5.0 Maximum value: 5.0 Step width: 0.01
Comment	Comment	ASCII Characters

Further information:

- Table Tools [▢287]
- File tools [▢288]
- Helpers for Input [▢282]
- Overview of the Setup2 Editor of the CMS [▢280]
- Setup Data [▢274]
- Comparing Setup1 to Setup2 [▢276]

5.5.5 Carriage speed

Different carriage speeds can be entered for different knitting situations. The indirect carriage speed only becomes effective when it is slower than the normal speed.

	Explanation	Value range (meters/second)
MSECK	Carriage speed for small knots over m rows, standard: 1 row	Minimum value: 0.05 Maximum value: 1.20 Step width: 0.05
MSEC	Speed (normal speed)	Minimum value: 0.05 Maximum value: 1.20 Step width: 0.05
MSEC0	Speed for empty rows (S0)	Minimum value: 0.05 Maximum value: 1.40 Step width: 0.05
MSEC1	Speed for transfer rows	Minimum value: 0.05 Maximum value: 1.20 Step width: 0.05
MSECI	Speed with Intarsia Yarn Carrier (CMS ADF-3: Specification is not taken into account)	Minimum value: 0.05 Maximum value: 1.00 (CMS-C: 0.7) Step width: 0.05
MSECC	Speed outside the needle bed when the yarn carrier is brought in the clamp or taken out of the clamp.	Minimum value: 0.05 Maximum value: 0.50 Step width: 0.05
MSEC2-20	Speed for knitting rows	Minimum value: 0.05 Maximum value: 1.20 Step width: 0.05
Comment	Comment	ASCII Characters

Further information:

- Table Tools [287]
- Helpers for Input [282]
- Setup2 Editor [280]
- Setup Data [274]
- Comparing Setup1 to Setup2 [276]
- File tools [288]

5.5.6 Cycle counters

The cycle counter specifies how often a pattern area is to be repeated. Which cycle counter controls which pattern area is defined in the knitting program.


	Explanation	Value range
RS1 - RS39	Cycle counters 1 to 39	1-99999
Comment	Comment	ASCII Characters

Further information:

- [Table Tools \[287\]](#)
- [File tools \[288\]](#)
- [Helpers for Input \[282\]](#)
- [Overview of the Setup2 Editor of the CMS \[280\]](#)
- [Setup Data \[274\]](#)
- [Comparing Setup1 to Setup2 \[276\]](#)

5.5.7 Yarn length



Basic settings


	Explanation
"Operating mode for patterns"	Determine the yarn length control mode.  : On the CMS the mode can be changed here. <ul style="list-style-type: none"> ◆ Production without YLC ◆ Working with mm ◆ Working with original fabric ◆ According to Sintral specification
"Correction data (Working with mm)"	<input type="checkbox"/> No correction data was determined yet.
"Original fabric data (Working with original fabric)"	<input checked="" type="checkbox"/> Correction data was determined.
"Wheel"	left device: Select measuring wheel (n=9 to 16). right device: Select measuring wheel (n=1 to 8).
"Y"	Select the yarn carrier (1A to 8D) working with this measuring wheel.
"Comment"	Comment (ASCII Characters)

Further information:

- [Helpers for Input \[282\]](#)
- [File tools \[288\]](#)
- [Table Tools \[287\]](#)
- [Setup Data \[274\]](#)
- [Overview of the Setup2 Editor of the CMS \[280\]](#)
- [Comparing Setup1 to Setup2 \[276\]](#)

Correction Values


	Explanation
"Correction for all measuring wheels"	Enter a correction value for all measuring wheels
"Maximum deviation of the target value per knitting row"	Stopping the machine when exceeding the correction value (Standard = 15%).
"Wheel"	right device: Select measuring wheel (n=1 to 8). left device: Select measuring wheel (n=9 to 16).
"Y"	Select the yarn carrier (1A to 8D) working with this measuring wheel.
"Correction < +/-[%]"	Enter correction value for an additional thread from the from the right. The correction value has an effect in the carriage direction to the left. 
"Correction > +/-[%]"	Enter correction value for an additional thread from the from the left. The correction value has an effect in the carriage direction to the right. 
Only when "Working with original fabric"	
"Yarn correction for original fabric"	Change the fabric length without determining once again the original fabric data. If, for example, the same pattern is to be knitted with another yarn color (not yarn thickness). Value range: -10%...+10%, step width: 0.1

	Explanation
"Minimum width for original fabric"	<p>Change the minimum width only if the error message "YLC: deviation from set value of measuring wheel x too large" is displayed.</p> <p>Value range: - 2 E...0...+ 2 E (E = Number of needles per inch = Gauge of the machine)Example for E16: -32...0...+32 needles</p> <p> In the "Yarn length control" window execute again the program item "Record original fabric" afterwards.</p>
"Comment"	Comment (ASCII Characters)

Further information:

- [Helpers for Input \[282\]](#)
- [File tools \[288\]](#)
- [Table Tools \[287\]](#)
- [Setup Data \[274\]](#)
- [Overview of the Setup2 Editor of the CMS \[280\]](#)
- [Comparing Setup1 to Setup2 \[276\]](#)

Yarn data The yarn data are necessary for the calculation of the yarn consumption.

	Explanation
"Wheel"	right device: Select measuring wheel (n=1 to 8). left device: Select measuring wheel (n=9 to 16).
"Y"	Select the yarn carrier (1A to 8D) working with this measuring wheel.
"Yarn Quality" for yarn disposition only	"Yarn" A maximum of 5 yarns can be threaded into one measuring wheel. The yarn data is entered in a separate line for each yarn.
	"Yarn Quality" Example: <input type="text" value="Nm 28/2"/> Enter 28 here
	"Number of Yarn Threads" Enter the number of individual threads. Example: <input type="text" value="Nm 28/2"/> Enter 2 here
	"Number of Threads "  Enter the number of threads per yarn carrier here
	NM; TEX; DTEX; NE/C; NE/W; DEN Select unit for the yarn thickness. Enter NM here
"Yarn ID"	Yarn ID or comment

Further information:

- [Helpers for Input \[▢282\]](#)
- [File tools \[▢288\]](#)
- [Table Tools \[▢287\]](#)
- [Setup Data \[▢274\]](#)
- [Overview of the Setup2 Editor of the CMS \[▢280\]](#)
- [Comparing Setup1 to Setup2 \[▢276\]](#)

NP (Knitting Mode) / Wheel Display showing which stitch cam position works together with which measuring wheel.

The list is filled out automatically (mode "Working with mm", program item "Determine basic conditions").

	Explanation
"front"	Stitch cam position on the front needle bed
"Back"	Stitch cam position on the rear needle bed
"Wheel"	Measuring wheel
"Active"	Selection for program item "Production": <input checked="" type="checkbox"/> The stitch cam position is controlled with YLC. <input type="checkbox"/> The stitch cam position is not controlled with YLC.
"Comment"	Comment (ASCII Characters)

Further information:

- [Helpers for Input \[282\]](#)
- [File tools \[288\]](#)
- [Table Tools \[287\]](#)
- [Setup Data \[274\]](#)
- [Overview of the Setup2 Editor of the CMS \[280\]](#)
- [Comparing Setup1 to Setup2 \[276\]](#)

5.5.8 Racking

The racking instructions are valid for one carriage stroke.

	Explanation	Value range
VCI...	Racking function	VCI1 to VCI50
VK	Racking correction by m steps (0-10)	Step width: 1/70 of the needle distance
Dir	Direction of the racking correction < - to the left > - to the right ? - not defined, will be defined on the machine	
VV	Racking speed n (1-32), without an instruction VV=32	
V+/-	V+ - Overracking, in addition to the racking specification positive value: Overracking in racking direction negative value: Overracking in opposite to the racking direction	(n=1-24, step width: 1/8 of the needle distance)
Comment	Comment	ASCII Characters



Further information:

- Table Tools [287]
- Helpers for Input [282]
- File tools [288]
- Overview of the Setup2 Editor of the CMS [280]
- Setup Data [274]
- Comparing Setup1 to Setup2 [276]

5.5.9 Miscellaneous

General data about the machine are displayed.

Data about the machine cannot be modified here.



















	Explanation	
#137	Needle gauge	These data derive from the "Select Machine" dialog box of the M1plus
#195	Needle hook gauge	
#156	Coupling width (with tandem machines)	
Machine -No.	Stoll machine number:	These data are entered automatically at the machine.
Hostname	Name of the computer within the network	
Online-ID	KnitLAN-ID	
Comment	General comment about the Setup file	 ASCII Characters
		 Display only

Further information:

- Table Tools [287]
- File tools [288]
- Helpers for Input [282]
- Overview of the Setup2 Editor of the CMS [280]
- Setup Data [274]
- Comparing Setup1 to Setup2 [276]

5.5.10 Data Mode and File Mode

The "Setup2 Editor" of the CMS and of the M1plus differs between the editing of Setup2 files (.setx) and of data of the loaded pattern (.mdv / .zip).

		Data Mode	File Mode
Origin of the data		Loaded pattern	Setup2 files (.setx)
Calling up		By the "Pattern Parameters" / "Setup-Data..." menu	By the "MC-Program" / "Display MC Program..." / "MC-Setup..." menu
			 / .setx 
Save		Button "Apply"	Menu  "Save"
			
Effect of editing		Direct in the pattern Direct in the fabric	Modified Setup2 file
Difference in editing		Restricted possibilities due to the situation	Restricted possibilities due to the situation
File Tools		Not available	Menus "File" "Edit" "?"    
		Not available	
Title		"<pattern name> - <CMS...> - Setup2"	"Sintral Editor - <file name>.setx"

5.6 Setup1 - Editing the setup file

The Setup data editor allows setup data to be edited without loading them into the machine beforehand. It is thus possible to edit another setup file while the machine is knitting a pattern. Each group of setup data has its own tab with the corresponding input fields in the "Setup data editor" window.










If no STIXX device is connected to the machine, the "STIXX" and "STIXX3" tabs are not displayed although the setup file contains STIXX data.

The STIXX data cannot be edited.

If the set-up data are saved, then existing STIXX data (not displayed) are also saved.

The following events can prevent a correct saving of setup data:


- The setup file is write protected.
This is displayed by a touch. The write protection can be deactivated by the additional function key "Deactivate write protection".
- Limiting values do not agree with each other.
The limiting values of the entered setup data are compared to data of current machine and checked.
Conflicts may therefore arise if a setup file of a different machine is being edited on the machine.
- The tabs "NP1..50", "NP51..100", "WMF" and "MSEC" can contain empty input fields.
This is because of the M1 that only deposits the used NP, WMF and MSEC data into setup file.
When saving data from setup data editor, only the used NP, WMF and MSEC data are also saved in setup file.

Key	Function
	Call up the "Load & save" window
	Activate the "Setup selection"
	Call up the "Setup data editor" window
	Call up "Additional function keys"
	"Activate write protection" key
	"Deactivate write protection" key
	Call up "Main menu"

Keys for the "Setup data editor" window


Activating the Setup data editor

1. Call up the "Load & save" window.



"Load & save" window

2. Activate the "Setup selection" key (1).
3. Select the desired setup file (2).
 - ▷ The "Setup data" editor key is displayed (3).
4. Tap the "Setup data editor" key (3).
 - ▷ The "Setup data editor" window is open.



"Setup data editor" window

- A Total of 8 tabs:
The STIXX and STIXX3 tabs are only displayed if a STIXX device is connected.
- B Working area
changes, depending on the selected card.
- C Status bar:
with the file name of the loaded setup file.

The "Setup data editor" window contains a maximum of 8 tabs:

Card	Meaning
NP 1..50	Stitch cam position with index 1 to 50
NP 51..100	Stitch cam position with index 51 to 100
WMF	Specifications for take-down value
YD	Distance between yarn carriers and fabric selvedge
KI/K<I>	Correction value of yarn carriers in fabric area
MSEC	Specifications for carriage speed in m/sec
STIXX	Specifications for the STIXX yarn length measuring device (STIXX menu)
STIXX3	Specifications for the STIXX yarn length measuring device (STIXX3 menu)

Tabs in the "Setup data editor" window

Setup1 - Editing the setup file

Working with the setup data editor

Set/deactivate write protection:

✓ The Setup data editor window is open.

1. Call up "Additional function keys".
2. Tap the "Activate write protection" key in order to activate the write protection.

- or -

→ Tap the "Deactivate write protection" key in order to deactivate the write protection.

Editing the setup file:

1. Tap the tab to be edited.
2. Select the desired field.
3. Overwrite the value.
4. Confirm input.
5. Repeat steps 1 or 2 to 4 for further inputs.

- or -

→ Call up "Main menu".

6 Maintenance of the knitting machine

This chapter contains information on:

- Minimize wear [▢314]
- Cleaning the knitting machine [▢316]
- Lubricate knitting machine [▢326]

6.1 Minimize wear

All parts of the knitting machine have carefully been selected and checked by Stoll. Nevertheless, they are subject to wear due to wear. You can keep the wear to a minimum if you lubricate, clean and check the machine regularly.

The following table contains an overview of the wearing parts and the possible causes for excessive wear.

Wearing part	Possible causes of increased wear
Fabric take-down rollers	<ul style="list-style-type: none"> ◆ Excessive fabric take-down values ◆ Contact pressure too high/low ◆ Yarns harmful for e.g. abrasive, sanding yarns or yarn finishes like greases or oils ◆ UV radiation (including direct sunlight) ◆ Cleaning agents harmful to rubber, e.g. ether or fuels. Recommendation: Use cleaning petrol for cleaning
Belts of the fabric take-down (Belt take-down) *	<ul style="list-style-type: none"> ◆ Too high belt speed ◆ Fabric winding ◆ Thread winding ◆ Yarns harmful for e.g. abrasive, sanding yarns or yarn finishes like greases or oils ◆ UV radiation (including direct sunlight) ◆ Cleaning agents harmful to rubber, e.g. ether or fuels. Recommendation: Use cleaning petrol for cleaning
Needle brushes, Brushes of the central lubrication Brushes of the winding protection device *	<ul style="list-style-type: none"> ◆ Incorrect adjustment
Feed wheel rollers	<ul style="list-style-type: none"> ◆ Sanding yarn ◆ Allowing the feed wheel to run unnecessarily
Needle bed elements, cams	<ul style="list-style-type: none"> ◆ Excessive fabric take-down values ◆ Yarn too thick ◆ Insufficient lubrication ◆ Insufficient cleaning
Yarn guiding parts (deflectors, yarn control device, etc.)	<ul style="list-style-type: none"> ◆ Sanding yarn
Yarn carrier, yarn carrier slide block	<ul style="list-style-type: none"> ◆ Insufficient lubrication ◆ Sanding yarn
Yarn carrier magnet	<ul style="list-style-type: none"> ◆ Magnet may not come into contact with grease or oil

Wearing part	Possible causes of increased wear
Belt on auxiliary take-down	<ul style="list-style-type: none"> ◆ Following a fault on the auxiliary take-down (fabric winding device), the residual threads were not removed carefully
Belts (drive, racking, comb take-down, auxiliary take-down)	<ul style="list-style-type: none"> ◆ Belt tension too high: Danger of bearing damage (adjustment with measuring device by Stoll technician) ◆ Belt tension too low: Danger of position errors (racking, auxiliary take-down)
Energy chain trailing cable	<ul style="list-style-type: none"> ◆ Heavy soiling ◆ Laying down of objects ◆ Damage to depositing gutter ◆ Not moved into position carefully after work at the rear of the machine

Wearing parts

Further information:

- Adjusting needle brushes [▢194]
- Yarn table [▢469]
- Lubricate knitting machine [▢326]
- Cleaning the knitting machine [▢316]
- Adjusting the brushes of the central lubrication * [▢203]
- Symbols in this document [▢14]

6.2 Cleaning the knitting machine

To retain the operability of the knitting machine and ensure the quality of the fabric, the knitting machine must be cleaned regularly.


Cleaning interval	Cleaning work
if necessary	Cleaning the touch screen
6 to 24 operating hours	Cleaning suction and lint container
daily	Vacuuming off knitting machine Cleaning needle bed Cleaning thread clamping and cutting device Cleaning the active thread clamp Cleaning the permanent brakes Cleaning the friction feed wheel
100 operating hours	Cleaning main drive fan
once a month	Cleaning fan and radiators in right control unit Cleaning filter mat of power supply unit
3 to 6 months	Thoroughly cleaning needle bed
6 months	Clean the knitting systems


Cleaning plan

We recommend the use of following cleaning agent:

Cleaning agent	Cleaning work
Cloth, suction, compressed air	on the entire knitting machine
Special cleaning agent for plexiglas (note the manufacturer's specifications)	Touch screen and covers
Cleaning petrol (note the manufacturer's specifications)	Roller rubber of the take-down roller

Cleaning agent

NOTICE	
	Plastics, in particular the transparent covers, may not be cleaned with alcohol or spirit, but instead only with a special cleaning agent for plexiglas.

NOTICE	
	Do not remove metallic parts and fragments (e.g. broken needle latch or needle hook) with a magnetic tool. There is a danger that the needle bed or cams can be magnetized, leading to incorrect selection.



Further information:

- Cleaning the touch screen [▢317]
- Cleaning suction and lint container * [▢318]
- Vacuuming off knitting machine [▢319]
- Cleaning needle bed [▢320]
- Cleaning thread clamping and cutting device [▢320]
- Cleaning the active thread clamp [▢321]
- Cleaning the permanent brakes [▢321]
- Cleaning the friction feed wheel * [▢321]
- Cleaning main drive fan * [▢322]
- Cleaning fan and radiators in right control unit [▢322]
- Cleaning filter mat of power supply unit [▢323]
- Thoroughly cleaning needle bed [▢323]
- Clean the knitting systems [▢325]

6.2.1 Cleaning the touch screen

Use a clean, soft cloth for cleaning. If heavy soiling is present, use a cleaning agent suitable for plexiglas. To prevent menus and function keys from being activated when cleaning the touch screen, two options are available:

- Disconnect machine main switch
- Deactivate touch screen using the "Block input" key

Key	Function
	Call up the "Service" menu
	"Block input" key



Keys for cleaning the touch screen

Cleaning the touch screen:

1. Call up the "Service" menu from the "Main menu".
2. Tap the "Block input" key.
3. Clean the touch screen.
4. Reactivate the screen again after cleaning. For this purpose, trigger a manual stop, e.g. by pushing open a cover over the needle bed.


6.2.2 Cleaning suction and lint container *

1. Stop knitting machine when carriage is located on right half of needle bed.
2. Slide on cover over needle bed.
3. Push locking of lint container inwards and pull away container upwards.



Lint container and filter

4. Empty the lint container.
5. Clean filter (1) of lint container.
6. Reinstall the lint container.
7. Remove left rear panel segment.
8. Clean motor cover.




Cleaning motor cover

**NOTICE****Damage to the suction tube!**

The suction tube will be damaged at the coupling point of the suction tube and the hose if you lift it by the suction nozzle.

- Lift the suction tube always in the middle so that the coupling point "suction tube - hose" is separated.

9. Lift the suction tube in the middle until the fixing clip is pulled out of the carriage.



Suction tube

10. Blow out the suction tube with compressed air.

Further information:

- Symbols in this document [14]

6.2.3 Vacuuming off knitting machine



In order to avoid any dust being deposited on the inaccessible points of the machine, we recommend that the dust should be vacuum cleaned and the machine not to be cleaned by compressed air.



NOTICE

Damage of needles!

The spring-mounted needle latches will be damaged if the needles are blown out with compressed air.

→ Always vacuum fluff and dust off the needles, never blow them out.


1. Stop the knitting machine.
2. Vacuum fluff and dust off the knitting machine.

6.2.4 Cleaning needle bed

The pelerine springs of the needles should be cleaned daily, however at least once a week. The entire needle bed is cleaned every 12 to 26 weeks.

Cleaning needle bed:

1. Transfer all stitches to the rear needle bed.
2. Slide open all covers over the needle bed.




Cleaning the needle bed

3. Push up all needles of the front needle bed completely.
4. Vacuum off dirt in the area of the needle hook/pelerine spring (1) and in the area of the needle bed (2).
5. Close all covers over the needle bed again.
6. Transfer all stitches to the front needle bed and clean the rear needle bed in the same way.

Further information:

- Thoroughly cleaning needle bed [▢323]
- Helpful knitting rows [▢352]

6.2.5 Cleaning thread clamping and cutting device




Cleaning thread clamping and cutting device

1. Push the clamping and cutting needle upward.
2. Clean the clamp and cutting needles and the clamping pinion with a cloth or a brush.
3. Push the clamping and cutting needle back upward.

6.2.6 Cleaning the active thread clamp


1. Bring the lateral yarn tensioner in still position. Thereby the active thread clamp is open.



Cleaning the active thread clamp

2. Blow the eyelets in the lateral safety door by compressed air.


6.2.7 Cleaning the permanent brakes



Cleaning the permanent brake

- Clean both the brake settings of each permanent brake with a cloth.

6.2.8 Cleaning the friction feed wheel *



Cleaning the friction feed wheel


1. Vacuum off the fluff and dust from the friction feed wheel.
2. Remove dirt (e. g. paraffin) from the friction rollers.

Further information:

- Symbols in this document [14]

6.2.9 Cleaning main drive fan *

1. Switch off the machine and wait until the machine is currentless.
2. Swing open the cover on the right-hand control unit.



Main drive fan

3. Clean fan.
4. Close the cover on the right control unit.
5. Switch on machine.




The control checks the motor temperature when switching on machine main switch. The fan only runs at higher motor temperature.

Further information:

- Symbols in this document [□ 14]

6.2.10 Cleaning fan and radiators in right control unit

1. Switch off the machine and wait until the machine is currentless.
2. Swing open the cover on the right-hand control unit.



Control unit


3. Vacuum-off and blow-out the fan (1) and heat sink (2).
4. Close the cover on the right control unit.
5. Switch on machine.



The fan is temperature-controlled.

6.2.11 Cleaning filter mat of power supply unit

1. Swing open the cover on the control unit.



Fan power supply unit

2. Remove screw (1) and hinge down the housing toward the front.
3. Remove filter mat and blow it out with compressed air.
4. If heavy soiling is present, vacuum off and blow out the radiator (2).
5. Replace filter mat.
6. Swing in the cover on the left control unit.


6.2.12 Thoroughly cleaning needle bed

The needle bed is cleaned daily by the operator. In addition, it must be cleaned thoroughly every 12 to 26 weeks.



If the needle bed is not cleaned thoroughly and carefully, a non-uniform stitch appearance results during production due to needles that do not run smoothly, and the operation of the machine can no longer be ensured.

Thoroughly cleaning needle bed:




Thorough cleaning of needle bed

- ✓ No fabric may be hanging on the needle bed.
- ✓ The required tools (groove cleaner and extraction hook) are included with the accessories.


1. Remove needle rail (4) with extraction hook (5).
2. Remove screw (3) on left and right-hand sides of jack bed.

Cleaning the knitting machine

3. Take off jack bed (1).
4. Remove needles, coupling part, intermediate slider and selector jacks.
5. In case of CMS 520 C and CMS 830 C take off the selection jack bed additionally.

NOTICE	
	<p>Dirt-caked needle channels due to oil or cleaning agent!</p> <p>When the needle channels are cleaned with oil or cleaning agent, the dirt swells up and clogs the needle channels.</p> <ul style="list-style-type: none"> → Do not clean needle channels with oil or cleaning agent. → Push dirt out of needle channels and blow out needle channels with compressed air.

6. Push dirt out of needle channels with groove cleaner (6).



Groove cleaner

7. Clean groove for pelerine spring of needle.
8. Blow out dirt with compressed air from the needle bed.
9. Make sure needles, coupling part, intermediate slider and selector jacks are undamaged.
10. Clean needles, coupling part, intermediate slider and selection jacks with oil.
11. Pull out wire (2) to enable jack bed to be guided into holding-down jacks more easily during assembly.
12. Reassembly needle bed.
13. Lubricate needles, coupling part, intermediate slider and selector jacks. If a central lubrication is installed, then use the setting "Initial lubrication" for approx. 15 minutes.




The needle hooks and the holding-down jacks can be cleaned quickly and easily with the needle bed cleaning apparatus (special attachment).

Further information:


- Removing selection jack bed (CMS 520 C and CMS 830 C) [▢371]
- Cleaning needle bed [▢320]
- Lubrication interval [▢327]
- Setting of central lubrication [▢329]

6.2.13 Clean the knitting systems

1. Stop the knitting machine.
2. Move the carriage assembly into the left reversing position.
3. Set the main switch to "0" and wait until the touch screen is switched off.
4. Remove the carriage part.

	NOTICE
	<p>Damage to the knitting systems!</p> <p>Dirt will be blown into the guides of the movable parts and the knitting systems will be damaged if they are blown out with compressed air.</p> <p>→ Always vacuum off the knitting systems, never blow them out.</p>

5. Vacuum off the knitting systems and selection systems.

	NOTICE
	<p>Damage to the selection systems and impulse givers!</p> <p>The selection systems and impulse givers will be damaged if they are cleaned with acetone or trichlorethylene (Tri).</p> <p>→ Clean the selector systems and pulse generators with a clean cloth.</p>

6. Clean the selector systems and pulse generators with a clean cloth.
 7. Check the cams for wear and damage.
 8. Apply oil to the cams with a brush.
 9. Set the carriage part on the needle bed again.
 10. Repeat step 4 to 9 for all carriage parts.
 11. Set the main switch to "1".
- ▶ The carriage position is re-referenced.

Further information:

- Removing and mounting carriage part [374]

6.3 Lubricate knitting machine

This chapter contains information on:

- Lubrication interval [▢327]
- Setting lubricating interval for needle bed [▢328]
- Setting of central lubrication [▢329]
- Oil needle bed [▢333]
- Restarting lubricating interval [▢334]
- Oiling jack bed [▢334]
- Oiling yarn carrier rods [▢335]
- Oiling the control of the holding-down jacks [▢335]
- Oiling carriage guide rail [▢335]
- Greasing impulse sensor rails [▢336]
- Greasing butts of the coupling parts and intermediate sliders [▢337]
- Oiling lifting slide (yarn carrier plunger) [▢337]
- Greasing racking device [▢338]
- Grease needle bed support/adjustment pieces [▢339]

6.3.1 Lubrication interval

To retain the operability of the knitting machine and ensure the quality of the fabric, the knitting machine must regularly be lubricated.

Lubrication interval	Lubricating work
adjustable Recommendation: Every 6 - 10 operating hours; select shorter interval if necessary	Oiling the needle bed
	CMS 520 C, CMS 830C: Greasing the coupling parts and the intermediate sliders
10 operating hours	Oiling the jack bed Oiling the yarn carrier rods Oiling the control of the holding-down jacks
100 operating hours	Oiling the carriage guide bar Greasing the impulse sensor rails Greasing the coupling parts and the intermediate sliders Oiling the lifting slide Greasing the control sliders (CMS 822)
6 months	Greasing the racking device Greasing the needle bed supports/adjustment pieces

Lubrication schedule

i Only the named lubricants or others recommended by Stoll may be used. Other lubricants may damage the machine, e. g. due to insufficient lubricating action, rust on metal parts or damage to the electrical cable insulation and the plastic parts. We point out here that failure to observe this, will void our warranty services.






Lubricants Use only the lubricants found with the accessories of the machine or those listed in the lubricating schedule.

	Label	Gauge	ID
Oil	Silvertex T46	E3 E3,5 E4 E5 E7 E8 E2,5.2 E3,5.2 E5.2 E10 E12 E14 E6.2 E7.2	230 614
	Silvertex T32	E16 E18 E8.2 E9.2	005 341
Bold	OKS 475		005 351
	Klueber Staburags NBU 12/300 KP		231 191

i In the first weeks after setting up the knitting machine, select shorter lubricating intervals.

6.3.2 Setting lubricating interval for needle bed

For the needle bed a lubricating interval of between 1 and 65.535 courses can be set. A mean value for a three-system machine is 25,000 courses. However, this value depends highly on: Machine speed, temperature and number of knitting systems. We recommend: Selecting a shorter lubricating interval instead of a longer one. After the lubricating interval expires, a message appears stating that the needle bed must be oiled.

Key	Function
	Call up the "Service" menu
	Call up the "Lubricating" menu
	Call up the "Lubricating - Needle bed" window
	Confirm input
	Call up "Main menu"

Keys for setting the lubricating interval

Set lubricating interval:

1. Call up the "Service" menu from the "Main menu".
2. Call up the "Lubricating" menu.
3. Call up the "Lubricating - Needle bed" window.




"Lubricating - Needle bed" window

4. Input "Syst. run through until lubricic."
5. If the machine is to be stopped after reaching the system run-throughs, then deactivate the check box.
6. Confirm input.
7. Call up "Main menu".

6.3.3 Setting of central lubrication






All machines with four or more knitting systems are equipped with a central lubrication as a standard equipment (not for CMS 822)



Lubrication points of the central lubrication

i

The needle bed and jack bed must be oiled manually before a new machine has been set up and for a machine which has been out of operation for a longer period of time or which has just had a gauge conversion. Then use the "Initial lubrication" setting for approx. 15 minutes.


Key	Function
	Call up the "Service" menu
	Call up the "Lubricating" menu
	Call up the "Central lubrication" window
	Confirm input
	Call up "Main menu"

Keys for adjusting the central lubrication

Lubricate knitting machine

Adjust central lubrication:

1. Call up the "Service" menu from the "Main menu".
2. Call up the "Lubricating" menu.
3. Call up the "Central lubrication" window.



"Central lubrication" window

4. Make settings.
5. Confirm input.
6. Call up "Main menu".

Field	Explanation
1	Switch on/off the central lubrication. Switch off the central lubrication: Observe the section "Switch off the central lubrication." [332]
2	Three settings are available for the lubrication interval: Initial lubrication: This setting is used for the initial lubrication of a new machine at the Stoll stoll factory. The values cannot be modified. (Caution - risk of soiling the fabric) Select this setting for approx. 15 minutes after a gauge conversion or with a machine, which has been out of operation for a longer period of time. STOLL inputs: This setting can be used for production. The values cannot be modified. The values cannot be modified. User settings: With this setting, the values can be changed by the user. (Attention: An improper setting could lead to insufficient oiling. Ensure that the central lubrication applies sufficient oil to the needle bed.)

Field	Explanation
3	Each setting consists of two values.
	Lubricat. process after system run-throughs: Setting of the number of knitting systems after which lubrication occurs. The lubrication procedure stretches across the current traversing path of the carriage.
	Lubrication processes until lubricating all needles: Setting of the number of lubrication procedures after which the entire needle bed is to be lubricated.
4	Number of system run-throughs since the last lubrication process
5	A lubrication procedure is triggered in the next carriage reversal. The entire needle bed is lubricated.
6	The oil line is de-aerated with this switch. The oil pump is switched on for max. 30 seconds. Use this switch for ventilation only, not for lubrication (Caution - risk of soiling the fabric).


"Central lubrication" window



All lubrication processes and operating actions are logged. The inputs can be read. For this purpose, call up the "additional function keys" and the "Central lubrication log" key in the "Central lubrication" window.

Lubricate knitting machine

Error messages If an error occurs in the area of the central lubrication, it is displayed on the touch screen.

Error Message	Explanation
Central lubrication oil reservoir almost empty	If a certain level is undershot, this message appears. It is always displayed until the oil is filled up or the oil level reaches the "Min" mark. The machine then stops and the "Oil reservoir empty" error message appears.
Central lubrication oil reservoir empty	Fill oil reservoir with oil until the "Max" mark has been reached. 
Central lubrication pressure switch	The oil pressure is monitored. If it is too low, this error message appears. Check oil line. If the oil line is OK, set the "Ventilation" switch to "On" and then to "Off" again. This switches the oil pump on again. If the error occurs again, the oil line must be deaerated, see [▢394].

Error messages for central lubrication

Further information:

- Switching off Central Lubrication [▢332]
- Deaerating oil line [▢394]

Switching off Central Lubrication

The central lubrication can be switched on and off. If it is switched off, observe the following points:

- monitoring of the lubrication interval is automatically activated.
Set lubricating interval [▢328]
(path: "Central lubrication" window -> additional function keys -> "Lubricating" window)
- The following lubrication tasks must be performed manually:
 - Oil needle bed [▢333]
 - Oil jack bed [▢334]

Further information:


- Setting lubricating interval for needle bed [▢328]
- Oil needle bed [▢333]
- Oiling jack bed [▢334]

6.3.4 Oil needle bed

When the lubricating interval for the needle bed expires, a pictograph appears stating that the needle bed must be oiled.



1. Apply oil with a brush or spray bottle.



Oiling needle bed (top: without central lubrication, center: with central lubrication)

2. With CMS 520 C, CMS 830 C:
The pictograms "Oil needle bed" and "Grease needle bed" are displayed alternately.
Start oiling the needle bed elements and then grease the butts of the coupling parts and intermediate sliders.
3. Brushes are attached at the side of the needle bed. Put some oil in the upper brush so that the cams near the coupling parts are oiled.
4. Oil the thread clamping and cutting device.
5. Restart lubricating interval. [▢334].


Further information:

- Restarting lubricating interval [▢334]


6.3.5 Restarting lubricating interval

1. Tap display for "Lubricate needle bed" message.
 - ▷ The "Current message" window appears.
2. Tap "624 Lubricate needle bed (OIL)" message.
 - ▷ The message is marked with a frame. The function key for opening the "Sensors" window appears at the bottom of the touch screen.
3. Call up the "Sensors" window.
4. Input "Syst. run through until lubricic."
5. Confirm input.
6. Call up "Main menu".

6.3.6 Oiling jack bed




Oiling the jack bed

	NOTICE
	<p>If a spray gun is used for oiling, too much oil may be applied!</p> <p>The suction tube becomes clogged.</p> <p>→ Do not use a spray gun for oiling.</p>

→ Use a brush to apply oil to the jack bed (1).


6.3.7 Oiling yarn carrier rods



Oiling the yarn carrier rods


1. Use a brush or a spray bottle to apply oil to the yarn carrier rods (1).
2. If intarsia yarn carriers are used, wipe off the oil with a cloth until the notch on the yarn carrier rod (2) is only coated with a residual lubricating film.

6.3.8 Oiling the control of the holding-down jacks



→ Apply oil on the control of the holding-down jacks with a brush.

6.3.9 Oiling carriage guide rail




Oiling the carriage guide bar

→ Use a cloth to apply oil to the carriage guide bar (1).

6.3.10 Greasing impulse sensor rails

Depending on the machine gauge, there is a front and a rear impulse sensor rail.

Machine gauge	Impulse sensor rail
E18 (E9.2) E16 (E8.2) E14 (E7.2) E12 (E6.2) E10 (E5.2)	front and rear
E8 E7 (E3,5.2) E5 (E2,5.2) E4 E3.5 E3	Back





Greasing the impulse sensor rails

→ Use a brush to apply grease to the impulse giver rails (1).

6.3.11 Greasing butts of the coupling parts and intermediate sliders


After every tenth "Oil needle bed" note appears a "Grease needle bed" pictograph.



Greasing the butts of the coupling part and intermediate sliders

→ Use a brush to apply grease to the butts of the coupling parts and intermediate sliders.


6.3.12 Oiling lifting slide (yarn carrier plunger)



1. Apply oil to the lifting slide with a brush.
2. Move the lifting slide several times with the finger so that the guide in the metal housing is oiled. There are two lifting slides per yarn carrier plunger

6.3.14 Greasing racking device

To ensure that the greasing of the racking spindle will not be forgotten, the "Grease racking spindle" message appears after 180 days.



Greasing racking device

1. Position the rear needle bed at an angle.
2. Remove the cover over the racking spindle.
3. Apply grease to the racking strip and to the sliding guidance with a brush.
4. Grease the lubricating nipple (1) with a grease gun (Klueber Staburags NBU 12/300 KP, ID 231 191)

Further information:

- Remove needle bed or position it at an angle [364]

Confirm the lubrication process


Key	Function
	Call up the "Service" menu
	Call up the "Lubricating" menu
	Call up the "Lubricating - Racking" window
	Call up "Main menu"

Keys for confirming the lubrication process

Confirm the lubrication process:


1. Call up the "Service" menu from the "Main menu".
2. Call up the "Lubricating" menu.

3. Call up the "Lubricating - Racking" window.



4. Confirm the lubrication process.
Tap on the "Confirm greasing" key for this.
5. Call up "Main menu".

6.3.15 Grease needle bed support/adjustment pieces



Greasing the needle bed supports/adjustment pieces

1. Position the needle beds at an angle.
2. Vacuum off fluff and dust.
3. Apply grease to needle bed supports with a brush.

Further information:

- Remove needle bed or position it at an angle [▢364]

7 Repairing the knitting machine

This chapter contains information on:

- Supplementary activities during maintenance [▢340]
- Helpful knitting rows [▢343]
- Replacing parts [▢345]
- Eliminating faults in electronics system [▢387]
- Check fuses [▢395]
- Needle selection displacement [▢404]
- Entering the data of the needle selection displacement manually [▢415]

7.1 Supplementary activities during maintenance





This chapter contains information on:

- Switching power supply 40 V off and on [▢340]
- Central lubrication - mounting and working position [▢342]

7.1.1 Switching power supply 40 V off and on

The power supply of the carriage (step motors, selection systems, yarn carrier plunger) can be switched off for assembling works. This eliminates the switching off and on of the main machine switch and thereby the waiting time until the computer of the knitting machine has shut down and rebooted.


The machine cannot be started with the engaging rod when the power supply is switched off.

Key	Function
	Call up the "Service" menu
	Call up window "Manual interventions Service"
	Confirm message
	Call up "Main menu"

Keys for switching power supply 40 V off / on

Switch power supply off and on again:

1. Call up the "Service" menu from the "Main menu".
2. Call up from "Service" window "Manual interventions Service".



Window "Manual interventions Service"

3. Tap the "Off" switch if the "40 Volt power supply" is to be switched off. Answer the message "Switch off?" with "Yes".
- or -
→ Tap the "On" switch if the "40 Volt power supply" is to be switched on. Tap the "Confirm message" key. The machine is ready for operation.
4. Call up "Main menu".

7.1.2 Central lubrication - mounting and working position


Only on machines with central lubrication

The central lubrication can be swiveled upward for mounting activities, e.g. to remove the carriage part.

Mounting position

Swivel central lubrication into mounting position:

1. Swivel central lubrication upward (approx. 100 degrees).




Mounting position of central lubrication


2. Move central lubrication downward somewhat until it stops.

Working position

Swivel central lubrication into working position:

	DANGER
	<p>Central lubrication in mounting position!</p> <p>If the machine is started and the carriage moves outward, the side safety door could be thrown open.</p> <p>→ Swivel central lubrication into working position.</p>

1. Move central lubrication upward somewhat until the lock is released.



Swiveling central lubrication into working position




2. Swivel central lubrication downward until it touches the carriage.

7.2 Helpful knitting rows

When carrying out cleaning, adjustments and repair work, it is helpful to set a certain knitting situation immediately. The following table lists the knitting specifications mentioned in the operating instructions.

	Knitting specifications
Empty row	< > S0 W0 Or: Tap in window "Machine start" on the key "SPF S0".
Empty row with transfer racking	< > VU S0 W0
Empty row with half racking	< > V# S0 W0
Transfer row to the rear (R = all needles)	< > S:U^SR; S1
Transfer row to the front	< > S:UVSR; S1

Knitting specifications

Key	Function
	Switch on Sintral editor
	Call up "Machine start" window
	Call up "Main menu"


Keys for entering a knitting row

Enter and fix a knitting row:

1. Stop the carriage shortly after the left reversing position.
2. Call up the Sintral Editor.
3. Position the cursor accordingly (e.g. on line 998) in the Sintral program.
4. Enter the knitting row using the virtual keyboard.
For example, you may want to enter a transfer row to the rear on line 998.
The specifications are as follows: 998 < > S:U^SR; S1
5. Confirm input and return to the "Main menu".
6. Call up the "Machine start" window.

Replacing parts

7. In the "SPF line fixed" line, tap the "Line: 999" field and enter the line number "998".



"Machine start" window

8. Fix this line by tapping the "SPF line fixed" key and engaging the machine.
 ▷ The knitting specification is carried out after the next reverse.
9. Stop the carriage if it is in the left reverse again.
10. Carry out work on the knitting machine.
11. To resume production tap in the window "Machine start" on the key "SP from line 1" and engage the machine.



An empty row is entered on line 999 in a STOLL knitting program.



For the first 2 knitting rows after "SPF", the carriage moves over the entire needle bed.


7.3 Replacing parts

This chapter contains information on:

- Replacing needle and coupling part [▢346]
- Replacing intermediate slider [▢348]
- Replacing selection jack [▢351]
- Replacing holding-down jack [▢352]
- Remove needle bed or position it at an angle [▢355]
- Repairing needle bed and additional needle bed [▢358]
- Removing selection jack bed (CMS 520 C and CMS 830 C) [▢362]
- Removing and mounting carriage part [▢365]
- Removing cam plate [▢373]
- Removing and mounting step motor [▢374]
- Replacing gear racks in the step motor [▢375]
- Replacing yarn carrier [▢379]
- Mount intarsia yarn carrier * [▢380]
- Replacing yarn control unit [▢382]
- Replacing drive belts and friction roller of friction feed wheel [▢382]
- Deaerating oil line [▢385]
- Replacing comb hook [▢386]

Replacing parts

7.3.1 Replacing needle and coupling part




Replacing needle and coupling part

with all machines
(Exception: CMS 830 C)


1. Pull-out the needle rail (1) with the extraction hook (6).
2. Pull needle (2) upwards, the coupling part (3) will, with it, also be pulled upwards.
3. When the butt of the coupling parts (4) bumps into the holding-down jack bed, press the coupling part downward. Pull out the needle and coupling part upward.

- or -

- With CMS 520 C: The end of the coupling part bumps into the wire (5), and must therefore be pushed harder.




4. Assemble the new needle and coupling part.
5. To mount the new needle and coupling part, push the butt of the coupling part through into the needle bed under the jack bed. While doing so, make sure that the needle is guided in above the knock-over wire.



Replacing needle
(CMS 830 C)

1. Pull needle (2) upwards, the coupling part (3) will, with it, also be pulled upwards.



Replacing needle and coupling part

2. If needle butt bumps into needle rail, tilt needle laterally so that the connection needle-coupling part is loosen. Should this be difficult, then provide help with a knitting hook. Push coupling part downward and return needle to straight position. Pull out needle upward.
3. Install the new needle in the reverse order. Lift coupling part a little by means of pliers.

Replacing coupling part
(CMS 830 C)

1. If a coupling part must be replaced, then remove the corresponding needle. Lift upper end of coupling part out of needle bed with a needle or a knitter hook. Push coupling part upwards by means of pliers and lift it out of needle bed.



Removing a coupling part

2. Inserting a new coupling part. Put pliers above butt of coupling part and then push coupling part downwards by means of pliers.



Inserting a coupling part

3. Reassemble needle.

7.3.2 Replacing intermediate slider

There are different models depending on the machine type and the gauge.


Type 1

Valid for:

CMS 822, CMS 530, CMS 520

E10 | E12 | E14 | E16 | E18 | E6.2 | E7.2 | E8.2 | E9.2

To replace the intermediate slider, you need a small pair of pliers.



Replacing the intermediate slider

1. Push the needle and coupling part (1) upward.
2. Using the pliers, pull the lower butt of the intermediate slider (2) downwards out of the needle bed while pressing the upper butt into the needle bed and pressing it under the cover rail (3).
3. Install the new intermediate slider in the reverse order.
4. Slide the needle and coupling part into the home position.

Type 2

Valid for:


CMS 822, CMS 530, CMS 520

E5 | E7 | E8 | E2,5.2 | E3,5.2 | E5.2

CMS 740, CMS 730 T, CMS 530 T, CMS 502

all gauges

To replace the intermediate slider, you need a small pair of pliers.



Replacing the intermediate slider

1. Push the needle and coupling part (1) upward.
2. Push the intermediate slider (2) until the lower butt bumps into the cover rail (3).
3. Pull the upper butt of the intermediate slider out of the needle bed while pressing the lower butt into the needle bed and under the cover rail.
4. Install the new intermediate slider in the reverse order.
5. Slide the needle and coupling part into the home position.

Replacing parts


Type 3

Valid for:

CMS 830 C, CMS 520 C

all gauges


To replace the intermediate slider, you need a small pair of pliers.



Replacing the intermediate slider

1. Push the needle and coupling part (1) upward.
2. Push the spring wedge (3) to the side.
3. Pull out the intermediate slider (2) upwards.
4. Install the new intermediate slider in the reverse order.
5. Slide the needle and coupling part into the home position.

7.3.3 Replacing selection jack



Replacing selection jack (right picture: CMS 520 C and CMS 830 C)


1. Push the needle with the coupling part upward.
2. Push the intermediate slider (1) until the lower butt bumps into the spring wedge (2).
3. Push the selection jack (3) upward until it bumps into the cover rail (4).
4. Press the butt (5) of the selection jack into the needle bed while at the same time sliding the selection jack further upward.
5. Remove the selection jack.
6. Install the new selection jack in the reverse order.
7. On the CMS 520 C and CMS 830 C, make sure when inserting the new selection jack that the butt of the selection jack is behind the butt of the intermediate slider.
8. Slide the intermediate slider in home position.
9. Slide the needle and the coupling part into the home position.

Replacing parts

7.3.4 Replacing holding-down jack


Not with CMS 830 C

1. Transfer all stitches of the needle bed in which the jack is replaced to the other needle bed.



Removing the limiter (3)

2. Remove screw (1) on left and right-hand sides of jack bed. Use the special hexagon screwdriver from the accessories for this purpose.
3. Loosen the screw (2) on the left and right-hand sides of the jack bed.
4. Remove the limiter (3) on both sides.




Replacing a jack

5. Pull out wire (4) and, with gauges E3,5.2, E5.2, E6.2, E7.2, E8.2, E9.2 (with 72", 84") wire (6) as well, up to the point of repair. When doing so, always guide in the replacement wire from the accessories after it from the other side of the machine so that the jacks do not fall out of the needle bed.
6. Pull out the wire (5).
7. Take out the holding-down jack from above and insert a new one.
8. Reassemble the needle bed in the reverse order.


With CMS 830 C Replacing spring of holding-down jack:

1. Transfer all stitches of the needle bed in which the jack is replaced to the other needle bed.



Push spring into "Position open"

2. Push all springs (1) of the holding-down jacks into the rear position (2).
3. Remove screw (3) on left and right-hand sides of jack bed.
4. Pull out the wire (4) up to the point of repair.
5. Push defective spring into the front position and pull out upward.
6. Push holding-down jack (5) into "Position closed" and insert new spring. While doing so, the holding-down jack is pushed into "Position open" again. Make sure that the spring lies under the spring wedge (6) and is located in the rear position (2).




Replacing spring

7. Assemble in reverse order.
- or -
- Replace holding-down jack.


Replacing parts

Replacing holding-down jack:

1. Once work has been carried out on the front needle bed, then position the needle bed at an angle. This enables the wires to be pulled out more easily.




2. Loosen screws (1) and (2) on the left and right sides of the jack bed. Use the special hexagon screwdriver from the accessories for screws (1).
3. Remove the limiter (3) on both sides.
4. Push all springs (5) of the holding-down jacks into the rear position (6).
5. Remove screw (7) on left and right-hand sides of jack bed.
6. Pull out the wire (4). Push the springs toward the front carefully until force is no longer being applied to the holding-down jacks.



Push springs toward the front

7. Pull out the wire (5) and (6) up to the point of repair.



Pulling the wires out

8. Remove the spring of the defective holding-down jack.
9. Take out the holding-down jack (7) together with the support (8) upward. Insert new holding-down jack and support.
10. Reassemble the needle bed in the reverse order.


Further information:

- Helpful knitting rows [▢343]
- Remove needle bed or position it at an angle [▢355]

7.3.5 Remove needle bed or position it at an angle

This chapter contains instructions on:


- Releasing needle bed
- Removing needle bed
- Positioning the needle bed at an angle
- Screwing on the needle bed tight

Key	Function
	Call up "Manual interventions" window

Key for calling up "Manual interventions" window


Releasing needle bed on all machines (exception: CMS 520 C, CMS 830 C)

1. Transfer all stitches of the needle bed to be removed or positioned vertically to the other needle bed.
2. When the carriage assembly is in the left reversing position, stop the machine with the engaging rod. If a central lubrication is present, the carriage must be in the left reversing position.
3. Tap the "Rel. drive brake" key in the "Manual interventions" window and slide the carriage assembly to the left up to the stop.
4. Remove two screws (2) on each side of the machine.



Releasing needle bed

5. Releasing the rear needle bed for gauge E 10 - E 18 (CMS 502: E16, E18, E8.2): Remove the screws (3). Push the connection (4) to the side. While doing so, the impulse sensor rail is pushed to the side.




Link of the impulse sensor rail

Replacing parts

Remove needle bed or position it at an angle

1. Front needle bed: Swivel towards the front carefully and lean it against the machine covering.
2. Rear needle bed: Remove the needle bed from the machine with two persons.

Screwing on needle bed tight



Installing front and rear needle beds

→ Reassemble the needle bed in the reverse order. When doing so, make sure that the needle bed contacts the pin (1) and the roller (2).


Release needle bed CMS 520 C, CMS 830 C

The selection jack bed is fixed on the needle bed. If the needle bed is positioned at an angle, the selection jack bed bumps into the cover (6) of the carriage guide bar. There is a danger of the selection jack being damaged.

✓ Spacer (2): 200 x 20 x 40 mm, 1 piece


✓ Spacer (4): 50 x 20 x 40 mm, 2 pieces

1. Transfer all stitches of the needle bed to be removed or positioned vertically to the other needle bed.
2. When the carriage assembly is in the left reversing position, stop the machine with the engaging rod.
3. Tap the "Rel. drive brake" key in the "Manual interventions" window and slide the carriage assembly to the left up to the stop point.
4. Remove two screws (1) on each side of the machine.




5. Lay the spacer (2) on the carriage guide bar on the left machine side.
6. Lift the needle bed with a lever (3) enough to be able to slide the spacer (4) under the needle bed support (5).


7. Lay the spacer (2) on the carriage guide bar on the right machine side.



8. Lift the needle bed with a lever (3) enough to be able to slide the second spacer (4) under the needle bed support (5).
9. Lay the spacer (2) on the carriage guide bar on the left machine side.



10. Lift the needle bed with a lever (3) enough to be able to slide the spacer (4) completely under the needle bed support (5).
11. Position the needle bed at an angle and secure against tilting.




Replacing parts

Remove needle bed or position it at an angle

1. Front needle bed: Swivel towards the front carefully and lean it against the machine covering.
2. Rear needle bed: Remove the needle bed from the machine with two persons.


Screwing on needle bed tight



Installing front and rear needle beds

→ Reassemble the needle bed in the reverse order. When doing so, make sure that the needle bed contacts the pin (1) and the roller (2).

7.3.6 Repairing needle bed and additional needle bed



Damaged needle bed

If the carriage is blocked, the needle bed may be damaged. This means that the movable parts (needles, coupling part, intermediate slider and selection jack) do not move smoothly or are blocked. This damage must be eliminated carefully and conscientiously before the machine is started up again. If it is not, a risk of the carriage blocking again immediately and damaging the needle bed again is present.


When performing repairs, the needle bed types must be determined. There are two different versions: milled and combined needle beds. The additional beds are always milled.

Needle bed	Description
Milled	The grooves for the moving parts have been cut out of the needle bed.
Combined	The needle bed is composed of individual stays. They are inserted into a base plate and screwed down.




Repairs must be carried out very carefully and without the use of force.

- Milled needle bed
1. If the carriage blocks, then separate the connection of the carriage part to the carriage. Move carriage to the next reversal point. Lift carriage part from needle bed. Check cam parts for damage and remove broken working butts from the moving parts.
 2. Find the channel chisel and channel file accessories.
 3. Remove the movable parts (needle, coupling part etc.) at the point of damage.
 4. Set damaged stays into a vertical position again using the channel chisel and straighten them. The chisel may only be struck with light hammer blows in the damaged groove. Do not strike the chisel in too deep, as the needle bed foundation will be damaged.




Positioning stays vertically

5. Take a needle or selector jack from this machine and place it into the repaired groove. Push the needle up and down in the groove. If it moves easily, check whether the moving parts of the neighboring grooves move easily as well.
6. If this is not the case, repeat Steps 4 and 5.
7. Do this for all damaged grooves. The grooves to the left and right of the point of damage must move easily as well.
8. If the damaged stays are bent upward, knock them even (smooth) again using the channel chisel.




Smoothing surface

9. Check whether the needle bed elements move easily in the grooves. Repeat step 5.

NOTICE	
	<p>The needle bed may be damaged if the channel file is used improperly!</p> <p>If too much of a stay is filed off, the needle bed is defective at this point and can only be repaired by a Stoll technician.</p> <ul style="list-style-type: none"> → Use the channel file for the removal of burrs only. → The grooves must be cleaned carefully after the channel file is used.

10. Check whether the edges of the damaged stays have burrs. If this is the case, carefully remove these burrs with the channel file.



Removing burrs


11. Check whether the needle bed elements move easily in the grooves. Repeat step 5.
12. If everything is in order, carefully polish the needle bed with the channel file. Place the channel file flat on the needle bed and lightly move it back and forth perpendicular to the needle channel.
13. The metal debris must be removed from the needle channels. For this purpose, clean the area of repair with a brush.
14. If everything is in order, reinsert the moving parts into the needle bed.

Further information:

- Removing and mounting carriage part [▢365]
- Replacing needle and coupling part [▢346]
- Replacing intermediate slider [▢348]
- Replacing selection jack [▢351]

Combined needle bed If a stay of a combined needle bed is slightly damaged, it can be repaired as described above. It must be replaced if it is heavily damaged, though.

1. If the carriage blocks, then separate the connection of the carriage part to the carriage. Move carriage to the next reversal point. Lift carriage part from needle bed. Check cam parts for damage and remove broken working butts from the moving parts.
2. Remove needle bed. Place the needle bed on a level surface (e.g. workbench or table).
3. Remove the movable parts (needle, coupling part etc.) at the point of damage.
4. Remove the holding-down jacks at the point of damage.
5. Remove safety device and pull out wire (1).



Repairing a combined needle bed


6. Remove the bar (2) at the point of damage.
7. Lift the damaged stay at the rear end (3) and carefully pull it out toward the back.
8. Remove the debris near the removed stay.
9. Spare stays are found among the machine accessories. Use a new stay from the accessories.
10. Reassemble the needle bed in the reverse order. Tighten the screws used to secure the bar (2) to a torque of 2.6 Nm. Return the needle bed to the machine.

Further information:

- Removing and mounting carriage part [▢365]
- Remove needle bed or position it at an angle [▢355]
- Replacing needle and coupling part [▢346]
- Replacing intermediate slider [▢348]
- Replacing selection jack [▢351]
- Replacing holding-down jack [▢352]


7.3.7 Removing selection jack bed (CMS 520 C and CMS 830 C)

- with CMS 520 C
1. Stop the carriage assembly into the left reversing position.
 2. Remove two screws (1) on each side of the machine.




Releasing the selection jack bed

3. Remove the screws (2) over the entire length of the selection jack bed.
4. Push the intermediate sliders (3) into its highest position.




Lifting selection jacks

5. Push the selection jacks (4) into their highest position.
6. Starting from one side, lift the selection jacks at their top end while simultaneously pushing the wire (5) out of the accessory between the selection jack bed and the selection jack. Carry this out over the entire length of the selection jack bed. The wire must be pushed in so that the working butts of the selection jacks stick out so high that they touch neither the intermediate slider nor the needle bed.
7. Push the selection jack bed to the side. The front bed to the left and the rear bed to the right. (Use a rubber mallet, if necessary.)
8. Take off the selection jack bed.
9. When mounting the selection jack bed, make sure that it rests on the pin (6).





Installing selection jack bed

- with CMS 830 C
1. Stop the carriage assembly into the left reversing position.
 2. Remove needle bed. Lay the needle bed on a flat surface (e.g. workbench or table).
 3. Push the intermediate sliders (1) into their highest position.



Lifting selection jacks

4. Remove two screws (2) on each side of the machine.




Releasing the selection jack bed

5. Remove the screws (3) of the clamping pieces (4) over the entire length of the selection jack bed.
6. Loosen both grub screws (5) at each clamping piece. Move clamping piece to the side and remove it.
7. Push the selection jacks (6) into their highest position.
8. Starting from one side, lift the selection jacks at their top end while simultaneously pushing the wire (7) out of the accessory between the selection jack bed and the selection jack. Carry this out over the entire length of the selection jack bed. The wire must be pushed in so that the working butts of the selection jacks stick out so high that they touch neither the intermediate slider nor the needle bed.
9. Take off the selection jack bed.

Replacing parts

10. When mounting the selection jack bed, make sure that it rests on pin (8).



Installing selection jack bed

11. Mounting the clamping pieces: Insert clamping piece and push it to the side. Secure it with the screw (3) and then tighten the grub screws (5).

Further information:

- Remove needle bed or position it at an angle [↻355]

7.3.8 Removing and mounting carriage part

Removing carriage part


The carriage part is removed when:

- the cams must be replaced (e.g. wide or narrow coupling of tandem machines)
- a carriage part blocks, e.g. when working butts of the movable parts (needle, coupling part, intermediate slider, and selection jack) are broken.

This chapter contains information on:

- Remove the carriage part to replace the cams [▢365]
- Remove the carriage part when the carriage assembly is blocked in the needle bed [▢367]
- Assembling carriage part and carriage assembly [▢370]

Remove the carriage part to replace the cams

Key	Function
	Call up "Manual interventions" window


Key for calling up "Manual interventions" window

1. If a central lubrication is present, swivel it into mounting position.
2. Move the carriage assembly outward up to the support surface.
3. Switch off 40 V power supply.
4. Remove the carriage assembly panelling (1).



Panelling of carriage assembly

5. If the rear carriage part is removed, the needle detector is to be removed as well.




Needle detector

6. Mark the position of the needle detector so that it can be reassembled in the same position.


Remove the carriage part to replace the cams Replacing parts

7. Remove the suction tube on the carriage assembly.
8. Unscrew the shoulder screws (2) and screws (4) on the left and right sides.



Swiveling plate

9. Swivel left and right swiveling plates (5) inward.



Opened carriage assembly

10. Loosen the screws on the plugs (3) and pull out the plugs.
11. To release the drive brake, tap the "Rel. drive brake" key.
("Main menu" -> "Manual interventions service" window, "Release drive brake" key)
12. Push away the carriage assembly.

**If the carriage assembly is blocked:**

The drive brake has automatically closed.

- Release the drive brake again and continue pushing the carriage assembly in the original direction.

13. Lift the carriage part off the support surface.

- or -

- Open the side safety door hood and lift out the carriage part to the side.
14. To replace the cams, turn the cam plate upward.


Further information:

- Switching power supply 40 V off and on [▢340]
- Central lubrication - mounting and working position [▢342]
- Removing cam plate [▢373]

Replacing parts Remove the carriage part when the carriage assembly is blocked in

Remove the carriage part when the carriage assembly is blocked in the needle bed

In the case of a shock on the needle bed, e.g. in the case of needle breakage, the piezo-electric shock stop switches off the knitting machine. On the touch screen a pictograph appears showing on which needle bed the fault occurred.



Possible causes:

- Working butts of the movable parts (needle, coupling part, intermediate slider, and selection jack) are broken
- Thereby it is possible that trick walls got damaged as well.

Before starting to operate the machine, you have to eliminate the fault. Otherwise, the carriage assembly might block again immediately. To eliminate the fault you need to remove the corresponding carriage part from the needle bed. Check the cams and the needle bed for possible damage.

Remove the carriage part from the needle bed



On tandem machines both carriage parts (front or rear) are raised, even if only one is blocked.

Key	Function
	Call up "Manual interventions" window

Key for calling up "Manual interventions" window


1. Call up "Manual interventions" window.
2. To switch off the needle selection, set the "Needle selection" switch to "Off".
3. To switch off all yarn carriers, tap the "YC bolt Up" key.
4. Push all yarn carriers outward.
5. If a central lubrication is present, swivel it into mounting position.
6. Switch off 40 V power supply.
7. Remove the carriage assembly panelling (1).



Panelling of carriage assembly


Remove the carriage part when the carriage assembly is blocked in the needle bed

8. If the rear carriage part is removed, the needle detector is to be removed as well.




Needle detector

9. Mark the position of the needle detector so that it can be reassembled in the same position.
10. Remove the suction tube on the carriage assembly.
11. Loosen the shoulder screws (2) and screws (4) on the left and right sides.



Swiveling plate

12. Swivel left and right swiveling plates (5) inward.
13. Tighten shoulder screws (2) and screws (4) evenly; the carriage part is raised off the needle bed in the process.
14. Loosen the screws on the plugs (3) and pull out the plugs.




Opened carriage assembly

15. To lower the carriage part again, loosen the shoulder screws (2) and screws (4) on the left and right-hand sides.
16. Remove the shoulder screws (2) and screws (4).

Replacing parts Remove the carriage part when the carriage assembly is blocked in

17. To release the drive brake, tap the "Rel. drive brake" key.
("Main menu" -> "Manual interventions service" window, "Release drive brake" key)

NOTICE	
	<p>Damage to needles and knitting system!</p> <p>There are still needles in the knitting system. If the direction is changed when moving the carriage assembly, the needles and knitting system will be damaged.</p> <p>→ Never change the pushing direction of the carriage assembly.</p>

18. Push away the carriage assembly.



If the carriage assembly is blocked:

The drive brake has automatically closed.

- Release the drive brake again and continue pushing the carriage assembly in the original direction.

19. Lift carriage part from needle bed.



With CMS 520 C, CMS 830 C there is a danger of the selection jacks being damaged if the carriage part is lifted off directly from the needle bed.

The reason for this: The carriage part engages under the upper end of the selection jacks.

- Lift the carriage part in the direction of the "Yarn carrier rods".

- Lift carriage part from needle bed.

20. Check the carriage part and the needle bed.



Do not remove metallic parts and fragments (e.g. broken needle latch or hook) with a magnetic tool. There is a danger that the needle bed or cams can be magnetized, leading to incorrect selection.

Check the carriage part and the needle bed

1. Check the cams for damage.
Remove broken working butts of the movable parts (needle, coupling part, intermediate slider, and selection jack).
2. Check the needle bed for damage.
Remove broken working butts of the movable parts (needle, coupling part, intermediate slider, and selection jack).
If trick walls are damaged, they have to be repaired.

Further information:


- Central lubrication - mounting and working position [▢342]
- Switching power supply 40 V off and on [▢340]

Assembling carriage part and carriage assembly Replacing parts

Assembling carriage part and carriage assembly

Please observe with a machine with clamping and cutting bed:

If the front carriage part is returned to the machine, it needs to be pushed from outside on to the support surface (1). The reason for this: The movable parts in the clamping and cutting bed will be pushed by the carriage part (more exactly: by the cam box curve) into their correct positions.







Support surface of carriage part

Preparations, machine with and without clamping and cutting bed

Please observe the following procedure:


		Procedure
Front needle bed	with clamping and cutting bed	<ul style="list-style-type: none"> ◆ Open the lateral safety door (on the left or right side) ◆ Push the carriage part from outside on to the support surface (1). ◆ Push the carriage part inward enough to position it above the clamping and cutting bed.
	without clamping and cutting bed	<ul style="list-style-type: none"> ◆ Position the carriage part on the support surface (1) (on the left or right side)
Rear needle bed		<ul style="list-style-type: none"> ◆ Open rear panel segments ◆ Position the carriage part on the support surface (1) (on the left or right side)

Replacing parts Assembling carriage part and carriage assembly

Key	Function
	Call up "Manual interventions" window
	Confirm the repair
	Call up "Machine start" window
	Call up "Main menu"

Keys for assembling carriage part and carriage assembly

1. Switch on 40 V power supply.
2. Call up "Manual interventions" window.
3. To release the drive brake, tap the "Rel. drive brake" key.
4. Push the carriage assembly directly over the carriage part.
5. Switch off 40 V power supply.
6. Screw in the shoulder screws (3) until the carriage assembly is raised somewhat.



Fastening carriage assembly on carriage part

7. Swivel the left and right swiveling plates outward below the carriage assembly.
8. Tighten both shoulder screws (3) for fastening the carriage assembly.
 - i** Assembly of the rear carriage part: pull the upper area of the carriage part (needle brushes) away from the needle bed to ensure that the shoulder screw does not cant.
9. Tighten screws (4) evenly.
10. Plug in the plugs (2) while watching the plug coding.
11. Tighten the safety screws on the plugs.
12. Place the yarn carriers in their starting positions.
13. Mount the carriage assembly panelling.
14. Mount the suction tube on the carriage assembly.

15. If a central lubrication is present, swivel it into working position.
16. Switch on 40 V power supply.
17. Call up "Main menu".
18. Call up "Machine start" window.
19. Tap the "SPF line fixed" key.
20. Start the machine with the engaging rod.
21. Only if the carriage assembly was blocked: If the carriage stops after the left reversion, set the needle selection to "On" in the "Machine start" window.
22. Tap in "Machine start" window on key "SP from line 1" to start production.


Further information:

- Switching power supply 40 V off and on [▢340]
- Central lubrication - mounting and working position [▢342]

7.3.9 Removing cam plate


The cam plate is removed for cleaning, checking or replacing cams or step motors.

1. Switch off 40 V power supply.
2. Remove the carriage part.




Plugs of the selection systems

3. Disconnect the plugs of the step motors (1) and selection systems (2).
4. Remove the screws (3).



Screws for cast body on cam plate

5. Loosen screws (4). Pull control (5) of holding-down jacks a little bit to the front. Thus, the cam plate is not blocked by control (5) anymore.



Control of holding-down jacks

6. Turn over the carriage part so that the cam plate is located at the bottom, making sure that the cam plate and the carriage part (cast body) do not separate.
7. Remove the carriage part.
8. Carry out work on cams or step motors.
9. Reassemble the cam plate and carriage part in the reverse order.


Further information:

- Switching power supply 40 V off and on [▢340]
- Removing and mounting carriage part [▢365]
- Remove the carriage part to replace the cams [▢365]

7.3.10 Removing and mounting step motor

Each knitting system contains a step motor which controls the stitch cam position.

1. Remove the carriage part.
2. Remove the cam plate.



Removing step motor

3. Move defective step motor to home position: Turn the scale (2) until the pointer (1) is positioned exactly on the zero point (3).




NOTICE

Adjusting screws!

If adjusting screws are released, the step motor must be readjusted at STOLL.

→ Do not loosen any adjusting screws (5).

4. Remove the screws (4).
5. Take off the defective step motor.
6. Move new step motor to home position: Turn the scale (2) until the pointer (1) is positioned exactly on the zero point (3).
7. Press the mechanics (pressure part tuck) downward to be able to insert the roller (6) in the gear rack of the step motor.



8. Mount the step motor. If this is not possible, repeat step 7.
9. Screw on the screws (4) tight.
10. Reassemble the cam plate and carriage part in the reverse order.

Further information:

- Removing cam plate [373]
- Removing and mounting carriage part [365]

7.3.11 Replacing gear racks in the step motor

There are different models depending on the machine type and the gauge.

Type 1


Valid for:

CMS 530, CMS 520, CMS 822, CMS 933, CMS ADF-3


E10 | E12 | E14 | E16 | E18 | E6.2 | E7.2 | E8.2 | E9.2

Replacing gear racks:

1. Take off the step motor.
2. Rotate positioning disk (1) to the mounting position (5 o'clock).



3. Turn over the step motor and check the mounting position.
The adjustment is correct if
The upper gear rack (2) and the boring are aligned.
The lower gear rack (3) and the boring are aligned.




- 2 upper gear rack
- 3 lower gear rack

Control of the stitch tension


Control of the pressure parts for tuck and stitch take over

- Remove the screws (4) for the defective gear rack.



- Remove carefully the guide strip (5) and the gear rack.
- Replace defective gear rack.
- Mount the new gear rack and the guide bars.
- Check whether the gear racks are positioned correctly. For this purpose, turn the positioning disk (1) to the home position (6 o'clock).

▷ The gear racks must be aligned.



- If this is not the case, repeat steps 2 till 8.


► The gear rack is replaced.

Type 2

Valid for:
CMS 530, CMS 520, CMS 822, CMS 933, CMS ADF-3
E5 E7 E8 E2,5.2 E3,5.2 E5.2
CMS 740, CMS 730 T, CMS 530 T, CMS 502, CMS 830 C, CMS 520 C
all gauges


Replacing gear racks:

- Take off the step motor.
- Rotate positioning disk (7) to the home position (6).




Step motor home position

3. Set at the rear the left pin of the lower gear rack guide.



Pin of gear rack guide


4. Push lower gear rack manually to the left until all gear racks can be removed.
5. Replace defective gear rack.
6. Set the installation position. For this purpose, turn the serrated lock washer (1) in such a way that the right edge is positioned somewhat in front of the light barrier (2). (visually expressed: if this setting were on a clock, the time would be: 11:58)



Built-in position

7. In this installation position, push in the gear rack (3) from the left until light resistance can be felt.
 - ▷ The gear rack contacts the pinion.
8. Push in gear rack (5) as well.
9. Push in gear rack (4) from the right until light resistance can be felt.
 - ▷ The gear rack contacts the pinion.
10. Push gear racks (3) and (4) inward evenly.
 - ▷ Gear rack (5) is automatically pulled inward when gear rack (4) is pushed.
11. Check whether the gear racks are positioned correctly. For this purpose, turn the positioning disk (7) to the home position (6).

12. The gear racks must be aligned.



Monitoring of built-in position

13. If this is not the case, repeat step 3 through 11.

14. Move pin of the lower gear rack guide at the rear to the home position.

► Replacement of the gear racks is complete.

Further information:


- Removing and mounting step motor [▢374]

7.3.12 Replacing yarn carrier



When replacing the yarn carrier bow, ensure that the punch mark is located on the inside when mounting shim (2).

1. Stop the carriage assembly into the left reversing position.



Screws of the yarn carrier limiter





2. Loosen the screws (1) of the yarn carrier limiter.
3. To remove the yarn carrier limiters, turn the screws (1). The yarn carrier limiters can be removed and mounted in any position.
4. Shift yarn carrier to the right or left to the replacement point (A) and remove it.
5. Place new yarn carriers on the rails.
6. Place the yarn carrier limiters of yarn carriers on the rails, position them in a staggered way and screw them on tight.
7. Check the adjustment the yarn carrier.

Further information:

- Adjusting yarn carriers [201]


7.3.13 Mount intarsia yarn carrier *

Combination possibilities for normal and Intarsia yarn carriers:

<p>Normal yarn carrier type 1</p>	<p>Normal and intarsia yarn carriers can be used side by side but not on the same track.</p>  <p>Reason: The disengaging arms (1) of the normal yarn carrier collide with the intarsia yarn carrier or the yarn carrier limiter.</p> <p>The combination possibilities:</p>  <p>Each combination can be used with itself or with another combination.</p> <p>i: Equip the yarn carrier tracks from inward to outward. With the allocation from inward to outward no track must be kept empty when using intarsia and normal yarn carriers.</p>
<p>Normal yarn carrier type 2</p>	<p>Normal yarn carriers type2 and intarsia yarn carriers can be used together on the same track.</p>  <p>The combination possibilities:</p>  <p>You can equip the yarn carrier rails as desired. You can equip all the tracks.</p>


Mount intarsia yarn carrier:

1. Stop the carriage assembly into the left reversing position.




Yarn carrier limiter

2. Loosen the screws (3) of the yarn carrier limiter.
3. To remove the yarn carrier limiters, turn the screws (3). The yarn carrier limiters can be removed and mounted in any position.
4. Shift normal yarn carrier to the right to replacement point (A) and remove it.
5. Mount the intarsia yarn carriers and push them into their starting positions. To do this, press the clamp (1) outward or the lifter (2) inward.



Intarsia yarn carrier

6. Place the yarn carrier limiter on the rails so that the ramp faces outward.




7. Position the yarn carrier limiters of yarn carriers in a staggered way and screw them on tight.
8. Check the adjustment the yarn carrier.

Further information:

- Symbols in this document [▢14]
- Intarsia yarn carrier * [▢30]
- Adjusting intarsia yarn carrier (type 1) * [▢204]
- Adjusting intarsia yarn carriers (type 2) * [▢205]

7.3.14 Replacing yarn control unit



Dismantling a yarn control unit

1. Mark the position of the old yarn control unit.
 2. Remove the screw (1).
 3. Lift the yarn control unit in the front until the contact pins are free. Push the yarn control unit to the rear and remove it.
 4. Mount the new yarn control device exactly at the position (marking) of the old yarn control device.
- or -
- Mount an additional yarn control unit at a distance of 90 mm (minimum 75 mm) from the next yarn control unit.
 5. Hook in the new yarn control unit in the rear guide rail. Pull the yarn control unit to the front and press it downwards simultaneously.
 6. Pull the yarn control unit to the front and screw it tightly with the screw (1).


7.3.15 Replacing drive belts and friction roller of friction feed wheel

The drive belts and the friction roller of the friction feed wheel are replaced with the following steps:

- Preparations
- Replace the drive belt
- Change position of friction roller
- Replacing the friction roller

Replacing parts Assembling carriage part and carriage assembly

- Preparations 1. Remove the lug (1) by loosening the knurled screws somewhat.




Friction feed wheel

2. Remove screws (2) and take off the stop motion rails.
3. Release the couplings of the arms (3) so that they can swing downward.
4. Remove the screws (4) and take off the housing cover (5).

Replace the drive belt

1. Turn the V-ribbed belt pulley (6) by hand until both Allen screws can be released through the holes (7).



Drive belt


2. Remove the belt (8).
 3. Mount the new belt in such a way that it runs in the grooves of the drive pulley.
 4. Press the motor (9) upward and tighten the screws of holes (7)
 5. Check the belt tension.
- The belt can be pushed through by approx. 2 to 4 mm when light pressure is applied.

Assembling carriage part and carriage assembly Replacing parts

Change position of friction roller

The surface of the friction roller is worn over the course of time by the yarn. Then the friction roller does not need to be replaced immediately, but its position can be shifted by 11 mm. This doubles its service life.

1. Remove the screws (12).



Screws for friction rollers


2. Remove the spacer (11).
3. Take off both friction rollers (10).
4. To assemble: Push the spacer (11) onto the axis of the friction roller (10)
5. Reinstall the friction rollers (10).
6. Retighten the screws (12) without the spacers.

Replacing the friction roller

1. Remove the screws (12).
2. Take off the friction rollers (10).
3. Lay down the new friction roller.
4. Tighten the screws (12).

7.3.16 Deaerating oil line

Only on machines with central lubrication




"Central lubrication" window

Key	Function
	Call up the "Service" menu
	Call up the "Central lubrication" window
	Call up "Main menu"

Keys for deaerating the central lubrication

Deaerate oil line:

1. Stop carriage outside needle bed.
2. Loosen vent screw (7) somewhat.





Deaerating central lubrication

3. Swivel central lubrication into mounting position. Recommendation: Place a cleaning cloth under the central lubrication, as oil will be fed.
4. From the "Main menu" call up the "Service" window.
5. Call up the "Central lubrication" window.
6. Set "Ventilation" switch to "On".
 - ▷ The pump feeds oil into the oil line.


7. If oil comes out of the hole of the vent screw, set "Ventilation" (6) switch to "Off".
8. Tighten vent screw again (9.5 Nm).
9. Repeat the ventilation process at all lubrication units.
10. Call up "Main menu".

7.3.17 Replacing comb hook

Key	Function
	Call up "Main menu"
	Call up "Comb" window

Keys for replacing comb hooks

1. Open the comb cover plate.
2. Call up the "Comb" window from the "Main menu".
3. Tap on the "Release brake (=X=)" key.
4. Push the comb take-down manually upwards (about 8 cm).
 - ▷ The cover rails of the comb take-down are located above the left and right control unit.
5. Push the cover rails (1) to the side only until an open area results at the repair point.
For this purpose, push the upper cover rails to the left until the repair point. Push the lower cover rails to the right until the repair point.



6. Remove the comb hook.
7. Insert the new comb hook.
8. Close the cover rails.
9. Close the comb cover plate.
10. Tap the "Reference run (=R=)" key.
 - ▶ The belt take-down is disassembled.

7.4 Eliminating faults in electronics system


This chapter contains information on:


- Overview of the electronic control (control cabinet right) [▢387]
- Overview of the electronic control (control cabinet right) [▢390]
- Power supply unit [▢393]
- Control of yarn carrier magnets [▢393]
- Replacing electronic card [▢394]

7.4.1 Overview of the electronic control (control cabinet right)

Valid for:	
	Type
CMS 530	642
	643
CMS 520 C	647
CMS 502	645
	646

The machine control is located in the right control cabinet under the cover. The card for controlling the yarn carrier magnets is located in the carriage.






Right control cabinet

	Card	Function
1	301 000	Drive and racking control unit Controlling the drive and racking motor. Passing on the error messages from the motors to card 009.
2	301 023	Input card, output card, fuse for (1) The card ensures that the machine cannot be started as long as an error is present. Switching off main switch: <ul style="list-style-type: none"> ◆ if the automatic switching off of the machine is activated ◆ in case of extreme overvoltage ◆ if the servos are not ready for operation Controlling the fluff absorption and fault lamp. Ballast fuse for servo drive and racking. Controlling horn, lighting, piezo elements, and central lubrication.
3	301 018	Fabric take-down card Controlling the fabric take-down motors (main take-down, auxiliary take-down, comb, comb hook motor, belt take-down). Passing on the error messages from the fabric take-down motors to board 009. Controlling the feed wheel.
4		Fan

Electronic cards

Replacing parts Assembling carriage part and carriage assembly



Right control cabinet

	Card	Function
5	039 (ID 301 039)	Controlling the input unit and the touch screen. Controlling the SSD hard disk (Solid-State-Drive). The SSD hard disk is integrated on the board.
6	009 (ID 301 009)	Main computer; collecting all messages from the other cards. Output of instructions to the other cards. Control of the knitting sequence. Controlling the carriage (main drive) and the racking position of the rear needle bed.
7	965 (ID 300 965)	Monitoring of the carriage assembly positions. Actuation of the selection systems and the step motors. Forwarding of the information to the board 943.
8	040 (ID 30 040)	Motor driver of the step motors of the stitch cams. Cooperation with the card 965.
9	301 020	Power supply unit with LEDs Checking the charging state of the batteries. Activating charging.
10	301 027	Battery plug-in unit
11		Display cable
12		Socket for Ethernet connection, if the machine is interconnected.

Electronic cards


Further information:

- Switch off machine at the end of work [87]


7.4.2 Overview of the electronic control (control cabinet right)

Valid for:	
	Type
CMS 530	621
	627
CMS 520 C	629
CMS 502	637
	638

The machine control is located in the right control cabinet under the cover. The card for controlling the yarn carrier magnets is located in the carriage.




Replacing parts Assembling carriage part and carriage assembly



Right control cabinet

	Card	Function
1	301 000	Drive and racking control unit Controlling the drive and racking motor. Passing on the error messages from the motors to card 009.
2	301 012 (301 007, until August 2012)	Battery-, input-, output-card (BIO), fuse for (1) The card ensures that the machine cannot be started as long as an error is present. Switching off main switch: <ul style="list-style-type: none"> ◆ if the automatic switching off of the machine is activated ◆ in case of extreme overvoltage ◆ if the servos are not ready for operation Controlling the feed wheel, fluff absorption and fault lamp. Ballast fuse for servo drive and racking. Checking the charging state of the batteries. Activating charging. Controlling horn, lighting, piezo elements, central lubrication and battery relay.
3	301 006	Fabric take-down card Controlling the fabric take-down motors (main take-down, auxiliary take-down, comb, comb hook motor). Passing on the error messages from the fabric take-down motors to board 009. Capacitors for fabric take-down motors on wiring system (CMS 530, CMS 520: 251 453, CMS 502: 253 667)
4		Fan

Electronic cards



Right control cabinet


	Card	Function
5	010 (ID 301 010)	Controlling the input unit and the touch screen. Controlling hard disk. The hard disk is integrated on the board.
6	009 (ID 301 009)	Main computer; collecting all messages from the other cards. Output of instructions to the other cards. Control of the knitting sequence. Controlling the carriage (main drive) and the racking position of the rear needle bed.
7	965 (ID 300 965)	Monitoring of the carriage assembly positions. Actuation of the selection systems and the step motors. Forwarding of the information to the board 943.
8	943 (ID 300 943)	Motor driver of the step motors of the stitch cams. Cooperation with the card 965.
9	300 923	Power supply unit with LEDs
10	301 008	Battery plug-in unit
11		Ethernet cable, if the machine is networked.

Electronic cards

Further information:

- Switch off machine at the end of work [87]

7.4.4 Power supply unit




Power supply unit

The LEDs on the power supply unit indicate which voltages are generated and at which voltage an error occurs. While switching on the main switch, the lower three LEDs light up immediately, and the +28 V approx. 1 second later, followed by the +40 V. The order in which the LEDs light up when switching on may provide information on fault causes.

7.4.5 Control of yarn carrier magnets

Each knitting system has got an electronic board (1) for controlling yarn carrier magnets.




Electronic cards for controlling yarn carrier magnets


Card	Function
960 (ID 300 960)	Activating of the yarn carrier magnets after the time for switching the yarn carrier magnets has been announced by the board 966.

Electronic cards

7.4.6 Replacing electronic card

1. Set main switch to "0" and wait until the LEDs on the power supply unit go out (approx. 60 seconds).
2. Open the cover of the left control cabinet.

	NOTICE
	<p>An electronic card can be destroyed by electrostatic charge!</p> <p>If you touch a board while you are electrostatically charged, the board will be destroyed.</p> <p>→ First discharge yourself by touching "ground", e.g. a water pipe or the machine frame, then touch a card.</p> <p>→ Only touch cards on the edge or the front side.</p>


	NOTICE
	<p>The electronic boards can be damaged by damage to the pins on the rear of the board!</p> <p>If the pins of the cards are bent or broken off at the rear, new cards must be used.</p> <p>→ When replacing the cards, make sure that the pins are not damaged.</p>

3. Remove the card.
4. Plug in the new card.
5. Close the cover of the left control cabinet.
6. Set the main switch to "1" and acknowledge the error remedy.


7.5 Check fuses

7.5.1 Checking fuse (right control cabinet)

Valid for:	
	Type
CMS 530	642
	643
CMS 520 C	647
CMS 502	645
	646

	DANGER
	<p>Life-threatening high voltage!</p> <p>Electrical shock may cause death or serious injuries.</p> <p>→ Set the main switch to "0" and wait until the touch screen is dark and an alarm signal sounds.</p>

1. Set machine main switch to "0".
2. Wait until the touch screen is dark and an alarm signal sounds.
3. Check fuses (1) to (4) at the rear of the right control unit.




Fuses at the rear of the right control unit (for a better overview the fan was dismantled)

- | | |
|---------------------------------------|-------------------------------------|
| 1 28 V (stop motions) (1A, slow-blow) | 3 Yarn control unit (1A, slow-blow) |
| 2 STIXX (1A, slow-blow) | 4 Battery charge (1A, slow-blow) |

Assembling carriage part and carriage assembly Check fuses

4. Inspect battery fuse (9).
Disconnect the plug 7 for this.
Remove the screw (8).
Pull out the battery plug-in unit.
Inspect battery fuse (9).




DANGER

Burning risk!

Injuries by hot parts.

→ Watch out not to touch the resistors (6) when pulling out the board. The resistors can get very hot.


5. Check the ballast fuse (5) on the input and output card. For this purpose, remove the screws at the top and bottom and pull out the card.



Ballast fuse for servo drive and racking on the input and output card.

6. Check fuses on the transformer at the rear of the machine.
Remove the cover for this.

Check fuses Assembling carriage part and carriage assembly



Fuses on transformer at the rear of the machine

F4	Friction feed wheel	F18	Central lubrication
F8	Servos	F20	Fluff absorption

7. Eliminate the cause.

8. Insert new fuse.



Use a replacement fuse from the accessories. Use only a fuse with the same specifications.

Specifications of the fuse: see sticker (impression) or circuit diagram. The circuit diagram can be found on the documentation DVD, which has been delivered with this machine.

7.5.2 Checking fuse (right control cabinet)


Valid for:	
	Type
CMS 530	621
	627
CMS 520	620
	628
CMS 520 C	629
CMS 502	637
	638
CMS ADF-3	681

**DANGER****Life-threatening high voltage!**

Electrical shock may cause death or serious injuries.

→ Set the main switch to "0" and wait until the touch screen is dark and an alarm signal sounds.

1. Set machine main switch to "0".
2. Wait until the touch screen is dark and an alarm signal sounds.
3. Check fuses (1) to (4) at the rear of the right control unit.



Fuses at the rear of the right control unit (for a better overview the fan was dismantled)


- | | |
|---------------------------------------|-------------------------------------|
| 1 28 V (stop motions) (1A, slow-blow) | 3 Yarn control unit (1A, slow-blow) |
| 2 STIXX (1A, slow-blow) | 4 Battery charge (1A, slow-blow) |

Check fuses Assembling carriage part and carriage assembly


4. Check the battery fuse (7) on the control unit.



Battery fuse below the power supply unit


	DANGER
	<p>Burning risk! Injuries by hot parts.</p> <p>→ Watch out not to touch the resistors (6) when pulling out the board. The resistors can get very hot.</p>

5. Check the ballast fuse (5) on the right control unit . For this purpose, remove the screws at the top and bottom and pull out the board.



Ballast fuse for servo drive and racking on the control unit

6. Check fuses on the transformer at the rear of the machine.



Fuses on transformer at the rear of the machine

F1-F3	Fabric Take-down	F11- F13	Power supply unit
F4-F6	Friction feed wheel	F18	Central lubrication
F8- F10	Servos	F20- F22	Fluff absorption

7. Eliminate the cause.

8. Insert new fuse.



Use a replacement fuse from the accessories. Use only a fuse with the same specifications.

Specifications of the fuse: see sticker (impression) or circuit diagram. The circuit diagram can be found on the documentation DVD, which has been delivered with this machine.

7.5.3 Checking fuse (right and left control cabinet)


Valid for:
CMS 530 T
CMS 730 S
CMS 730 T
CMS 822
CMS 830 C
CMS 830 S
CMS 933

**DANGER****Life-threatening high voltage!**

Electrical shock may cause death or serious injuries.

→ Set the main switch to "0" and wait until the touch screen is dark and an alarm signal sounds.

1. Set machine main switch to "0".
2. Wait until the touch screen is dark and an alarm signal sounds.
3. Check fuses (1) to (4) at the rear of the left control unit.




Fuses at rear of left control unit

- | | |
|---------------------------------------|-------------------------------------|
| 1 28 V (stop motions) (1A, slow-blow) | 3 Yarn control unit (1A, slow-blow) |
| 2 STIXX (1A, slow-blow) | 4 Battery charge (1A, slow-blow) |

Assembling carriage part and carriage assembly Check fuses

4. Check fuse (12) on the left control unit. For this purpose, pull out plug (13), remove both screws (14) and pull out battery insert.



Battery fuse (12) below the power supply unit




DANGER

Burning risk!

Injuries by hot parts.


→ Watch out not to touch the resistors (6) when pulling out the board. The resistors can get very hot.

5. Check fuse (5) on the right control unit. For this purpose, remove the screws at the top and bottom and pull out the board.



Ballast fuse (5) for servo drive and racking on the control unit

6. Check fuses on the transformer at the rear of the machine.



Fuses on transformer at the rear of the machine

F1-F3	Fabric Take-down	F16- F17	CMS 933: Lighting
F4-F6	Friction feed wheel	F18	Central lubrication
F8- F10	Servos	F20- F22	Fluff absorption
F11- F13	Power supply unit		

7. Eliminate the cause.

8. Insert new fuse.



Use a replacement fuse from the accessories. Use only a fuse with the same specifications.
Specifications of the fuse: see sticker (impression) or circuit diagram. The circuit diagram can be found on the documentation DVD, which has been delivered with this machine.

7.6 Needle selection displacement

Condition:

- Operating system of the knitting machine: Operating system OKC V 2.5 (or higher).

With this test the interaction of the impulse sensor, the control unit and the different selection systems is synchronized. This takes place with the help of test series. With different reaction times it is checked whether the needles are driven out to the "stitch" position for knitting or not. You have to check this in both carriage directions. You enter these test results in a table. From these test results the optimum reaction time is calculated.



Time required

Manually:

If you carry out the test series manually, you will need between 2 and 4 hours depending on the machine gauge.

Automatic:

The measuring system "JNA" (Setup-Needle-Selection) is available at your agency or at Stoll. With this measuring system the test series are carried out automatically. Time required: 30 - 60 minutes.



"JNA" measuring system

With the "JNA" measuring system you will get instructions on how to carry out a needle selection displacement.

You do not need to carry out the section "Determine manually the needle selection displacement" of this instructions.

The needle selection displacement is carried out with the following steps:

- Setting the impulse sensor type [▢405]
- Preparations [▢410]
- Reset reference values of impulse sensor, carry out carriage reference run [▢411]
- Determining the needle selection displacement manually [▢412]

Documents for this purpose:

- ▢ Mounting instructions "Replace impulse sensor" (resources/pdf/258255_01_bedan_gb--1498493067.pdf)
- Setting the impulse sensor type [▢405]
- Preparations [▢410]
- Reset reference values of impulse sensor, carry out carriage reference run [▢411]
- Determining the needle selection displacement manually [▢412]

7.6.1 Setting the impulse sensor type

This is only necessary with older OKC machines:

- OKC 2.0 machines (2005 until February 2009)
- OKC 3.0 (March 2009 until June 2010)

On newer machines (OKC 3.0, from July 2010 on), this is not necessary as only the new impulse sensor type can be built-in. You may skip this section. It continues on Page [410].

Assembling carriage part and carriage assembly Needle selection displacement

		Type	Component type
OKC 3.0 (March 2009 until June 2010)	CMS933	771 773	000
	CMS830 S	633	000
	CMS830 C	631	000
	CMS822	623 632	000 000
	CMS740	630	000
	CMS730 T	588	000
	CMS730S	625	000
	CMS530 T	587	000
	CMS530	621 627	000 - 001 000
	CMS520 C	629	000
	CMS520	620 628	000 000
	CMS502	626	000

Needle selection displacement Assembling carriage part and carriage assembly

		Type	Component type
OKC 2.0 (2005 until February 2009)	CMS933	769	000 - 004
	CMS922	770	000 - 004
	CMS830 C	573	000 - 004
	CMS822	574	000 - 005
	CMS740	572	000 - 004
	CMS730 T	586	000 - 004
	CMS730 S	554	000 - 004
	CMS530 T	585	000 - 004
	CMS530	566	000 - 004
	CMS520 C	570	000 - 004
	CMS520	567	000 - 004
	CMS420 E	579	000 - 004

Machines for which the impulse sensor type has to be set.

If you are not sure about the machine type, check the machine type plate.








The first column of numbers in the "Type" field indicates the machine type and the second column of numbers indicates the component type. In the above example, the machine in question is the "621" type, and the "000" component type.

Assembling carriage part and carriage assembly Needle selection displacement

Setting the impulse sensor type You need to inform the control unit about the impulse sensor type you installed in the machine. It is possible to install two different impulse sensor types in older OKC machines. You will find the ID in the spare parts delivery.

Impulse sensor type	ID	
1	240 562	Impulse sensor of OKC machines until June 2010
2	260 396	Replacement for the previous impulse sensor (ID 240 562)

Key	Function
	Continue on to the next window
	Call up "Additional function keys"
	Call up "Machine parameters 2" window
	Confirm input
	return to the "Machine parameters"


Keys for setting the machine parameters

Carry out restart with machine configuration:

✓ The machine is switched off.

1. To switch on the machine, set the main switch to 1.

▷ The "BootOkc" window is displayed on the touch screen.




"BootOkc" window

2. Touch the "Restart and Machine Configuration" key.

3. Tap repeatedly on the "Continue on to the next window" key until the "Machine parameters" window is displayed. ("Language" -> "Machine configuration" -> "Machine configuration 2" -> "Machine options" -> "Machine parameters")

4. In the "Machine parameters" window tap on the "Additional function keys" key.

5. Call up the "Machine parameters 2" window.



6. Select the impulse sensor type "2 - ID 260 396".

Select this setting also with mixed operation (old and new impulse sensor type).

7. Confirm input.

8. Return to the "Machine parameters" window.

9. Advance till the Main menu appears.

Documents for this purpose:

📄 Mounting instructions "Replace impulse sensor" (resources/pdf/258255_01_bedan_gb--1498493067.pdf)

■ Preparations [410]

7.6.2 Preparations

- Stop the carriage after the left reversing position.
- With tandem machine: Couple carriage narrow.
- Cast-off the stitches on both needle beds.
- Remove the needle brushes on the front and rear carriage part.
- The test series is required for all the impulse sensors of the machine - with a tandem machine there are four impulse sensors.
- For the check you need a small knitting program.
Example for a 3-system machine.

```
10 START
15 MSEC=0.15
20 SEN=1-#138
30 <> S:R-0; Y:0; S1 S2 S3
40 <> S:0-R; Y:0; S1 S2 S3
50 END
```

Line 30: Check of the front impulse sensor

Line 40: Check of the rear impulse sensor






If you have a 2-system machine simply leave out the indication "S3" for the third knitting system in the lines 30 and 40.

Documents for this purpose:

- 📄 Mounting instructions "Replace impulse sensor" (resources/pdf/258255_01_bedan_gb--1498493067.pdf)

7.6.3 Reset reference values of impulse sensor, carry out carriage reference run

Before determining the new values you have to delete the "old" values of the impulse sensors.

Key	Function
	Call up the "Service" menu
	Call up the "Basic settings" menu
	Call up "Machine parameters" window
	Call up "Additional function keys"
	Call up "Machine parameters 2" window

Keys for deleting the reference values

1. Call up the "Service" menu from the "Main menu".
2. Call up "Basic Settings" menu.
3. Call up the "Machine parameters" window.
4. Call up "Additional function keys".
5. Call up the "Machine parameters 2" window.








6. Select all impulse sensors (activate control box). On a tandem machine there are four impulse sensors.
7. Confirm input tapping on the (1) key.
8. You will be asked whether the values are to be deleted. Confirm this message with "OK".
 - ▷ The values are deleted.
9. Carry out carriage reference run.

Documents for this purpose:

- 📄 Mounting instructions "Replace impulse sensor" (resources/pdf/258255_01_bedan_gb--1498493067.pdf)

7.6.4 Determining the needle selection displacement manually

Key	Function
	Call up the "Service" menu
	Call up the "Basic settings" menu
	Call up the "Adjustment of needle selection" menu
	Call up the "Automatic" menu
	Call up the "Manually coarse" menu


Keys for determining the needle selection displacement

Determine the needle selection displacement:

1. Fix knitting row.
For checking the front impulse sensor enter "SPF30".
2. Engage the machine, stop the carriage in the right reversing point.
3. Call up the "Service" menu from the "Main menu".
4. Call up "Basic Settings" menu.
5. Call up the "Adjustment of needle selection" menu.
6. Call up the "Manually coarse" menu.

Needle selection displacement Assembling carriage part and carriage assembly

7. Carry out the test series.



- | | |
|---|--|
| <p>A Test for the front needle bed</p> <p>1 Reset
Delete the test results for the front needle bed.</p> <p>2 Current line of the test series</p> <p>3 Enter the test result (carriage direction: >>)
Switch setting "1" – OK
Switch setting "0" – F (Error)</p> | <p>B Test for the rear needle bed</p> <p>4 Enter the test result (carriage direction: <<)</p> <p>5 Proceed to the next line</p> <p>6 Calculating the optimal reaction time</p> <p>7 Reset
Delete the test results for the rear needle bed.</p> |
|---|--|

8. Tap the "Reset" (1) key.
The active line (2) of the test series is highlighted.
9. Engage the machine.
 - ▷ The carriage moves very slowly from right to left (MSEC=0.15).
10. While the carriage is running you perform a visual inspection. Check whether all the needles are driven out for knitting or not.
11. Stop the carriage in the left reversing point.
12. Enter the test result in the table.
If all the needles are driven out, you do not need to enter anything, as "OK" is entered by default in the active line.
- or -
- If one or more needles are not driven out, set the switch (4) to "0". An "F" is entered in the table.
13. Engage the machine and check the needle selection in the other carriage direction.
14. Stop the carriage in the reversing position and enter the test result with the help of the switch (3).

i If you are not sure that no error occurred, repeat the check for both carriage directions.

15. Resume the test series. Press the (5) key for this.
 - ▷ The next line of the test series is selected automatically. Internally, the reaction time is increased by "1".
 16. Resume the test series until one error occurs in both carriage directions (steps 9 to 15).
 - ▷ Now you have reached the limit for the "positive" reaction time.
 17. The second part of the test follows. Press the (5) key for this. The test will be carried out automatically with "negative" reaction times.
 18. Repeat the steps 9 to 15 until one incorrect selection occurs in both carriage directions.
 - ▷ The switches automatically get inactive (grey).
 19. The test series for this impulse sensor is finished.
 20. Calculating the reaction time. Tap the (6) key for this. The optimum reaction time is calculated. This takes about 10 seconds. When the calculation is finished a message appears on the touch screen.
 21. Repeat the test series for the rear impulse sensor. For this fix the knitting row 40 - enter "SPF40".


Attention: With step 8 tap on the "Reset" (7) key. (If you tap on the (1) key, the recently determined values are deleted.) Repeat the steps 8 to 20.
 22. With a tandem machine: switch the option in the "Right/left carriage" to the other carriage. Repeat the steps 8 to 21.
- ▶ The determination of the needle selection displacement is finished.



If you accidentally tap the (5) key twice, one line of the test series is skipped. The test series is not valid. You have to execute again the entire test series (step 8).

Concluding activities

- The data of the needle selection displacement is part of the machine settings. It is automatically saved in the dongle data. You can save this data additionally if necessary:
 - on a USB memory stick
 - note on the machine data sheet at the right control cabinet



Documents for this purpose:

- 📄 Mounting instructions "Replace impulse sensor" (resources/pdf/258255_01_bedan_gb--1498493067.pdf)

7.7 Entering the data of the needle selection displacement manually









Only for Stoll technicians or knitting technicians

If the data for the needle selection displacement got lost and there is no Dongle data available, the data can be entered manually.

When delivering the knitting machine, the machine data was printed out and put on the right control cabinet.



Machine data sheet at the right control cabinet

Key	Function
	Call up the "Service" menu
	Call up the "Basic settings" menu
	Open the "Needle bed parameters" window
	Call up "Additional function keys"
	Open the "Needle bed parameters 2" window
	Call up "Main menu"






Keys for controlling the data for the needle selection displacement

Assembling carriage part and carriage assembly Entering the data of the needle

Controlling the data of the needle selection displacement

1. Call up the "Service" menu from the "Main menu".
2. Call up "Basic Settings" menu.
3. Open the "Needle bed parameters" window.
4. Call up the additional function keys in the "Needle bed parameters" window.
5. Open the "Needle bed parameters 2" window.
6. Compare the displayed values with the values on the machine data sheet.
7. If the values are not identical to the data of the needle selection displacement enter them manually (see next section).
8. Call up the "Main menu".

Entering the data of the needle selection displacement manually


Key	Function
	Continue on to the next window
	Call up "Additional function keys"
	Open the "Needle bed parameters 2" window
	Confirm input
	return to the "Needle bed parameters" window

Keys for entering the data for the needle selection displacement

✓ The machine is switched off.

1. To switch on the machine, set the main switch to 1.

▷ The "BootOkc" window is displayed on the touch screen.



"BootOkc" window

Entering the data of the needle selection displacement manually Assembling carriage

2. Touch the "Restart and Machine Configuration" key.
3. Tap repeatedly on the "Continue on to the next window" key until the "Machine parameters" window is displayed. ("Language" -> "Machine configuration" -> "Machine configuration 2" -> "Machine options" -> "Machine parameters" -> "Needle bed parameters")
4. In the "Needle bed parameters" window tap on the "Additional function keys" key.
5. Open the "Needle bed parameters 2" window.

**NOTICE**

If you enter wrong values it will lead to a faulty selection of the needles.

6. Enter the values of the machine data sheet in the "Needle bed parameters 2" window.
7. Confirm entries.
8. Return to the "Needle bed parameters" window.
9. Advance till the Main menu appears.
10. Save the change in the machine adjustments on the USB memory stick.

Further information:

- Saving all machine data on the USB-Memory-Stick [432]

8 Software - Installation and basic settings

In this chapter the description of how can one install and set the Stoll operating system is given.

It is important thereby that one gets to know the boot process (the booting of software and the activation of control) on the knitting machine.

One has to engage in this boot process during installation and setting of the Stoll operating system.

Thereby call up various windows e.g. the "Basic Settings Menu" window.

For the setting of the Stoll operating system more windows are open in which the changes can be made.

If your knitting machines are interconnected or are connected with a pattern unit, you can configure the on-line connection.




Save the machine data against any data losses before every installation of Stoll operating system or before any changes in the configuration.

This chapter contains information on:

- Boot process [419]
- Saving all machine data on the USB-Memory-Stick [432]
- Saving pattern after a big fault [434]
- Installing the Stoll operating system [436]
- Diagnose Control [460]

8.1 Boot process

The following figure shows a schematic representation of the boot process of the knitting machine (with control OKC).



Schematic representation of the boot process


Boot process

Description of the boot process

After switching on knitting machine (main switch **1**) windows XP gets started. The opening screen is displayed on the touch screen.


Thereafter the individual control components start their boot programs i. e. the different drivers and the applications of the System Control Unit (SCU) are loaded.

During this time, the following window is displayed on the touch screen:



Start the System Control Unit (SCU)

If this process is closed, then the "BootOkc" window is displayed.



"BootOkc" window

- 1 Symbol and status bar show the connection status.
- 2 Keys for carrying out definite actions.
- 3 Activity and progress display show the present progress of the boot process.
- 4 Lists that number the status and error messages and show the date and time. Further debug information can be connected to, if needed. This information is also saved in a log file and can be copied with **Copy Logfiles**, if needed.
- 5 Keys for setting the touch screen.

First of all, only the keys "Installation", "Installation and Configuration" and "Basic Settings" are released. As soon as the connection to control is made, more keys are released based on the control information.

If a warm start is possible, then this is automatically carried out after a waiting time that can be set (basic setting: 30 seconds).

Thereafter, the main menu and the last opened window are displayed.













Main menu

The knitting machine is now ready to knit.

Boot process

Interrupt warm start The warm start of the knitting machine can be interrupted. This happens by tapping the keys in the "BootOkc" window.

Key	Meaning
	Start the installation process of a Stoll operating system. The storage location of the Stoll operating system can be selected in the "Basic Settings" window.
	Starts the installation process of a Stoll operating system including configuration of the machine. The storage location of the Stoll operating system can be selected in the "Basic Settings" window.
	Starts the software anew (Reboot).
	Starts the software anew (Reboot) with configuration of the machine inclusive.
	Carries out a manual warm start.
	Calls up the "Basic Settings Menu" window.
	Set the screen brightness infinite.
	Set screen brightness one step darker.
	Set the screen one step brighter.
	Calibrate touch screen.

Possibilities for interrupting a warm start


Further information:

- Setting touch screen [65]

8.1.1 Basic Settings

Call up "Basic Settings Menu" window:

- ✓ The knitting machine is switched off.
- 1. Set the main switch to "1".
 - ▷ The "BootOkc" window is displayed.
- 2. Type in within the waiting time for the warm start on the "Basic Settings" key.
 - ▷ The "Basic Settings Menu" window is displayed.



"Basic Settings Menu" window


Area	Explanation
Boot Source	Keys for selecting a source for the installation data.
Delay Time for automatic Warmstart	Enter the waiting time till the automatic warm start.
Service Activities	Keys for service purposes.

Areas of the "Basic Settings Menu" window

Boot process

Selecting the source of the installation data (Boot Source)

In the "Boot Source" area of the "Basic Settings Menu" window ascertain the source from where the installation of the Stoll operating system is done.



Selection of the source in "Basic Settings Menu" window

Key	Explanation
Current Version (HD)	Renewed installation of the existing version.
New Version (HD)	Installation of a new version.
Previous Version (HD)	Installation of the previous version.
Network	Installation of a version from a network drive.
USB Device	Installation of a version from a device which is connected to the USB socket.
User Defined Path	Installation of a version from a user-defined storage location.
Change Path	Key for selection of a storage location.

Keys in the "Boot Source" area of the "Basic Settings Menu" window

Setting waiting time until warm start

In this area of the "Basic Settings Menu" window, the waiting time that is spent in between the display of the "BootOkc" window, and the automatic warm start (display of the main menu) is entered.



Waiting time for warm start in the " Basic Settings Menu" window




The waiting time can be interrupted at anytime by pressing any key in the "Basic Settings" window.

Set waiting time:


1. Pull the slide to the desired position.
 - ▷ The waiting time is displayed in the input field.
2. Confirm input.

Configure machine



Defined by the concept of control OKC some basic information about the machine should be known right from the start. Enter this information in the "Machine Configuration" window.

- Tap on the "Machine configuration" key.
- ▶ The "Machine Configuration" window is displayed.



"Machine Configuration" window

Label	Description
Machine Classification	Enter the machine classification.
Component Type	Enter the component type.
Controller Characteristic	Name of the control unit (only display)
Date	Entry of the date
Time	Entry of the time
Time Zone	Entry of the time zone
Autoadjust clock for daylight saving	Automatically switch the clock to summer- or wintertime.
Motor Types	Select which motor (different motors with different ID) is installed in the machine. (Might be necessary after replacing a motor)

Components of the "Machine Configuration" window

Entering the machine classification and the component type:


1. In the "Machine Classification" list field, select the machine classification.
2. In the "Component Type" list field, select the component type.
 - ▷ In the "Controller Characteristic" field, the controller type is displayed.
3. Confirm input.

Boot process

Enter the date, time and time zone:

1. In the "Date" list field, enter current date.
2. In the "Time" list field, enter current time.
3. In the "Time Zone" list field, select the time zone.
4. Confirm input.

Configuring network



If you wish to connect the knitting machine with another knitting machine or a pattern unit, you must set up and switch on the network on the knitting machine. The "Network Configuration" window is used for it.

→ Tap on the "Configure Network" key.

► The "Network Configuration" window is displayed.

"Network Configuration" window

In this window all the necessary network parameters are entered. The values are entered with the internal keyboard (virtual keyboard) or with an external keyboard.

Label	Description
Computer Name	The input of a (machine) name is necessary in order to enable the other network users an access to this machine. This machine is identified with this name in the network. Enter descriptions of this machine in the "Description" field.
Workgroup	All knitting machines should be located in the same "Workgroup" so that the machines can communicate with each other. This input field must be filled up. Ask for your corresponding Work group name from your Network administrator in case of a network spanning your firm/LAN.
Description	Although entering a description is optional, it does help to identify machines more efficiently in larger networks. e.g. Type of the machine, gauge and other special features of the machine. This input appears as a comment in the Windows Explorer.
My Network	Here are listed the computers that have been defined in "My Network" field, see KnitLAN connection [☐269]. If you wish to supplement the lists manually, take note of the spelling when multiple computers are used: \\computer name;\\computer name;\\computer name As a separator between the individual computers the semicolon (";") must be used.
User Name	This user must be familiar with his password in the network so that the shared drives and folders can be used. Your Network administrator will create a user name and a password for you so that you can access the network resources.
Password	
E-Mail	Input an e-mail address (Configure). The messages of the control unit are sent to this address, when the "Enable" check box is activated.
IP Address	Each machine (computer) should have a unique IP address within a network. The network protocol TCP/IP communicates with the individual machines by this IP address. The division of the network is done in the so-called network classes. An individual Network-address is assigned to each machine automatically by the program and it is displayed here.
Subnet Mask	This field is automatically filled up by the program with a value for the shared network Class B .

Boot process

Label	Description
Use DHCP	The DHCP (Dynamic Host Configuration Protocol) enables with the help of a corresponding server the dynamic allocation of an IP address and the further configuration parameters to the computers (machines) in a network.
MAC Address	Media Access Control Address.
Name	Name of the network board.
Use DNS	Domain Name Services via a DNS Server. Enter the name of the IP address of the server, if necessary.
Use WINS	Windows Internet Name Services. Enter the name of the IP address of the server, if necessary.
Gateway	A Gateway enables the connection between the shared networks. Enter the IP-Address of the active component, if necessary.

Components of the "Network Configuration" window



Settings in the "Network Configuration" window, especially the settings for **External LAN**, are to be done by a Network Administrator. The settings for **Internal LAN** serve developers purposes only and may not be altered.

The Ethernet IP addresses **192.168.0.0** to **192.168.0.255** are reserved for Stoll knitting machines and may not be used in the company network.

The reason for this: The cards 963 (IPC) and 966 (Power CPU) in the knitting machine use these IP addresses to communicate with each other. But if both these addresses are used in the company network, the cards cannot work correctly with each other anymore and the machine does not function any longer.

Display/hide screen
keyboard

→ In order to keep the virtual keyboard constantly open, activate the check box before "Use Touch Screen Keyboard".

⇒ By clicking on an input field the virtual keyboard opens.

- or -

→ In order to close the virtual keyboard deactivate the check box before "Use Touch Screen Keyboard".

Enter the machine name
(Computer-Name)

1. Touch the "Computer Name" entry field.

▷ The virtual keyboard is displayed.

2. Tap into the "Computer Name" by any desired name (5-15 characters) for the respective knitting machine.

- or -

→ Maintain the standard setting.

Enter the user name and the password



Your Network administrator must create a user name and a password before you can access the network resources.

1. In the "User Name" input field, tap the user name (5-15 characters).
2. In the "Password" input field, tap the corresponding password (5-15 characters).

▶ A * (asterisk) appears for each character you enter.

Enter Workgroup

→ In the "Workgroup" input field, tap the name of the work group and the machine group for this machine (5-15 characters).

- or -

→ Maintain the standard setting.


Enter the description of the machine (Description)

→ Enter a meaningful description of this machine (maximum 50 characters) in the "Description" input field.

Enter E-Mail-Address

1. Activate the "Enable" check box.
2. Tap on the "Configure" key.

▷ The "E-Mail Configuration" window is displayed.




3. Select the cases in the field Events by the appearance of which the e-mail should be sent.
4. Enter the e-mail address in the "E-Mail address" field
5. Confirm input.

Further information:

- KnitLAN connection [269]

Advanced adjustments



For the Stoll technician only

Boot process

Load the machine settings in the machine computer



The machine settings do not only contain the machine data, but also the machine options, the machine configuration, the report, the network settings, and other internal control information. This data is referred as **Dongle**. Dongle-Data are saved in a file with the **mcnumber.dgl** (mcnumber = machine number) name.

✓ A file with dongle data is available.

1. Tap the "Load Dongle" key.

▷ A selection window for opening a file is displayed.

2. Select Dongle-file (mcnumber.dgl).




The current machine settings will be overwritten!
When you copy the machine settings to the hard disk, the current machine settings are overwritten.
Only carry out the following steps if you want to replace the current machine settings with the settings saved on the file.

3. Confirm input.

4. When the network settings are available, the question appears whether these should be read also. If you answer this question with "Yes" the network settings are loaded and a Reboot is automatically run.

▶ The machine settings are copied to the machine. After the copying is complete, a message appears.

Saving dongle data



The machine settings do not only contain the machine data, but also the machine options, the machine configuration, the report, the network settings, and other internal control information. This data is referred as **Dongle**. Dongle-Data are saved in a file with the **mcnumber.dgl** (mcnumber = machine number) name. It is important to back up the data, e.g. when the hard disk is replaced.

1. Tap on the key "Save Dongle".

▷ A selection window for saving a file is displayed.

2. Select the saving location.

3. Confirm input.

▶ The machine settings are copied on the target medium (file name: mcnumber.dgl).

Error diagnostics with Copy Logfiles



If the machine computer has serious problems, e.g. it does not react to any inputs or the program crashes any longer, the cause is very important for Stoll. The computer saves the data up to the fault internally in so-called **Logfiles**. For an exact error diagnosis, we want to ask you to save these files and to send them to the Stoll-Helpline.

1. Tap on the key "Copy Logfiles".


▷ A selection window for saving a file is displayed.

2. Select the saving location.

3. Confirm input.

▶ The log files are zipped, and saved on the target medium (file name: Log_date_time_mcnr.zip).

Restore the last version of the Stoll operating system



1. Tap on the key "Restore Last Version".

▷ A dialog window for confirming the restoration appears.



The current operating system version will be overwritten! When you restore the saved operating system version, the current operating system version is overwritten. Only carry out the following steps if you want to replace the current operating system by the previous version.

2. Confirm message.

▷ The "BootOkc" window is displayed. The source (Boot Source) "Previous Version (HD)" is automatically set.


3. When the Stoll operating system is to be installed without the final configuration tap on the key "Installation".

- or -

→ When the Stoll operating system is to be installed with the final configuration, tap on the key "Installation and Configuration".

▶ The Stoll operating system gets installed.

Displaying current software version



For diagnostics purposes it is important to know which software is installed on the computer. In the "Info" window, the version numbers of the currently installed Stoll operating system are displayed. In the case of error messages, these version numbers should also be provided to Stoll-Helpline, if possible.


→ Tap on the key "Show Current Version".

▶ The "Info" window is displayed. Here the current version numbers of the Stoll operating system are displayed.



With **Copy Logfiles** this data is automatically saved with the file **Log_date_time_mcnr.zip**.

Displaying the history of the software versions



For diagnostics purposes it is important to know which software is installed on the computer. In the "Version Info" window, the current versions and all previously installed software programs are logged. In the case of error messages, these version numbers should also be provided to Stoll-Helpline, if possible.

→ Tap on the key "Show Version History".

▶ The "Version Info" window is displayed. Here the current version numbers and all the software installations of Stoll operating system executed so far are displayed.






With **Copy Logfiles** this data is automatically saved with the file **Log_date_time_mcnr.zip**.

8.2 Saving all machine data on the USB-Memory-Stick


The machine settings do not only contain the machine data, but also the machine options, the machine configuration, the report, the network settings, and other internal control information. This data is referred as **Dongle**. Dongle-Data are saved in a file with the **mcnumber.dgl** (mcnumber = machine number) name.

The Machine data can be copied on a USB-Memory-Stick. After installing a new operating system version or following data loss or the change of the hard disk the machine data can be copied back from the USB Memory-Stick to the machine computer.

Key	Function
	Call up the "Service" menu
	Call up "Copy service data" window
	Call up "Main menu"

Keys for saving the machine data on a USB-Memory-Stick

1. Insert the USB memory stick into the USB socket.
2. Call up the "Service" menu from the "Main menu".
3. Call up the "Copy service data" window.



"Copy service data" window

4. Select the desired data carrier e.g. . USB memory stick (Drive F:).
5. Tap on the "Copy Dongle" key.
 - ▷ The entire machine data are saved under the **mcnumber.dgl** on the USB-Memory-Stick (**mcnumber** = machine number) file name.

6. Call up "Main menu".
7. Take out the USB-Memory-Stick.




Loading of the machine settings with the "Load Dongle" key in the "Basic Settings" window.

Further information:

- Copying service data [▢182]
- Load the machine settings in the machine computer [▢430]

8.3 Saving pattern after a big fault


No "Warm start" can be made after a big fault of the control (e.g. system crash). You have to carry out a "Restart". You will be asked whether the logfiles and the pattern which has been loaded recently are to be saved.



If you do not want to save the logfiles and the pattern, then tap on the "NO" key. The "Restart" is carried out. Load the new knitting program.


Save pattern:

1. If you want to save the logfiles and the pattern, then tap on the "YES" key.
2. You will be asked where the logfiles and the pattern which has been loaded recently are to be saved. We recommend to save the pattern on a USB-Memory-Stick or network drive.



3. Confirm the path specification.
4. The selected files will be saved under a new name. Saved_pattern.sin (.jac, .set, .setx, .seq) with a sequence: Saved_pattern1.sin, Saved_pattern2.sin, etc.

5. Once the data are saved, a message is displayed. Confirm this message with "OK"



6. Carry out the "Restart".
7. Rename files. You cannot carry out this on the knitting machine. For this purpose go to the M1plus or a PC.
8. In order to be able to load the pattern into the machine, you have to add the machine type to the pattern name. For example for a CMS 530: CMS530.Saved_pattern.sin
9. Rename all the .sin and .set files, do not rename the .jac file.
10. For Setup2: Compress the files (zip), the name of the zip file has to be identical to the name of the .sin file.
11. Loading the files into the knitting machine.

8.4 Installing the Stoll operating system

The Stoll operating system can be installed in two ways:

- **Direct Installation:**

After switching on the main switch, the "BootOkc" window gets displayed. Type in within the waiting time for the warm start on the "Basic Settings" key, and select the memory location of the new Stoll operating system in the "Basic Settings Menu" window. Go back to the "BootOkc" window, and type on the "Installation" key or "Installation and Configuration". The installation process is triggered.

When you tap on the "Installation" key, the installation is run through till the "Reference run" window.

When you tap on the "Installation and Configuration" key, the machine can be configured afresh for stopping the installation.

- **Indirect Installation:**

During the production the new Stoll operating system is copied on the hard disk. You use the "Updating software" window for this purpose.

When the machine is switched on again the software can determine that a new Stoll operating system is available for installation. You will be asked in one window whether you want to install the new Stoll operating system and whether you wish to configure the machine anew simultaneously. If you acknowledge this process with "Yes" the installation process gets started with or without configuration.

In the next sections the different types of installations will be discussed at length.

- Direct installation [▢437]
- Indirect installation [▢443]
- Updating software [▢449]
- Carrying out a restart (Restart) [▢453]
- Carrying out restart with machine configuration (Restart and Configuration) [▢454]
- Setting online connection [▢456]
- Overview of all system data [▢458]
- Direct installation [▢437]
- Indirect installation [▢443]
- Updating software [▢449]
- Carrying out a restart (Restart) [▢453]
- Carrying out restart with machine configuration (Restart and Configuration) [▢454]
- Setting online connection [▢456]
- Overview of all system data [▢458]

8.4.1 Direct installation

For the **Direct Installation** the installation process is started directly in the "BootOkc" window.

Overview:

- Start the installation process by switching on the machine. In the "BootOkc" window, tap on the "Basic Settings" key to select memory location in which the installation data is available (**Boot Source**).
- In the "BootOkc" window, start the installation with the "Installation and Configuration" or "Installation" keys.
- Configure the machine after having selected the "Installation and Configuration" key or start a reference run after having selected the "Installation" key.



Select the "Installation and Configuration" key, if along with the installation of the new Stoll operating system the machine parameters are also to be altered.
Select the "Installation" key, if the machine parameters are not to be altered. This shortens the installation process.




The current operating system version will be overwritten!
When you install a new Stoll operating system version the current one is overwritten.
Carry out the following steps only if you want to replace the current operating system by the previous version.
Save the machine data and the files specifically the ones you have created before the installation process.

Select Boot Source ✓ The machine is switched off.

1. Set the main switch to 1.

▷ The "BootOkc" window is displayed on the touch screen.



"BootOkc" window

Installing the Stoll operating system

2. For the automatic warm start, tap on the "Basic Settings" key within the waiting time.

▷ The "Basic Settings Menu" window is displayed.

3. Select a source for the installation data in the "Boot Source" section.

4. Confirm input.

▶ The "BootOkc" window is displayed.

5. Continue with the next section.


Start installation

1. When you want to execute the installation with the final configuration, tap in the "BootOkc" window on the "Installation and Configuration" key.

- or -

→ When you want to execute the installation without the final configuration, tap in the "BootOkc" window on the "Installation" key.

▷ In the "User Message" window (INSTALLATION STARTED!) the path to the installation data is displayed.



"User Message" window (INSTALLATION STARTED!)

2. If only the files that have got altered are to be installed anew during the installation deactivate the "FORCE INSTALLATION" check box (expedites the installation process).



When you take up an installation in order to repair your operating system, activate the "FORCE INSTALLATION" check box so that the damaged files do not get overwritten subsequently.

3. To confirm the Installation press on the "YES" key.

- ▷ In the "User Message" window (CAUTION!), the version number of the Stoll operating system version selected earlier gets displayed.




"User Message" window (CAUTION!)







The current operating system version will be overwritten! When you install a new Stoll operating system version the current one is overwritten. Carry out the following step only if you want to replace the current operating system by the previous version.

4. To confirm the installation, tap on the "YES" key.

- ▷ When the installation file of the Stoll operating system has several languages, the "Install Languages" window is open.



"Install Languages" window

Key	Function
	End selection process without saving modifications
	Confirm selection
	Key "All languages"
	Key "No language"

Keys for language selection

5. Select the desired language(s).



If you want to have all languages available simultaneously, tap the "All languages" key.
If you only want

to carry on working in **German**, end selection process.

6. Confirm selection.

► The installation process gets started.

The "Language" window is displayed after having selected the "Installation and Configuration" key.

- or -

The "Reference runs" window is displayed after having selected the "Installation" key.

7. If the "Language" window is displayed, continue with the **Machine configuration** section.

- or -

→ If the "Reference runs" window is displayed, continue with the section

→ **Start reference runs.**

- Configure Machine ✓ The "Language" window is displayed.
1. Select the dialog language and confirm the selection.
 2. Proceed to the next window.
 - ▷ The "Machine configuration" window is displayed. The data have been set at the factory and will not be changed.
 3. Proceed to the next window.
 - ▷ The "Machine configuration 2" window is displayed. The data have been set at the factory and will not be changed.
 4. Proceed to the next window.
 - ▷ The "Machine Options" window is displayed. The data is set at the factory.

**Machine fault!**

The presence or lack of machine options must correctly be specified, as otherwise a fault may occur on the machine. Always specify the machine options correctly.

5. If necessary, change the data and confirm the changes.
6. Proceed to the next window.
 - ▷ The "Machine Parameter" window is displayed. The data is set at the factory.
7. If necessary, change the data and confirm the changes.
8. Proceed to the next window.
 - ▷ The "Needle bed parameters" window is displayed. The data is set at the factory.
9. If necessary, change the data and confirm the changes.
10. Proceed to the next window.
 - ▷ The "NPK-Values" window is displayed. The data is set at the factory.
11. If other NPK values are to be used, change the values and confirm the changes.
12. Proceed to the next window.
 - ▷ The "Knit Report Configuration" window is displayed.
13. If other settings are to be used, change the settings and confirm the changes. Use the "additional function keys" to activate/deactivate the running time control and/or running time measurement.
14. Proceed to the next window.
 - ▶ The configuration is complete. The "Reference runs" window is displayed.
15. Continue with the next section.

Installing the Stoll operating system

- Start reference runs
- ✓ The "Reference runs" window is displayed.
 - 1. If the racking device is not in the home position, cast-off the stitches of a needle bed.
 - 2. Carry out reference run(s).
 - 3. Proceed to the next window.
 - ▶ The installation process is complete and the "Main menu" is displayed.

Further information:

- Selecting the source of the installation data (Boot Source) [424]
- Setting waiting time until warm start [424]
- Configure machine [425]
- Configuring network [426]
- Load the machine settings in the machine computer [430]
- Saving dongle data [430]

8.4.2 Indirect installation

In the case of **Indirect Installation** the new Stoll operating system is immediately transmitted on the hard disk of the knitting machine ("Software update" window).

Overview:

- Start the installation process by switching on the machine. A message prompt displays that a new Stoll operating system is available for installation.
You have to make a decision here whether you wish to install the new Stoll operating system or wish to continue with the old one.
- Determine with the "Installation without configuration" check box whether the new Stoll operating system should be installed with simultaneous configuration of the machine parameter.
- Configure the machine if you have deactivated the "Installation without configuration" check box or carry out a reference run if you have activated the "Installation without configuration" check box.




Deactivate the "Installation without configuration" check box, if the machine parameters are also to be altered simultaneously with the installation of the new Stoll operating system. Activate the "Installation without configuration" check box, if you do not want to alter any machine parameters. This shortens the installation process.



The current operating system version will be overwritten! When you install a new Stoll operating system version the current one is overwritten. Carry out the following steps only if you want to replace the current operating system by the previous version. Save the machine data and the files specifically the ones you have created before the installation process.

- Start installation
- ✓ The Stoll operating system was updated.
 - ✓ The machine is switched off.
1. Set the main switch to 1.
 - ▷ The "BootOkc" window is displayed with the following message on the touch screen:



"User Message" window (START UPDATE NOW?)

Installing the Stoll operating system


2. Deactivate the "Installation without configuration" check box, if the machine parameters are also to be altered simultaneously with the installation of the new Stoll operating system.

- or -

- Activate the "Installation without configuration" check box, if you do not want to alter any machine parameters.
3. To start installation process tap on "YES".
 - ▷ In the "User Message" window (INSTALLATION STARTED!) the path to the installation data is displayed.



To proceed with the old Stoll operating system, tap on "NO".



"User Message" window (INSTALLATION STARTED!)

4. If only the files that have got altered are to be installed anew during the installation deactivate the "FORCE INSTALLATION" check box (expedites the installation process).



When you take up an installation in order to repair your operating system, activate the "FORCE INSTALLATION" check box so that the damaged files do not get overwritten subsequently.

5. To confirm the Installation press on the "YES" key.

- ▷ In the "User Message" window (CAUTION!), the version number of the Stoll operating system version selected earlier gets displayed.




"User Message" window (CAUTION!)







The current operating system version will be overwritten! When you install a new Stoll operating system version the current one is overwritten. Carry out the following step only if you want to replace the current operating system by the previous version.

6. To confirm the installation, tap on the "YES" key.

- ▷ When the installation file of the Stoll operating system has several languages, the "Install Languages" window is open.



"Install Languages" window

Key	Function
	End selection process without saving modifications
	Confirm selection
	Key "All languages"
	Key "No language"

Keys for language selection

7. Select the desired language(s).



If you want to have all languages available simultaneously, tap the "All languages" key.
If you only want

to carry on working in **German**, end selection process.

8. Confirm selection.

► The installation process gets started.

The "Language" window is displayed after having selected the "Installation without configuration" check box.

- or -

The "Reference runs" window is displayed after having selected the "Installation without configuration" check box.

9. If the "Language" window is displayed, continue with the **Machine configuration** section.

- or -

→ If the "Reference runs" window is displayed, continue with the section

→ **Start reference runs.**

- Configure Machine ✓ The "Language" window is displayed.
1. Select the dialog language and confirm the selection.
 2. Proceed to the next window.
 - ▷ The "Machine configuration" window is displayed. The data have been set at the factory and will not be changed.
 3. Proceed to the next window.
 - ▷ The "Machine configuration 2" window is displayed. The data have been set at the factory and will not be changed.
 4. Proceed to the next window.
 - ▷ The "Machine Options" window is displayed. The data is set at the factory.

**Machine fault!**

The presence or lack of machine options must correctly be specified, as otherwise a fault may occur on the machine. Always specify the machine options correctly.

5. If necessary, change the data and confirm the changes.
6. Proceed to the next window.
 - ▷ The "Machine Parameter" window is displayed. The data is set at the factory.
7. If necessary, change the data and confirm the changes.
8. Proceed to the next window.
 - ▷ The "Needle bed parameters" window is displayed. The data is set at the factory.
9. If necessary, change the data and confirm the changes.
10. Proceed to the next window.
 - ▷ The "NPK-Values" window is displayed. The data is set at the factory.
11. If other NPK values are to be used, change the values and confirm the changes.
12. Proceed to the next window.
 - ▷ The "Knit Report Configuration" window is displayed.
13. If other settings are to be used, change the settings and confirm the changes. Use the "additional function keys" to activate/deactivate the running time control and/or running time measurement.
14. Proceed to the next window.
 - ▶ The configuration is complete. The "Reference runs" window is displayed.
15. Continue with the next section.

Installing the Stoll operating system

- Start reference runs ✓ The "Reference runs" window is displayed.
1. If the racking device is not in the home position, cast-off the stitches of a needle bed.
 2. Carry out reference run(s).
 3. Proceed to the next window.
- ▶ The installation process is complete and the "Main menu" is displayed.

Further information:

- Configure machine [425]
- Configuring network [426]
- Load the machine settings in the machine computer [430]
- Saving dongle data [430]
- Updating software [449]









8.4.3 Updating software

A new Stoll operating system can also be copied on the hard disk while the machine is producing. No data is overwritten here; the operating system is loaded into a separate memory area.

This saves a few minutes time, as copying occurs during production. The updating is not carried out until later, i.e. when the machine is switched off and on again at the main switch. A prompt appears, asking you whether the new operating system shall be loaded.

- If the question is answered with **YES**, then the new Stoll operating system is installed.
- If it is answered with **NO**, then this question is asked again the next time you switch on whether the new Stoll operating system should be installed.


For the software update the source from where the new Stoll operating system should be copied can be selected.

Key	Function
	Call up the "Service" menu
	Call up the "Software updating" window
	Key "Select source folder"
	Key "Carry out update"
	Key "Update display"
	Save changes and end setting process
	End setting process without saving changes
	Call up "Main menu"

Keys for updating the software

Installing the Stoll operating system

- Updating software
1. Call up the "Service" menu from the "Main menu".
 2. Call up "Software updating" window.



"Software updating" window


3. Select source folder.
 - ▷ If multiple Stoll operating systems are found on the data carrier, these are listed.



When searching for the Stoll operating system the selected folder section and a section under this section (sub-folder section) is also searched.

4. If several Stoll operating systems are listed, the Stoll operating system (Type OS) that is to be copied should be marked.
5. Press the "Carry out update" key.
 - ▶ The installation files are copied on the hard disk of the machine in a separate storage location.
The "Update successfully installed" appears.

When the Stoll operating system is copied, two more program points are displayed in the "Software update" window.



"Software updating" expanded window

Key	Function				
1	The data of the separate memory area are deleted.				
2	You can choose if the installation should be carried out automatically or manually when switching on machine again				
	<table border="1"> <tr> <td>ON</td> <td>After a waiting time of 10 seconds the installation is automatically carried out till the "Reference runs" window (like in the case of "Installation"). Within the waiting time the installation can be cancelled by tapping on "Cancel". Select this setting if only the operating system should be updated.</td> </tr> <tr> <td>OFF</td> <td>Installation like in the case of "Installation and Configuration". Select this setting if machine data have been modified. For example after a gauge conversion or if a special equipment has been assembled.</td> </tr> </table>	ON	After a waiting time of 10 seconds the installation is automatically carried out till the "Reference runs" window (like in the case of "Installation"). Within the waiting time the installation can be cancelled by tapping on "Cancel". Select this setting if only the operating system should be updated.	OFF	Installation like in the case of "Installation and Configuration". Select this setting if machine data have been modified. For example after a gauge conversion or if a special equipment has been assembled.
	ON	After a waiting time of 10 seconds the installation is automatically carried out till the "Reference runs" window (like in the case of "Installation"). Within the waiting time the installation can be cancelled by tapping on "Cancel". Select this setting if only the operating system should be updated.			
OFF	Installation like in the case of "Installation and Configuration". Select this setting if machine data have been modified. For example after a gauge conversion or if a special equipment has been assembled.				

Other functions in the "Software update" window

Reset update:

- Tap on the key "Reset update" (1).
- ▶ The data is deleted in a separate storage location on the hard disk of the machine.

Select type of installation:

1. If the new Stoll operating system is to be installed after a waiting time of 10 seconds automatically, set the switch "Automatic Installation" (2) to **On**.
- or -
- If the new Stoll operating system is to be installed manually, set the switch "Automatic Installation"
 - (2) to
 - **off**.

Installing the Stoll operating system

More data on a network drive
or USB-Memory-Stick

In addition to the operating system, other data can be present on the network drive and the USB Memory Stick. Which data is available can be displayed by activating the key "Carry out updating".

Type	Meaning
OS	Operating system (OS)
IMG	Hard disk image
HDA	HD Analyst
UPT	Update of Windows XP Embedded (OPTION)
REP	Update of repair image

Selection of individual installation types

Further information:


- Indirect installation [443]

8.4.4 Carrying out a restart (Restart)

A restart is carried out when the software no longer reacts to inputs following an error.

Carry out a restart:

1. Set machine main switch to 0.
 - ▷ The switch-off process takes approx. 60 seconds. When the process is complete, the touch screen becomes dark and a signal sounds.
2. Set the main switch to 1.
 - ▷ The "BootOkc" window is displayed on the touch screen.



"BootOkc" window

3. For the automatic warm start within the waiting time tap on the key "Restart".
 - ▷ The machine is configured.
Finally the window "Reference runs " is displayed.
4. Carry out reference run(s).
5. Proceed to the next window.
 - ▶ The restart is complete and the "Main menu" is displayed.
The machine is ready to knit.

Further information:

- Setting touch screen [▢65]
- Setting waiting time until warm start [▢424]

8.4.5 Carrying out restart with machine configuration (Restart and Configuration)


A restart with the machine configuration is carried out after a gauge conversion or after attaching special attachments.

Carry out restart with machine configuration:

✓ The machine is switched off.

1. To switch on the machine, set the main switch to 1.

▷ The "BootOkc" window is displayed on the touch screen.



"BootOkc" window

2. For the automatic warm start within the waiting time tap on the "Restart and Configuration" key.

▷ The Restart Process gets started.

After the process is shut, the "Language" window is displayed.

3. Select the dialog language and confirm the selection.

4. Proceed to the next window.

▷ The "Machine configuration" window is displayed. The data have been set at the factory and will not be changed.

5. Proceed to the next window.

▷ The "Machine configuration 2" window is displayed. The data have been set at the factory and will not be changed.

6. Proceed to the next window.

▷ The "Machine Options" window is displayed. The data is set at the factory.



Machine fault!

The presence or lack of machine options must correctly be specified, as otherwise a fault may occur on the machine. Always specify the machine options correctly.





7. If necessary, change the data and confirm the changes.
8. Proceed to the next window.
 - ▷ The "Machine Parameter" window is displayed. The data is set at the factory.
9. If necessary, change the data and confirm the changes.
10. Proceed to the next window.
 - ▷ The "Needle bed parameters" window is displayed. The data is set at the factory.
11. If necessary, change the data and confirm the changes.
12. Proceed to the next window.
 - ▷ The "NPK-Values" window is displayed. The data is set at the factory.
13. If other NPK values are to be used, change the values and confirm the changes.
14. Proceed to the next window.
 - ▷ The "Knit Report Configuration" window is displayed.
15. If other settings are to be used, change the settings and confirm the changes. Use the "additional function keys" to activate/deactivate the running time control and/or running time measurement.
16. Proceed to the next window.
 - ▷ The configuration is complete.
The "Reference runs" window is displayed.
17. Carry out reference run(s).
18. Proceed to the next window.
 - ▶ The restart is complete and the "Main menu" is displayed.
The machine is ready to knit.

Further information:

- Setting touch screen [▢65]
- Setting machine parameters [▢178]
- Setting waiting time until warm start [▢424]
- Configure machine [▢425]
- Configuring network [▢426]

8.4.6 Setting online connection


The knitting machine (s) and the STOLL pattern preparation unit can be connected to an Ethernet connection.

Key	Function
	Switch on virtual keyboard
	Confirm input
	Continue on to the next window
	Confirm selection

Keys for setting online connection

Setting online connection:

- ✓ The knitting machine is switched off.
- 1. To switch on the machine, set the main switch to 1.
 - ▷ The "BootOkc" window is displayed on the touch screen.



"BootOkc" window

- 2. For the automatic warm start within the waiting time tap on the "Restart and Configuration" key.
 - ▷ The Restart Process gets started.
After the process is shut, the "Language" window is displayed.

3. Proceed to the next window.

▷ The "Machine configuration" window is displayed.

Parameter	Value
Machine classification	554
Version	0
Machine type	CMS 530
Specification of control	STOKC15-L-1
Knit and wear machine	Yes x.2 KW
Serial number	3455
Needle gauge	4.2
Needle hook gauge	4
Online ID	0
Date	07.12.2005 13:15:29

"Machine configuration" window

4. Tap in the "Online Id" field.

5. Enter the online ID of the knitting machine with the help of the virtual keyboard.

6. Confirm input.

7. Advance till the "Main menu" appears.


▶ The restart is finished.



If network problems occur and these are impairing the production, then the online ID can be set at 0 (switched off). In the "Service/Basic settings" menu call up the window "Machine-configuration" and alter the Online ID for this purpose.

8.4.7 Overview of all system data

All important hardware and software data of the control are displayed in the "System info" window.



"System info" window

Field	Data shown
1	Stoll operating system (OS) that is loaded, the machine number, machine type, gauge, yarn carrier type, etc.
2	"Memory" line: Display of the amount of memory this pattern occupies
3	Hardware and software data Network data

Key	Function
	Call up the "Service" window
	Call up "Diagnostics" window
	Call up the "System info" window
	Call up "Main menu"


Keys for calling up the "System info" window

Displaying System data:

1. In the "Main menu", tap on the "Service" key.
 - ▷ The "Service" window is displayed.
2. Tap on the "Diagnostics" key.
 - ▷ The "Diagnostics" window is displayed.
3. Tap on the "System Info" key.
 - ▶ The "System Info" window with all the important hardware and software data of the control is displayed.





8.5 Diagnose Control

You can activate different diagnoses for service purposes and for troubleshooting. The diagnoses protocol additional information in one log file which can be analysed by the service technician or the helpline.



"Diagnostic control" window

Field	Data shown
1	Take-down system: Main take-down, auxiliary take-down, comb take-down.
2	Main drive, racking, stop motions
3	Carriage position, step motor, needle selection
4	Clamping and cutting, holding-down jacks, 2nd stitch tension, presser foot, pressure cam
5	Yarn Length Control
Copy All Logfiles	Saving the data (logfiles)

Key	Function
	Call up the "Service" window
	Call up "Diagnostics" window
	Call up "Diagnostic control" window
	Call up "Main menu"

Buttons for calling up the "Diagnostic control" window

Carry out diagnoses:

1. In the "Main menu", tap on the "Service" key.
 - ▷ The "Service" window is displayed.
2. Tap on the "Diagnostics" key.
 - ▷ The "Diagnostics" window is displayed.
3. Tap on the "Diagnostic control" key.
 - ▷ The "Diagnostic control" window is displayed.
4. Tap the desired button. The diagnose is starting, you can see the work progress in the message window.
5. If other diagnoses are needed, then tap the corresponding button.
6. When all diagnoses are generated, tap on the "Copy All Logfiles" key.
 - ▶ The data (Logfiles) are saved on the selected data carrier. It will be saved on the data carrier that is set in the "Copy service data" window.

Further information:


- Copying service data [182]

9 Yarns and stitch tension

9.1 Economic production and the influencing factors

The requirements for a knitting machine can be divided into two main groups: the machine related goals and the business goals.

The knitting machine is to work with maximum speed with every knitting mode, every stitch tension, regardless of the yarn. Simultaneously a high productivity is expected from the knitting machine and the pattern shall be knitted faultless.



The simultaneous achievement of all goals is seldom possible, as there is a conflict between some goals. A conflict because they cannot be accomplished all simultaneously. Between the individual goals there are rather interactions, which can have negative effects on the accomplishment of other goals. In other words, there are goals that cannot be achieved together or that exclude each other.

Example:

One conflict exists between the yarn thickness, the stitch tension and the carriage speed. If the intention is to work at the upper limit, the maximum with all of the three goals, this will lead to a reduced running reliability of the pattern, an increased wear and in some cases even to machine damages.

The influencing factors

Running reliability	<ul style="list-style-type: none"> ◆ Structure of the pattern (knitting mode, Flexible Gauge, ...) ◆ Carriage speed ◆ Stitch length (stitch tension) ◆ Yarn quality (friction coefficient, elasticity, twisting, moisture, hairiness , bobbin setup, tensile strength) ◆ Yarn gauge, yarn count/twisted yarn ◆ Yarn type (fancy yarn) ◆ Yarn tension, yarn feeding ◆ Fabric take-down
Wear and machine damages	The unsuitable combination of the influencing factors may lead to increased wear and to the damage of machine parts.
Conclusion	<p>Therefore the influencing factors have to be adjusted.</p> <p>It's not possible to achieve any carriage speed and stitch tension with every yarn and knitting pattern.</p> <p>Recommendation: Start with a lower carriage speed (e.g. 0.7 m/sec) and increase it step by step.</p> <p>i Defective machine parts caused by disregarding our guidelines, are excluded from warranty.</p>

9.2 Stitch Tension Range

The tension ranges for knitting and splitting differ. The reason for this is the shape of the split-stitch piece. The information in the table show the minimum and maximum NP values.

Valid for:
CMS 933
CMS 822
CMS 530
CMS 520
CMS ADF-3

	min. NP	max. NP	min. NP (Split)	max. NP (Split)
E 3	7.0	16.7	8.2	15.6
E 3,5	7.0	16.7	8.2	15.6
E 4	7.0	16.7	8.2	15.6
E 5	6.5	16.9	8.0	14.1
E 7	8.3	18.7	9.8	15.9
E 8	8.8	19.5	10.3	16.6
E 10	7.25	19.2	9.3	17.65
E 12	7.55	20.0	8.4	16.2
E 14	7.95	20.7	8.8	16.85
E 16	7.6	21.9	8.9	17.85
E 18	7.6	21.9	8.9	17.85
E 5.2	7.8	17.5	9.0	14.7
E 6.2	7.55	20.0	8.4	16.2
E 7.2	7.95	20.7	8.8	16.85
E 8.2	8.0	22.3	9.3	18.25
E 9.2	8.0	22.3	9.3	18.25
E 2,5.2	6.5	16.9	8.0	14.1
E 2,5.2 m.4L	6.5	16.9	8.0	16.15
E 3,5.2	8.3	18.7	9.8	15.9
E 3,5.2 m.4L	8.3	18.7	9.8	17.95

Stitch Tension Range

Further information:

Economic production and the influencing factors [462]

Valid for:
CMS 830 C
CMS 730 T
CMS 530 T
CMS 520 C
CMS 502

	min. NP	max. NP	min. NP (Split)	max. NP (Split)
E 3	7.0	16.7	8.2	15.6
E 3 m.3L	7.0	16.7	8.2	15.6
E 3,5	7.0	16.7	8.2	15.6
E 4	7.0	16.7	8.2	15.6
E 5	6.5	16.9	8.0	14.1
E 7	8.3	18.7	9.8	15.9
E 8	8.8	19.5	10.3	16.6
E 10	7.4	21.5	9.4	17.7
E 12	7.7	21.5	9.4	15.1
E 14	8.1	22.3	9.8	15.5
E 16	8.1	22.5	9.5	15.2
E 18	8.1	22.5	9.5	15.2
E 5.2	7.8	17.5	9.0	14.7
E 6.2	7.7	21.5	9.4	15.1
E 7.2	8.1	22.3	9.8	15.5
E 8.2	8.1	22.5	9.5	15.2
E 9.2	8.1	22.4	9.5	15.5
E 2,5.2	6.5	16.9	8.0	14.1
E 2,5.2 m.4L	6.5	16.9	8.0	16.15
E 3,5.2	8.3	18.7	9.8	15.9
E 3,5.2 m.4L	8.3	18.7	9.8	17.95

Stitch Tension Range

Further information:

- Economic production and the influencing factors [462]

9.3 Stitch lengths

The specified values serve as a guideline. Depending on the yarn, these values may differ, as the quality and the specific weight of the material influence the stitch length.



NP	E 3	E 3.5	E 4	E 5	E 7	E 8	E 10 (1)	E 10 (2)	E 12
6.5				6.26					
7.0	7.67	5.90	7.03	6.96			1.83		
7.5	9.25	7.40	8.48	7.52			2.15	2.20	
8.0	10.83	8.90	9.93	8.22			2.85	2.80	2.85
8.5	12.42	10.40	11.38	8.92	4.66		3.56	3.60	3.38
9.0	14.00	11.90	12.83	9.48	5.46	3.58	4.26	4.20	3.91
9.5	15.85	13.40	14.28	10.18	6.10	4.30	4.97	4.80	4.45
10.0	17.17	14.90	15.73	10.88	6.90	5.20	5.67	5.60	4.98
10.5	18.75	16.40	17.18	11.44	7.70	5.92	6.38	6.20	5.51
11.0	20.33	17.90	18.63	12.14	8.34	6.82	7.00	7.00	6.05
11.5	21.92	19.40	20.08	12.84	9.14	7.54	7.71	7.60	6.58
12.0	23.50	20.90	21.53	13.40	9.94	8.44	8.41	8.40	7.11
12.5	25.08	22.40	22.98	14.10	10.58	9.34	9.12	9.00	7.65
13.0	26.67	23.90	24.43	14.80	11.38	10.06	9.82	9.80	8.18
13.5	28.25	25.40	25.88	15.36	12.18	10.96	10.53	10.40	8.71
14.0	29.83	26.90	27.33	16.06	12.82	11.68	11.23	11.00	9.25
14.5	31.42	28.40	28.78	16.76	13.62	12.58	11.94	11.80	9.78
15.0	33.00	29.90	30.23	17.32	14.26	13.30	12.57	12.40	10.31

Stitch length - yarn consumption per stitch (mm) with R/L fabric (Table 1)

(1) CMS 933, CMS 822, CMS 530, CMS 520, CMS ADF-3

(2) CMS 830 C, CMS 730 T, CMS 530 T, CMS 520 C, CMS 502

NP	E 14	E 16	E 18	E 2,5.2	E 2,5.2 m.4L	E 2,5.2 (3)	E 3 m.3L	E 3,5.2	E 3,5.2 m.4L
6.5				6.26	5.29		10.55		5.48
7.0				6.96	6.06	4.36	10.55		5.48
7.5				7.52	6.91	5.71	11.80		5.48
8.0		1.88		8.22	7.68	7.06	13.05	4.97	5.48
8.5	2.58	2.16	1.86	8.92	8.45	8.41	14.30	5.30	5.84
9.0	3.13	2.51	2.21	9.48	9.30	9.76	15.55	6.13	6.63
9.5	3.68	2.86	2.56	10.18	10.07	11.11	16.80	6.80	7.42
10.0	4.23	3.21	2.91	10.88	10.84	12.46	18.05	7.63	8.30
10.5	4.78	3.56	3.26	11.44	11.69	13.81	19.30	8.47	9.09
11.0	5.33	3.91	3.61	12.14	12.46	15.16	20.55	9.13	9.88
11.5	5.88	4.26	3.96	12.84	13.23	16.51	21.80	9.97	10.76
12.0	6.43	4.61	4.31	13.40	14.08	17.86	23.05	10.80	11.56
12.5	6.98	4.96	4.66	14.10	14.85	19.21	24.30	11.47	12.35
13.0	7.53	5.31	5.01	14.80	15.62	20.56	25.55	12.30	13.23
13.5	8.08	5.66	5.36	15.36	16.47	21.91	26.80	13.13	14.02
14.0	8.63	6.01	5.71	16.06	17.24	23.26	28.05	13.97	14.81
14.5	9.18	6.36	6.06	16.76	18.01	24.61	29.30	14.80	15.69
15.0	9.73	6.71	6.41	17.32	18.86	25.96	30.55	15.47	16.48

Stitch length - yarn consumption per stitch (mm) with R/L fabric (Table 2)

(3) CMS 830 C

Yarn table

NP	E 5.2	E 6.2	E 6.2 (knit and wear) (4)	E 7.2	E 7.2 (knit and wear) (5)	E 8.2	E 9.2
6.5							
7.0							
7.5	3.54	2.14	1.77				
8.0	3.86	2.47	2.07	2.14	1.58	1.57	1.61
8.5	4.66	3.02	2.57	2.58	1.99	1.91	1.91
9.0	5.46	3.57	3.08	3.13	2.49	2.33	2.30
9.5	6.26	4.12	3.58	3.68	3.00	2.75	2.68
10.0	7.06	4.67	4.08	4.23	3.50	3.18	3.06
10.5	7.86	5.22	4.58	4.78	4.01	3.60	3.45
11.0	8.66	5.77	5.08	5.33	4.51	4.02	3.83
11.5	9.46	6.32	5.58	5.88	5.02	4.45	4.21
12.0	10.26	6.87	6.09	6.43	5.52	4.87	4.60
12.5	11.06	7.42	6.59	6.98	6.03	5.29	4.98
13.0	11.86	7.97	7.09	7.53	6.53	5.72	5.36
13.5	12.66	8.52	7.59	8.08	7.04	6.14	5.75
14.0	13.46	9.07	8.09	8.63	7.54	6.56	6.13
14.5	14.26	9.62	8.59	9.18	8.05	6.99	6.51
15.0	15.06	10.17	9.10	9.73	8.55	7.41	6.90

Stitch length - yarn consumption per stitch (mm) with R/L fabric (Table 3)

(4) CMS 822



(5) CMS 530, CMS 822, CMS ADF-3

Further information:

- Economic production and the influencing factors [462]

9.4 Yarn table

The specified values serve as a guideline. The quality and the specific weight of a yarn must also be taken into account. Instead of a simple yarn, we recommend twisted yarn. With coarser machines it is advisable to use several twisted threads.

Gauge	assembled processing [Nm]	Final count [Nm]
	 <p>Several fine threads are assembled and fed as a thick yarn to the yarn carrier.</p>	 <p>Yarn thickness of the assembled threads Example: 6 x 16/2 $16/2=8$ $8:6=1,33$</p>
2	6 x 16/2	1,2 - 1,4
2.5	6 x 18/2	1,3 - 1,6
3	5 x 18/2	1 - 2
3 m.3L	15 x 20/2	0,65 - 1
3.5	6 x 24/2	1,4 - 2,5
4	5 x 24/2 6 x 34/2	1,4 - 3
5	4 x 24/2 4 x 34/2	3 - 4,5
7	2 x 22/2 2 x 28/2	4,5 - 7
8	2 x 24/2 2 x 34/2	6 - 8
10	2 x 36/2 1 x 24/2	8 - 12
12	1 x 24/2 2 x 44/2	10 - 18
14	1 x 28/2 2 x 40/1	14 - 20

Yarn table - Allocation of machine gauge and yarn thickness (Table 1)

Further information:

- Economic production and the influencing factors [462]

Yarn table

Gauge	assembled processing [Nm]	Final count [Nm]
16	1 x 48/2 1 x 54/2 1 x 60/2	20 - 30
18	1 x 54/2 1 x 60/2 1 x 80/2	20 - 40
20	1 x 80/2	20 - 40
2,5.2 (all needles)	3 x 28/2 2 x 14/2	3 - 4,5
2,5.2 m.4L	All needles: 3 x 28/2 Nm	3 - 4,5
	Every 2nd needle: 8 x 28/2 Nm	1,3 - 2
	Every 2nd needle with cast-off technique: maximum 13 x 28/2 Nm	1,1
2,5.2 (CMS 830 C) (each 2nd needle)	3 x 14/2 6 x 14/2	1 - 2
2,5.2 (each 2nd needle)	3 x 14/2 4 x 14/2	1,3 - 2
3,5.2 (all needles)	2 x 28/2 3 x 28/2	4,5 - 7
3,5.2 (each 2nd needle)	3 x 14/2 7 x 28/2	1,5 - 2,5
3,5.2 m.4L	All needles: 3 x 28/2 Nm	4,5 - 7
	Every 2nd needle: 7 x 28/2 Nm	1,5 - 2,5
	Every 2nd needle with cast-off technique: maximum 9 x 28/2 Nm	1,5

Yarn table - Allocation of machine gauge and yarn thickness (Table 2)

Further information:

- Economic production and the influencing factors [462]

Gauge	assembled processing [Nm]	Final count [Nm]
5.2 (all needles)	1 x 20/2 2 x 28/2	8 - 12
5.2 (each 2nd needle)	3 x 28/2 4 x 28/2	3 - 4,5
6.2 (all needles)	2 x 44/2 1 x 28/2	10 - 16
6.2 (each 2nd needle)	2 x 28/2 3 x 28/2	4,5 - 7
7.2 (all needles)	1 x 28/2 1 x 30/2	14 - 20
7.2 (each 2nd needle)	2 x 28/2 2 x 30/2	6 - 8
8.2 (all needles)	1 x 50/2 2 x 60/2	15 - 25
8.2 (each 2nd needle)	2 x 50/2 3 x 60/2	10 - 12
9.2 (all needles)	1 x 40/2 1 x 60/2	20 - 30
9.2 (each 2nd needle)	2 x 40/2 2 x 44/2 2 x 60/2 3 x 60/2	10 - 16

Yarn table - Allocation of machine gauge and yarn thickness (Table 3)

Further information:

- Economic production and the influencing factors [462]

Knitting technique
information

Gauge	Explanation
2,5.2 and 3,5.2 (knit and wear)	If an extreme yarn (non-elastic and/or very thick) is used, it should not be knitted too loosely (in the upper NP area), as there is a danger of wear of the cams and needle bed.

Knitting technique information

Further information:


- Economic production and the influencing factors [462]

9.5 Conversion table

The following table is used for the conversion of one yarn gauge to another. The named yarn gauges mean:

	TEX (Tt)
	Grams per kilometer
	COTTON (NeC)
	Number of strands at 840 yds. per lb.
	WORSTED (NeW)
	Number of strands at 560 yds. per lb.
	METRIC (Nm)
	Meters per gram
	DENIER (den)
	Grams per 9000 meters
	DECITEX (dtex)
	Grams per 10000 meters

Due to the great variety of natural and synthetic fibers, it must be noted that yarns with a low specific weight are often more voluminous than yarns with a high specific weight. Therefore, the relationship dtex / den / Nm does not necessarily correspond to the conversion result.



10 Empty chapter

11 Machine Management Tools

In our world the fast exchange of information has achieved a high level of significance. In order that the knitting machines lives up to the growing requirements, a series of auxiliary tools in the software have been taken up with the control OKC that can prove to be more efficient while working with the knitting machine and they are referred under the "Machine Management Tools" term comprehensively.

This chapter contains information on:




- Machine Management Tools window [▢475]
- Display the virtual keyboard [▢476]
- Remote control with the software VNC [▢477]
- Send email directly from the machine [▢485]

11.1 Machine Management Tools window



"Machine Management Tools" window

- 1 Opens the "VNC Properties (Service-Mode)" window for configuration of the remote control VNC.
- 2 Opens the "Send email" window to send the emails directly from the machine.
- 3 A virtual keyboard opens.

Key	Function
	Call up the "Service" window
	Call up "Diagnostics" window
	Call up "Machine Management Tools" window

Keys for calling up the machine management tools

Call up machine management tools:

1. In the "Main menu", tap on the "Service" key.
2. In "Service" window, tap on "Diagnostics" key.
3. In "Diagnostics" window, tap on the "Machine Management Tools" key.
 - ▷ The "Machine Management Tools" window opens.
4. Call up the desired machine management tools.

In the following sections is described how to set up the different tools and how to use them.

Further information:





- Display the virtual keyboard [476]
- Remote control with the software VNC [477]
- Send email directly from the machine [485]

Display the virtual keyboard

11.2 Display the virtual keyboard


For inputs that are not integrated in the user interface, an external keyboard or a virtual keyboard is required.

Display the virtual keyboard

Key	Function
	Call up the "Service" window
	Call up "Diagnostics" window
	Call up "Machine Management Tools" window
	Call up "Main menu"

Keys for calling up "Send email" window

1. Call up the "Service" window.
2. Call up "Diagnosis" window.
3. Call up "Machine Management Tools" window.
4. Tap on the "Virtual keyboard" switch.
 - ▷ The virtual keyboard is open.



Virtual keyboard

With the virtual keyboard you can make inputs as if an external keyboard has been connected.

You can find information for usage of the virtual keyboard in the "Help" menu.

Tips for working with the virtual keyboard:

- A **locked** key (e. g. alt) must be activated finally again to achieve a double key function.
- Various key layouts can be selected ("Keyboard" menu).

11.3 Remote control with the software VNC

You can use the remote control VNC to control a networked machine (VNC Server) by a remote computer (VNC client) as if you were standing in front of the machine and entering data via the touch screen.

Requirements:

- Network
- Networked and correctly configured ready-to-use machine
- Computer that serves as a client, is also networked (e.g. a note-book)
- Software VNC Viewer for the client
- Software for the client:
VNC Viewer or the Java Runtime Engine from Sun Microsystems Inc.

The VNC Viewer software for the client can for e.g. be obtained from the following manufacturer websites:

- www.realvnc.com
- www.tightvnc.com
- www.ultravnc.sourceforge.net








The Java Runtime Engine for the client can be obtained from the manufacturer website www.java.com.

In the following sections is described how to activate and use the remote control VNC:

- Activating the remote control VNC on the machine [▢478]
- Configuring the remote control VNC on the machine [▢479]
- Determine the IP address of the machine [▢480]
- Installing software VNC Viewer on the computer (e.g. a note-book) [▢480]
- Remote control with the VNC Viewer [▢481]
- Remote control via a web browser [▢483]

11.3.1 Activating the remote control VNC on the machine

The remote control VNC is deactivated on the knitting machine by default.


Key	Function
	Call up the "Service" window
	Call up "Diagnostics" window
	Call up "Machine Management Tools" window
	Call up "Additional function keys"
	Activate/deactivate "Remote control VNC"
	
	Call up "Main menu"

Keys to activate the remote control VNC on the machine

1. Call up the "Service" window.
 2. Call up "Diagnosis" window.
 3. Call up "Machine Management Tools" window.
 4. Call up "Additional function keys".
 5. Tap on "Remote control VNC" key.
- The activation of the remote control VNC gets is acknowledged by a message.

11.3.2 Configuring the remote control VNC on the machine

- ✓ The remote control VNC is activated on the machine.
- ✓ The "Machine Management Tools" window is displayed.
- 1. Tap on the "Remote operation - settings" switch.
 - ▷ The "VNC Server Properties (service mode)" window opens with different tabs.



"VNC Server Properties (service mode)" window with the "Connections" tab

2. Activate "Connections" tab.
Here all the fields are set to their default values.
3. Should another port be activated as the standard port 5900 the number of the port is to be entered in the "Accept connections on port:" field.
4. If the machine has to be controlled remote also via a web browser, activate the check box "Serve Java viewer via HTTP on port:" and enter 5800 as port.







Any other adjustments on the various tabs are not necessary.




The value in the "Disconnect idle clients after (seconds):" field causes the automatic disconnection of a VNC connection when the value entered here is exceeded and within the mentioned time no operation is carried out. Thereafter, the connection can be established again without any problem. By default one hour = 3600 seconds is adjusted.

11.3.3 Determine the IP address of the machine

Key	Function
	Call up the "Service" window
	Call up "Diagnostics" window
	Call up the "System info" window
	Call up "Main menu"

Keys for determining the IP address of the machine

- ✓ The main menu is displayed.
- 1. In the "Main menu", tap on the "Service" key.
- 2. In "Service" window, tap on "Diagnostics" key.
- 3. In "Diagnostics" window, tap on the "System Info" key.
- ▷ The "System Info" window opens.



"System info" window

- 4. Note IP address (2) and host name (1).

11.3.4 Installing software VNC Viewer on the computer (e.g. a note-book)

- ✓ The software VNC Viewer was obtained from the internet.
- 1. Start installation program.
- 2. Follow instructions of the installation program.
- ▶ Thereafter the software VNC Viewer is installed on the computer.

11.3.5 Remote control with the VNC Viewer

1. Start the software VNC Viewer on the computer.

▷ The "VNC Viewer: Connecting Details" window opens.



"VNC Viewer: Connection Details" window


2. Enter the noted IP address of the machine in the "Server" field.



When your network makes the **Naming Service** available, instead of the IP address the host name can also be entered. If another port as **5900** was entered during configuration of the remote control VNC on the machine, the port must be entered along with e. g. 172.17.12.54:5903.

3. In order to configure the software VNC Viewer when needed, click on the "Options" button.

▷ The "VNC Viewer Options" window opens.



"VNC Viewer Options" window, "Colour & Encoding" tab

4. In order that all colors are displayed, activate the "Full (all available colours)" option on the "Colour & encoding" tab under "Colour level".
5. In order to make a small square visible as the mouse pointer alternative, deactivate the "Render cursor locally" check box on the "Misc" tab.
6. To save the option adjustments, click on the "Save" button on the "Load / Save" tab under "Defaults".



You can find continuative instructions for configuration of VNC in the documentation of VNC.

7. Click on the "OK" button.

▷ The "VNC Viewer: Connection Details" window opens.

8. Click on the "OK" button.

► Now the user interface of the selected machine gets displayed.



Fig. 348: Display of the user interface of the machine

9. Operate the machine now from this window.



The machine can be operated simultaneously through the user interface of the machine or through the computer (VNC Client).

Further information:

- Configuring the remote control VNC on the machine [479]

11.3.6 Remote control via a web browser

When the Java Runtime Engine from Sun Microsystems Inc. is installed on the controlling computer (client), the access to a machine can be also be done through the web browser without the software VNC Viewer being installed.

By default the port **5800** is adjusted for this access on the VNC server on the machine and is activated in the server adjustment under **Serve Java Viewer**.


Start remote control:

1. Start web browser e.g. the Internet Explorer.
2. Enter the following address as URL: `http://<IP address of the machine>:5800`
 - ▷ A Java applet is run which is obtained as a alternative for the software VNC Viewer from VNC Server (machine).
Then the web browser appears as follows:



Web browser with the Java applet from VNC

3. Above opens the window "VNC Viewer: Connection Details".
The IP address is entered automatically.




"VNC Viewer: Connection Details" window

Remote control with the software VNC

4. Click on "Options".

▷ The "VNC Viewer: Connection Details" window opens.



"VNC Viewer: Connection Details" window

5. In order that all colors are displayed, activate the "Full (all available colours)" option on the "Encoding and Colour Level:".

6. In order to activate the mouse pointer alternative, deactivate the "View only (ignore mouse & keyboard)" check box under "Inputs".

7. Click "OK".

► The user interface of the machine is opened in the web browser and can now be operated from here.



Fig. 352: Display of user interface of the machine in the "Java applet" window








The machine can be operated through the user interface of the machine or in the "Java applet" window simultaneously.

11.4 Send email directly from the machine

In the "Send email" window emails can be written and sent directly from the machine.


For this purpose the machine must be connected to the internet or to a network with a mail server. Call up your network administrator in order to install this function.

Call up Send email window

Key	Function
	Call up the "Service" window
	Call up "Diagnostics" window
	Call up "Machine Management Tools" window
	Call up "Send email" window
	Call up "Main menu"







Keys for calling up "Send email" window

1. Call up the "Service" window.
2. Call up "Diagnosis" window.
3. Call up "Machine Management Tools" window.
4. The "Send email" window opens.
 - ▷ The "Send email" window opens.



"Send email" window on the machine

Send email directly from the machine

Inputs	Explanation
	"Delete all entries" key (except the entry in the "from" field).
	"Send email" key.
From	Sender of message. The machine name is entered here as a sender as standard. If you are expecting an answer to the email, enter a valid email address here as the machine cannot receive any emails.
To	addressee of message. Several addressee names are to be separated by a semicolon (;).
Subject	Subject of the message.
	Field for entering message text.
Mail attachment	
	"Unzipped" key: In the "File name" field, displayed files are attached unzipped to the message.
	"Zipped" key: The files which are displayed in the "File name" field are zipped before they are attached to the message.
	"Delete marked entry" key (in the "File name " field).
	"Mail attachment" key: Opens the "Mail attachment" window for selection of files (for example bitmaps, log files, zip files) that can be attached to the message. The file names are displayed in the "File name" field subsequently.
File name	Display of file (s) which are attached to the message.

Entries in the "Send email" window

Write email



Use the virtual keyboard for input.

1. Enter a sender address in the "from" field.



If you are expecting an answer to the email, enter a valid email address here as the machine cannot receive any emails.

2. In the "To" field, enter the email address of the receiver.
Several addressee names are to be separated by a semicolon (;).
3. In the "Subject" field, enter the subject of the message.
4. In the field below the "Subject" field, enter the content of the message.




With the "Delete all inputs" key, you can delete the inputs in all the fields of the "Send email" window (except the entry in the "from" field).

Attach files to the email

You can attach any files to an email which are sent with the message. In order to reduce the size of the file, the files to be attached can be zipped (compressed).

1. Tap on "Mail attachment" key.
 - ▷ The "Mail attachment" window opens.



"Mail attachment" window

2. In "Mail attachment" window, select the file that has to be attached.
 3. Confirm selection.
 - ▷ The file is displayed in the "File name" field.
 4. If additional files are to be attached, repeat the steps 1 to 3.
 5. If the files in the "File name" field are to be attached zipped to the email, tap on "Zipped" key.
- or -
- If the files in the "File name" field are to be attached unzipped to the email, tap on "Unzipped" key.



In order to remove a file from the "File name" field, mark this file and then tap on the "Delete marked entry" key.

Send email directly from the machine

- Send email ✓ Sender and receiver addresses have been entered correctly.
- ✓ The message is entered.
- ✓ The email attachments are selected.
- Tap on "Send email" key.
- ▶ The email is sent with the attachments.

Key word directory

A

Additional needle bed

Repair, 367

Adjusting

Adjust the belt take-down values, 136

Brushes of the central lubrication, 203

Carriage speed, 111

Fabric take-down, 135

Fabric take-down (control), 137,174

Fabric take-down menu (WBF), 139,143

Float slider (opening angle), 219

Friction feed wheel, 131

Horn, 174

Intarsia yarn carrier (type 1), 204

Intarsia yarn carrier (type 2), 205

Knitting areas (SEN), 134

Needle brushes, 194

Needle detector, 200

Plating yarn carrier, 226

Sensor mechanism, 174

Shape counters, 146

Stopping point of an intarsia yarn carrier, 207,218

Yarn carrier, 118,201

Yarn carrier guide, 203

Yarn carrier limiters, 202

Yarn carriers staggering, 126

Yarn tension, 129

Aggregates

Switching on and off, 169

Auxiliary take-down, 42

B

Backup copy, 254

Basic Settings, 423

Battery card, 397,400,403

Boot process, 419

Brushes (central lubrication)

Adjusting, 203

C

- Carriage assembly, 32
 - Coupling wide or narrow (CMS 822), 195
- Carriage part
 - Assembling, 379
 - Removing, 374
- Carriage speed
 - Economic production and the influencing factors, 462
 - Following machine stop, 178
 - Outside SEN area (MSECOS), 178
 - With open safety doors, 178
 - With small knots, 174
- Carriage Speed, 111
- Catch hook, 29
- Central lubrication, 33
 - Deaerating oil line, 394
 - Mounting and working position, 351
 - Setting, 329
- Cleaning
 - Knitting machine, 316
 - Needle bed, 323
- Cleaning row, 32
 - Setting, 169
- Comb functions
 - Run manually, 138,163
- Comb take-down, 43
 - Switching light barrier on and off, 174
- Component type, 13
- Computer viruses, 59,235
- Conditional stop, 85
- Configuring
 - Monitoring, 153
 - Toolbar, 151
- Control devices, 37
- Conversion table, 472
- Copy Logfiles, 430
- Copying
 - File, 254
- Courses of yarn, 23

D

- Date, 425
- Dongle data
 - Save, 430

E

- Electronic card
 - Control cabinet, 397,400,403
 - Replacing, 407
 - Tasks, 397,400,403
- E-mail, 485
- Emergency switch-off switch, 45
- End of work
 - Switch off knitting machine automatically, 87
- Engaging Rod, 46
- Error messages
 - Retrospective view, 109
 - Suppress, 111
- Ethernet
 - Set Online ID, 456

F

- Fabric sensors, 44
 - Switching on and off, 169
- Fabric take-down, 41
 - Adjusting, 135
 - Adjusting control, 174
 - Auxiliary take-down, 42
 - Comb take-down, 43,174
 - Control devices, 44
 - Releasing main take-down during switch-off, 178
 - Remove fabric winding, 106
 - Winding plate, 44
 - Winding protection device, 44
- Fault
 - Correcting stitch cam position (NPK), 192
 - Drop stitches, 194
 - Drop stitches (Intarsia), 219
 - Electronic cards, 397,400,403
 - Eliminate errors in the fabric, 101
 - Holes (Intarsia), 219
 - Intarsia yarn carrier - Adjust stopping point (basic setting, braking value), 207
 - Needle and coupling part, 355
 - Remove fabric winding around fabric take-down, 106
 - Removing cam plate, 382
 - Removing carriage part, 374
 - Removing step motor, 383
 - Replacing comb hook, 395
 - Replacing gear rack (step motor), 384
 - Replacing holding-down jack, 361
 - Replacing intermediate slider, 357
 - Replacing selection jack, 360
 - Save pattern after a big fault, 434,434
 - Start again after pressing off fabric, 101
 - Start machine, 107
 - Thread loop tears (Intarsia), 219
 - Threading-up thread into yarn carrier, 105
 - Wrong selection (needle selection displacement), 417,428
- Feed wheel
 - Friction feed wheel, 27
 - Storage feed wheel MSF 3, 27,133
 - Switch on and off, 169
- File
 - Copying, 254

- Displaying in the pattern editor, 250
- File Manager, 241
- Load and save, 245
- Loading, 59
- Managing, 241
- Float slider, 219
- Fluff absorption, 32
 - Switching on and off, 169
- Folder
 - Direct selection, 257
 - Load and save, 245
 - Loading, 59
 - Managing, 241
 - Setting path, 257
- Friction feed wheel, 27
 - Adjusting, 131
 - Replacing the friction roller, 391,391
 - Replacing the position of the friction roller, 391
- Function keys
 - Additional function keys, 55
 - Main menu, 52
 - Selection elements, 57
 - Standard function keys, 54
 - Standard input elements, 56
 - Virtual keyboard, 58
- Fuses
 - Checking, 408

H

- Hardware data, 458
- Helpline address, 13
- Holding-down jack, 35
 - Float slider (opening angle), 219
 - Replacing, 361
- Horn
 - Switching on and off, 174

I

- Impulse sensor, 37
- Input unit, 49
 - Cleaning, 317
 - Screen brightness, 66
 - Setting, 65
 - Touch pen, 49
- Intarsia yarn carrier, 30
 - Adjusting (type 1), 204
 - Adjusting (type 2), 205
 - Adjusting stopping point (braking value), 207
 - Check the pressure plates, 216
 - Correct stopping point (correction value), 218
 - Float slider (opening angle), 219
 - Mounting, 389
 - Normal yarn carrier type2, 222
 - Shifting, 206
- Internet address, 13

K

- KnitLAN 269
- Knitted structure 231
- Knitting areas (SEN)
 - Adjusting 134
- Knitting machine
 - Automatic switching off at end of work 87
 - Cleaning 316
 - Copying service data 182
 - Economic production and the influencing factors 462
 - Load the machine settings 430
 - Lubricating 327
 - Machine configuration 425
 - Machine data on the USB-Memory-Stick 432
 - Machine data sheet 182,233
 - Remote control with a web browser 483
 - Remote operation 477
 - Start after fault 107
 - Stitch length 466
 - Stitch tension range 464
 - Stop 85
 - Yarn table 469
- Knitting mode
 - Economic production and the influencing factors 462
- Knitting program
 - Apply shape counter 76
 - Check 260
 - Delete knitting memory 252
 - Enter number of courses 64
 - Enter piece number 64
 - Loading 59
 - Start 75
- Knitting system 34
- Knock-over wire 231

L

- Language
 - Setting, 172
 - Setting (Startup), 182
- Lateral yarn tensioner, 28
- Library
 - Load and save, 245
 - Loading, 59
- Lighting
 - Switching on and off, 148,169
- Loading
 - File, 245
 - Knitting program, 59
- Loss of data, 59,235
- Loss of production, 59,235
- Lubricants, 327
- Lubricating interval (needle bed)
 - Restarting, 334
 - Setting, 328
- Lubrication schedule, 327

M

- Machine data
 - Copying service data, 182
 - Machine data sheet, 182,233
 - USB-Memory-Stick, 432
- Machine main switch, 45
- Machine Management Tools, 474
 - Call up, 475
 - Remote control VNC, 477
- Machine parameters
 - Setting, 178
- Main switch, 45
 - Switch-off process, 45
- Main take-down, 41
- Maintenance, 313
- Message retrospective view, 109
- Monitoring, 153
- Motor type, 425

N

- Needle bed
 - Clean thoroughly, 323
 - Needle bed parameters, 176
 - Removing, 364
 - Repair, 367
 - Structure, 39
- Needle brushes
 - Adjusting, 194
- Needle detector, 38
 - Adjusting, 200
- Needle selection displacement, 417
- Needle selection displacement
 - Entering data manually, 428
- Network, 269
 - Configuring, 426
- Network data, 458
- Normal yarn carrier type 2, 222
- Number of courses
 - Enter, 64

O

- Online, 269
 - Set ID, 456
- Operating data, 78,81
- Operating system
 - Direct installation, 437
 - Direct/indirect installation, 436
 - Display the current version, 431
 - Display the previous version, 431
 - Indirect installation, 443
- Order data, 99
- Order menu, 96

P

Pattern

Setting up, 157

Pattern editor

Displaying file, 250

Piece number

Enter, 64

Plating

Double bow yarn carrier, 226

Normal yarn carrier type2, 222

Plating yarn carrier, 31,222

Adjusting, 226

Power failure, 180

Power supply 40 V, 349

Power supply unit, 397,400,403

Production

Economic production and the influencing factors, 462

Measure running time, 94

Monitor running time, 89

Program test, 260

R

Racking

- Racking basic correction VGK, 189
- Racking correction, 165
- Racking course, 39
- Racking device, 39
- Racking position correction VPK, 187

Raising cam, 34

Reference Run, 184

Remote control VNC

- Activate, 478
- Configure, 479
- Determine IP-address, 480
- Install software VNC Viewer, 480
- Start and configure Viewer, 481
- Web-Browser, 483

Removing

- Cam plate, 382
- Carriage part, 374
- Needle bed, 364
- Selection jack bed, 371
- Step motor, 383

Replacing

- Comb hook, 395
- Drive belt (friction feed wheel), 391
- Electronic card, 407
- Friction roller (friction feed wheel), 391
- Fuses, 408
- Gear rack (Step motor), 384
- Holding-down jack, 361
- Intarsia yarn carrier, 389
- Intermediate slider, 357
- Knock-over wire, 231
- Needle and coupling part, 355
- Pressure plates (intarsia yarn carrier), 216
- Selection jack, 360
- Yarn carrier, 388
- Yarn control unit, 391

Report, 78

- Save, 78

Restart, 453

Restarting with the machine configuration, 454

Running reliability

- Economic production and the influencing factors, 462

Running time

- Measuring, 94
- Monitoring, 89

S

- Screen brightness
 - Setting, 66
- Selection jack bed
 - Removing, 371
- Selection system, 34
- Sensors
 - Adjusting, 174
- Service data
 - Copying, 182
 - Machine data sheet, 182,233
- Setting
 - Aggregates, 169
 - Carriage speed following machine stop, 178
 - Carriage speed with small knots, 174
 - Central lubrication, 329
 - Clamping depth of cutting needle, 169
 - Cleaning row, 169
 - Comb take-down (light barrier), 174
 - Counter, 148
 - Cycle counter, 145
 - Date, time and time zone, 425
 - Fabric take down (releasing during switch-off), 178
 - Fabric take-down values, 135
 - Input unit, 65
 - Language, 172
 - Lighting, 148
 - Lubricating interval (needle bed), 328
 - Machine parameters, 178
 - Monitoring, 153
 - Motor type, 425
 - Needle bed parameters, 176
 - Path, 257
 - Piece number, 145
 - Power failure (switch-off time), 180
 - Racking basic correction VGK, 189
 - Racking correction, 165
 - Racking position correction VPK, 187
 - Screen brightness, 66
 - Shock stop (piezo), 176
 - Stitch cam position (NPK), 192
 - Stitch tension, 114
 - Stop resistance, 174
 - Suction, 169
 - Toolbar, 151
 - Touch screen, 65
 - Value for releasing thread clamp, 150
- Setup, 274
 - Setup1, 309
 - Setup2, 280
- Shift counter, 81
 - Automatic shift change, 83
- Shifting device (intarsia yarn carrier), 206
- Shock stop, 38
 - Setting, 176
- Signal light, 48
- Sintral editor, 262
- Software
 - Advanced adjustments (Enhanced Settings), 429

- Basic Settings, 423
- Configure network, 426
- Diagnose Control, 460
- Direct installation, 437
- Direct/indirect installation, 436
- Display current version, 431
- Display history, 431
- Display the previous version, 431
- Error diagnosis with Copy Logfiles, 430
- Indirect installation, 443
- Load the machine settings, 430
- Machine configuration, 425
- Machine data on the USB-Memory-Stick, 432
- Restart, 453
- Restart with machine configuration, 454
- Save dongle data, 430
- Select boot source, 424
- Set waiting time for warm start, 424
- Update, 449
- Software data, 458
- Software VNC, 477
 - Install viewer, 480
- Step motor, 36
 - Removing, 383
 - Replacing gear rack, 384
- Stitch cam, 34
 - Correcting stitch cam position (NPK), 192
- Stitch length, 466
- Stitch tension
 - Economic production and the influencing factors, 462
 - Step motor, 36
 - Stitch tension range, 464
- Stop resistance, 38
 - Setting, 174
- Suction, 32
- Summer time, winter time, 425
- Switch-off process, 45
- Symbols in this document, 14
- System configuration, 458
- System Control Unit (SCU), 419
- System crash
 - Save pattern after a big fault, 434
- System data, 458,460
- System info, 458,460

T

- Thread clamp, 29,44
 - Releasing, 150
- Thread clamping and cutting device, 29
- Time, 425
- Time zone, 425
- Tips history, 109
- Toolbar, 151
- Touch pen, 49
- Touch screen, 49
 - Cleaning, 317
 - Setting, 65
 - Touch pen, 49
- Touch Screen
 - Screen brightness, 66
- TP
 - Program test, 260
- Type plate, 13

U

- Update (software), 449
- User Interface, 50
- User profile, 272

V

- Virtual keyboard, 58,476
- Viruses, 59,235

W

- warm start
 - Interrupt warm start, 419
- Warmstart
 - Set waiting time for warm start, 424
- Wear
 - Economic production and the influencing factors, 462
 - Minimizing, 314
- Winding plate, 44
- Winding protection device, 44
- Worms, 59,235

Y

Yarn

- Conversion table, 472
- Courses of yarn, 23
- Economic production and the influencing factors, 462
- Threading up, 67
- Yarn table, 469

Yarn carrier

- Adjusting, 201
- Adjusting guide, 203
- Call up assignment, 67
- Correction (tandem machine), 123
- Intarsia yarn carrier, 30
- Normal yarn carrier type2, 222
- Plating yarn carrier, 31,222
- Replacing, 388
- Staggering, 126

Yarn carrier limiters

- Adjusting, 202

Yarn control unit

- Replacing, 391

Yarn deflector, 44

Yarn tension

- Adjusting, 129

Yarn tensioner (side), 28

